


## ECU POWER SOURCE CIRCUIT

### CIRCUIT DESCRIPTION


When the ignition switch is turned ON, battery positive voltage is applied to the coil which closes the contacts of the EFI main relay (Marking: EFI) and supplies power to the terminal +B of the engine ECU.

### WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 CHECK ECU



- (a) Turn the ignition switch ON.
- (b) Measure voltage between the terminals +B of the engine ECU E6 connector and E1 of the engine ECU E8 connector.


**VOLTAGE: 9-14 V**

OK

CHECK AND REPLACE ECU

NG

## 2 CHECK HARNESS AND CONNECTOR (ECU GROUND)



- (a) Disconnect the battery negative terminal.
- (b) Disconnect the engine ECU E8 connector.
- (c) Check continuity between the terminal E1 of engine ECU E8 connector and body ground. (Terminal arrangement on 05-241)

**RESISTANCE: 1Ω or less**


- (d) Check continuity between the terminal E1 of the engine ECU E8 connector and body ground. (Terminal arrangement on 05-241)

**RESISTANCE: 1Ω or less**

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

**3 CHECK E.F.I ECU RELAY**

- (a) Check continuity between the terminals shown below.


**RESISTANCE:**

TERMINAL NO.	RESISTANCE
1 - 2	1 $\Omega$ or less
3 - 5	1 M $\Omega$ or more


- (b) Check continuity between the terminals 3 and 5 of the connector when the battery voltage is applied to the terminals between 1 and 2.

**RESISTANCE:**

TERMINAL NO.	RESISTANCE
3 - 5	1 $\Omega$ or less


**NG****REPLACE E.F.I ECU RELAY****OK****4 CHECK FUSE(E.F.I.FUSE)**

- (1) Check continuity of E.F.I. fuse

**RESISTANCE: 1  $\Omega$  or less****NG****REPLACE FUSE****OK****5 CHECK RELAY OPERATION(E.F.I. COMPUTER RELAY)**

- (a) Confirm that the E.F.I relay operates normally when turning the ignition switch ON.

**RESULT:****E.F.I. relay operation sound is heard successively when turning the ignition switch ON.****NG****Go to step 9****OK**


**6 CHECK HARNESS AND CONNECTOR(ENGINE ECU-E.F.I. COMPUTER RELAY)**

- (a) Disconnect the battery negative (-) terminal.
- (b) Remove the E.F.I. computer relay.
- (c) Check continuity between the terminals 1 of the E.F.I. computer relay in the engine room R/B and +B of the engine ECU E6 connector.

**RESISTANCE: 1Ω or less**

- (d) Check continuity between the terminals 1 of the EFI computer relay in the engine room R/B and E1 of the engine ECU E8 connector.


**RESISTANCE: 1MΩ or more**



**NG**

**REPAIR OR REPLACE HARNESS AND CONNECTOR**

**OK**

**7 CHECK HARNESS AND CONNECTOR(E.F.I.FUSE-BATTERY)**

- (a) Disconnect the battery negative (-) connector.
- (b) Remove the E.F.I. fuse.
- (c) Check continuity between the terminals 1 of the EFI fuse holder in the engine room R/B and negative (-) of the battery.

**NOTICE:**


**Do not insert the tester leads hard in the procedure (c), or the holder may be damaged.**

**NG**

**REPAIR OR REPLACE HARNESS AND CONNECTOR**


**OK**

**REPLACE ENGINE ROOM RELAY BLOCK**

**8 INSPECT IGNITION OR STARTER SWITCH ASSY**

- (a) Check continuity between the connector terminals shown in the chart below.


Switch	Terminal No.	Resistance
LOCK	All Terminals	1MΩ or more
ACC	1↔3	1Ω or less
ON	1↔2↔3 5↔6	1Ω or less
START	4↔5↔6 1↔2	1Ω or less

**NG****REPLACE IGNITION OR STARTER SWITCH ASSY****OK****9 CHECK HARNESS AND CONNECTOR(IGNITION SWITCH-E.F.I. COMPUTER RELAY)**

- (a) Disconnect the battery negative (-) terminal.  
 (b) Remove the E.F.I. circuit opening relay.  
 (c) Disconnect the ignition switch connector.  
 (d) Check continuity between the terminals IG2 of the ignition switch connector and 5 of the E.F.I. circuit opening relay in the R/B.

**RESISTANCE: 1Ω or less**

- (e) Check for short between the terminal IG2 of the ignition switch and body ground.

**RESISTANCE: 1MΩ or more****NG****REPAIR OR REPLACE HARNESS AND CONNECTOR****OK****REPLACE ENGINE ROOM RELAY BLOCK**