

# TOYOTA INDUSTRIAL VEHICLE

# PARTS CATALOG

02-2FDC30

02-FDC28

No.G107-4

TOYOTA MOTOR CORPORATION  
TOYODA AUTOMATIC LOOM WORKS, LTD.

# TOYOTA

## FORKLIFT TRUCK

### PARTS CATALOG

|                |                 |
|----------------|-----------------|
| MODEL          | ----- FDC ----- |
| FRAME NO.      | 2 FDC 3 0 ----- |
| ENGINE NO.     | 2 J -----       |
| LIFTING HEIGHT | ----- mm -----  |

#### DESCRIPTION

|                                       |                                 |
|---------------------------------------|---------------------------------|
| Catalytic Muffler                     | UL-approved Model Type D        |
| Cyclone Air Cleaner<br>Single Element | UL-approved Model Type DS       |
| Cyclone Air Cleaner<br>Dual Element   | Oil Clutch                      |
|                                       | Fully Oil Charged Lift Cylinder |
|                                       |                                 |
|                                       |                                 |

**TOYOTA MOTOR CORPORATION**  
**TOYODA AUTOMATIC LOOM WORKS, LTD.**

#### QUICK REFERENCE INDEX

INTRODUCTION

ENGINE

FUEL SYSTEM

CHASSIS

BODY

ELECTRICAL SYSTEM

MAST

HYDRAULIC SYSTEM

## GENERAL INFORMATION

This parts catalog has been prepared for the customers of Toyota Industrial Vehicles and this shows only the part name codes instead of parts numbers.

When ordering parts from your local Toyota dealer, please specify the complete model number of the truck, the engine number or frame number. Also it is essential that you specify the part name codes described in the pages of illustrations and text.

The complete model number and frame number are shown in the front page of this catalog. All the columns in this quick reference index are supposed to be filled out by both the factory and your local dealer.

For the industrial vehicle with optional equipment, which is described in the lower part of the DESCRIPTION, it is imperative for you to specify optional equipment when ordering parts.

Your Toyota dealer has always been furnished with enough information to decode the correct part numbers based on your information of model number, engine number or frame number as well as part name code.

## INFORMATIONS D'ORDRE GENERAL

Ce catalogue de pièces a été préparé pour les propriétaires de Véhicules Industriels Toyota. On n'y trouvera que les codes de désignation de pièces au lieu des numéros de pièces.

Pour la commande de pièces auprès de votre concessionnaire Toyota, prière de spécifier le numéro de modèle complet de l'engin, le numéro du moteur ou le numéro du châssis. Il est aussi nécessaire de spécifier les codes de désignation de pièces comme ils sont décrits dans les pages d'illustrations et dans le texte.

Le numéro de modèle complet et le numéro de châssis sont indiqués en première page de ce catalogue. Toutes les colonnes de l'index de référence rapide devraient être remplies par l'usine et par votre concessionnaire.

Pour le véhicule industriel avec équipement optionnel, décrit en bas de page sous la rubrique "DESCRIPTION", il convient de bien spécifier qu'il s'agit de cet équipement lors de commande de pièces.

Votre concessionnaire Toyota est toujours suffisamment informé pour décoder les numéros de pièces sur la base de votre information du numéro de modèle, du numéro de moteur ou de châssis, et des codes de désignation de pièces.

## INFORMACION GENERAL

Este catálogo de piezas ha sido preparado para los clientes de vehículos industriales de TOYOTA, e incluye tan sólo los códigos de nombre de pieza en lugar de los números de pieza.

Cuando solicite piezas a su distribuidor local de TOYOTA especifique por favor el número de modelo completo del vehículo, el número de motor o el número de bastidor. Asimismo, es esencial que Vd. especifique los códigos de nombre de pieza descritos en las páginas de ilustraciones y de texto.

El número completo de modelo y el número de bastidor se indican en la portada de este catálogo. Se supone que todas las columnas de este índice de referencia se han rellenado, tanto por parte de la fábrica como por parte de su distribuidor local.

En lo que concierne a los vehículos industriales con equipos opcionales, que se describen en la parte baja de la DESCRIPCION, es absolutamente necesario que especifique equipos opcionales cuando solicite piezas de repuesto.

Su distribuidor local de TOYOTA posee la información necesaria para descifrar los números correctos de cada pieza a base de su información de número de modelo, número de motor o número de bastidor, así como el código de nombre de la pieza.

## ALLGEMEINE INFORMATION

Dieser Teilekatalog wurde für die Benutzer von Toyota Industriefahrzeugen zusammengestellt und zeigt anstelle von Teilenummern nur die Teilennamen-Kodes.

Geben Sie bei Teilebestellungen von Ihrem Toyota-Händler am Platz bitte die vollständige Modellnummer des Fahrzeugs, die Motornummer oder Fahrgestellnummer an. Es ist auch erforderlich, daß Sie die in den Illustrationen und im Text beschriebenen Teilennamen-Kodes angeben.

Die vollständige Modellnummer und Fahrgestellnummer finden Sie auf der Vorderseite dieses Katalogs. Alle Spalten in dieser Bezugstabelle sollen sowohl vom Werk als von Ihrem Händler am Platz ausgefüllt werden.


Für Industriefahrzeuge mit Sonderausrüstung, welche im unteren Teil der BESCHREIBUNG erläutert ist, müssen Sie bei der Bestellung von Teilen unbedingt diesbezügliche Angaben machen.

Ihr Toyota-Händler verfügt stets über genügend Information, um die richtigen Teilenummern zu entschlüsseln, basiert auf Ihren Angaben zu Modellnummer, Motornummer oder Fahrgestellnummer und den Teilennamen-Kodes.

Essentially, one (1) page will present both the illustration and part name code. However, when the space for text page is not enough the next page will be used in succession.

Básicamente, una (1) página incluirá tanto la ilustración como el código de nombre de la pieza.


No obstante, si el espacio no fuese suficiente, se utilizará la página siguiente.



- 1 **Número de figura**  
Este catálogo de piezas se ha preparado de acuerdo con los números de las figuras.
- 2 **Título de las figuras**  
Como título de las figuras de la página de ilustraciones, se incluye un nombre que sea representativo del nombre del mayor conjunto.
- 3 **Subtítulo**  
Se indican el nombre opcional o las especificaciones especiales de cada ilustración.
- 4 **Código de nombre de pieza**  
Se trata de una combinación de número de figura y de código de las ilustraciones correspondientes a cada pieza. Esta es la clave para que su distribuidor local de TOYOTA pueda encontrar el número de pieza correcto.
- 5 **Nombre de la pieza**  
Como norma, se indica el nombre de cada uno de los códigos de nombre de pieza.
- 6 **QTY (Cantidad)**  
La columna de cantidad indica el número de piezas utilizadas de cada unidad de código de nombre de pieza.  
Cuando la cantidad utilizada es intercambiable entre cada uno de los vehículos, se indica el máximo.  
Cuando la cantidad de piezas utilizadas pueda diferir o ser superior a 100, se indica como cantidad 99.
- 7 **Números de piezas normalizadas**  
Las piezas corrientes, tales como pernos, tuercas, arandelas etc., se describen con número de pieza. Cuando solicite tales piezas, indique su número de pieza.

## ILLUSTRATION ET COMPOSITION DU DE TEXTE DE CODE DE DESIGNATION DE PIECE

Une (1) page contiendra essentiellement une illustration et ses codes de désignation de pièce. Toutefois, lorsque l'espace réservé au texte est insuffisant, la continuation se trouvera sur la page suivante.



- Numéro de figure**  
Ce catalogue de pièces a été préparé en fonction des numéros de figures.
- Titre de figure**  
Une désignation de pièce représentative, celle d'une pièce d'un ensemble important, est indiquée comme titre de figure de l'illustration.
- Sous-titre**  
La désignation optionnelle ou les spécifications spéciales de chaque illustration sont indiquées.
- Code de désignation de pièce**  
Obtenu en combinant le numéro de figure et les codes des illustrations inhérents à chaque pièce. Ce code permettra à votre concessionnaire Toyota de trouver les numéros de pièces corrects.
- Désignation de pièce**  
La désignation de la pièce est indiquée pour chacun des codes de désignation de pièce.
- Q'ty (quantité)**  
La colonne quantité indique les pièces utilisées de l'unité de code de désignation de pièce. La quantité maximum est indiquée quand la quantité utilisée diffère pour chacun des véhicules. Quand la quantité de pièces utilisées diffère ou lorsqu'elle dépasse 100 pièces, la quantité 99 est indiquée.
- Numéros de pièces standard**  
Les pièces standard comme les boulons, les écrous, les rondelles, etc. sont décrits dans les numéros de pièces. Pour commander ces pièces, prière de spécifier les numéros de pièces.

## ABBILDUNG UND TEXTSEITENAUFBAU FÜR TEILENAMEN-KODE

Grundsätzlich finden Sie auf einer (1) Seite sowohl die Abbildung als auch den Teilnamen-Kode.  
Wenn für den Text jedoch nicht genügend Platz vorhanden ist, wird er auf der nächsten Seite fortgesetzt.

- Abbildungsnummer**  
Dieser Teilekatalog wurde nach Abbildungsnummern zusammengestellt.
- Abbildungstitel**  
Ein stellvertretender Teilname, welcher zugleich die Bezeichnung für die Hauptbaugruppe ist, wird als Abbildungstitel der Illustration angegeben.
- Untertitel**  
Ein zusätzlicher Name oder eine besondere Kennzeichnung werden für jede Illustration angegeben.
- Teilnamen-Kode**  
Dies ist eine Kombination von ziffern und Abbildungskodes, die jedes Teil betreffen. Es ist ein Schlüssel für Ihren Toyota-Händler, um die richtigen Teilenummern zu finden.
- Teilname**  
Grundsätzlich wird der Teilname für alle Teilnamen-Kodes angegeben.
- QTY (Menge)**  
Die Mengenspalte gibt die benutzte Stückzahl von Teilnamen-Kode-Einheiten an.  
Wenn die benutzte Stückzahl je nach Fahrzeug Verschieden ist, wird die Höchstmenge angegeben.  
Wenn die benutzte Menge 100 Stück überschreiten kann, wird als Menge 99 angegeben.
- Standardteile-Nummern**  
Die Standardteile, wie Schrauben, Muttern, Unterlegscheiben usw., sind in den Teilenummern beschrieben. Geben Sie bei Bestellung dieser Teile die Teilenummern an.

## DATA PLATE & SERIAL NUMBERS

For retrieving correct part numbers, it's indispensable to know the truck model, as well as frame number (or engine number).  
Customers can obtain said information in the data plate on the truck or in this user parts catalog.

## PLAQUE DE DONNEES TECHNIQUES & NUMEROS DE SERIE

Pour relever correctement le numéro des pièces, il est indispensable de connaître le modèle de l'engin, ainsi que le numéro du châssis (ou du moteur).  
Les propriétaires peuvent trouver ladite information sur la plaque de données techniques de l'engin ou dans le présent ouvrage.

## PLACA DE DATOS Y NUMEROS DE SERIE

Para obtener los números de pieza correctos, es indispensable conocer el modelo del vehículo, así como el número del bastidor (o del motor).  
Los clientes pueden obtener dicha información por la placa de datos del vehículo o este catálogo de piezas para el usuario.


## DATENPLATTE & SERIENNUMMERN

Um die richtige Teilenummer zu ermitteln, müssen unbedingt das Fahrzeugmodell sowie die Fahrgestellnummer (oder die Motornummer) bekannt sein.  
Kunden können diese Angaben von der Datenplatte am Fahrzeug oder in diesem Teilekatalog für Benutzer entnehmen.

Data plate  
Placa de datos  
Plaque de données techniques  
Datenplatte

|                                                                                                                      |                      |
|----------------------------------------------------------------------------------------------------------------------|----------------------|
|  <b>TOYOTA</b><br><b>LIFT TRUCK</b> |                      |
| MODEL                                                                                                                | <input type="text"/> |
| CODE NO. OF SPECIAL MODEL MODEL OF ATTACHMENT                                                                        |                      |
| VOLTAGE                                                                                                              | <input type="text"/> |
| FRAME NO.                                                                                                            | <input type="text"/> |
| LIFTING HEIGHT                                                                                                       | <input type="text"/> |
| CAPACITY                                                                                                             | <input type="text"/> |
| WEIGHT                                                                                                               | <input type="text"/> |
| PROD. YEAR                                                                                                           | <input type="text"/> |
| <b>TOYODA AUTOMATIC</b><br><b>LOOM WORKS. LTD.</b><br>KARIYA JAPAN                                                   |                      |


Data plate  
Placa de datos  
Plaque de données techniques  
Datenplatte




Frame Number  
(Top of the frame)  
Número de bastidor  
(Parte superior del bastidor)

Numéro de châssis  
(haut du châssis)  
Fahrgestellnummer  
(Oben am Fahrgestell)


# FIG. INDEX




エンジン アセンブリ  
Engine Assembly




ショート ブロック アセンブリ  
Short Block Assembly




オーバーホール ガasket kit  
Overhaul Gasket kit




シリンダ ヘッド  
Cylinder Head



シリンダ ブロック  
Cylinder Block





ギア カバート エンド プレート  
Gear Cover & End Plate




マウンティング  
Mounting


## エンジン グループ ENGINE GROUP (1/2)




ベンチレーション ホース  
Ventilation Hose




クランク シャフト & ピストン  
Crankshaft & Piston




カムシャフト & ベルブ  
Camshaft & Valve




オイル ポンプ  
Oil Pump




エア クリーナ  
Air Cleaner




エキゾースト パイプ  
Exhaust Pipe




マニホールド  
Manifold



ラジエータ ファン  
Radiator & Fan



ウォーター ポンプ  
Water Pump




オイル フィルタ  
Oil Filter

ENGINE, FUEL GROUP (2/2)




ENGINE, FUEL GROUP (2/2)




ニユー・マチック ガバサ  
Pneumatic Governor


# FIG. INDEX




LPG Fuel Pipe




LPG キャブレッタ  
LPG Carburetor



LPG Regulator




LPG フィルタ  
LPG Filter






LPG Container

LPG グループ  
LPG GROUP



# FIG. INDEX

|                                                                                                                     |                                                    |                                             |                                                        |                                                                |                                                                |                                                              |
|---------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|---------------------------------------------|--------------------------------------------------------|----------------------------------------------------------------|----------------------------------------------------------------|--------------------------------------------------------------|
| FIG. 3101 (MTM) 1<br>クラッチ<br>Clutch                                                                                 | FIG. 3102 (MTM) 2<br>クラッチ ペダル<br>Clutch Pedal      | FIG. 3105 3<br>クラッチ ブースター<br>Clutch Booster | FIG. 3106 4<br>フロー ダイヴィディング バルブ<br>Flow Dividing Valve | FIG. 3201 (ATM) 5<br>トルクコンバータ ハウジング<br>Torqueconverter Housing | FIG. 3201 (ATM) 6<br>オーバーホール キット<br>Overhaul Kit               | FIG. 3202 (ATM) 7<br>トルクコンバータ<br>Torqueconverter             |
| シャシ グループ<br>CHASSIS GROUP (1/2)  |                                                    |                                             |                                                        |                                                                |                                                                |                                                              |
| FIG. 4407 20<br>リア ネイロートタイヤ<br>Rear Wheel & Tire                                                                    |                                                    |                                             |                                                        |                                                                |                                                                | FIG. 3203 (ATM) 8<br>トルクコンバータ クラッチ<br>Torqueconverter Clutch |
| FIG. 4406 19<br>フロント ネイロートタイヤ<br>Front Wheel & Tire                                                                 |                                                    |                                             |                                                        |                                                                |                                                                | FIG. 3204 (ATM) 9<br>トルクコンバータ ギヤ<br>Torqueconverter Gear     |
|                                                                                                                     |                                                    |                                             |                                                        |                                                                | FIG. 3206 (ATM) 10<br>コントロール バルブ<br>Control Valve              |                                                              |
|                                                                                                                     |                                                    |                                             |                                                        |                                                                | FIG. 3213 (ATM) 11<br>トルクコンバータ パイピング<br>Torqueconverter Piping |                                                              |
| FIG. 4301 18<br>リア アクスル<br>Rear Axle                                                                                | FIG. 4201 17<br>フロント アクスル シャフト<br>Front Axle Shaft | FIG. 4101 16<br>ディファレンシャル<br>Differential   | FIG. 3303 (MTM) 15<br>ギヤ シフト フォーク<br>Gear Shift Fork   | FIG. 3302 (MTM) 14<br>トランスミッション ギヤ<br>Transmission Gear        | FIG. 3301 (MTM) 13<br>トランスミッション ケース<br>Transmission Case       | FIG. 3214 (ATM) 12<br>コントロール シャフト<br>Control Shaft           |









# FIG. INDEX

|                                                                                                                                                  |                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                |                                                                                                                                                  |                                                                                                                                              |                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>FIG. 4501</p> <p>1</p>  <p>ステアリングホイール<br/>Steering Wheel</p> | <p>FIG. 4502</p> <p>2</p>  <p>ステアリングポスト<br/>Steering Post</p> | <p>FIG. 4507</p> <p>3</p>  <p>ドラッグリンクとパイピング<br/>Drag Link &amp; Piping</p> | <p>FIG. 4508</p> <p>4</p>  <p>パワーシリンダ<br/>Power Cylinder</p> | <p>FIG. 4601</p> <p>5</p>  <p>パーキングブレーキ<br/>Parking Brake</p> | <p>FIG. 4701</p> <p>6</p>  <p>ブレーキペダル<br/>Brake Pedal</p> | <p>FIG. 4704</p> <p>7</p>  <p>ブレーキバルブ<br/>Brake Valve</p>              |
| <p>シャシ グループ<br/>CHASSIS GROUP (2/2)</p>                       |                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                |                                                                                                                                                  |                                                                                                                                              |                                                                                                                                                           |
|                                                                                                                                                  |                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                |                                                                                                                                                  |                                                                                                                                              | <p>FIG. 4706</p> <p>8</p>  <p>ブレーキアクкумуляター<br/>Brake Accumulator</p> |
|                                                                                                                                                  |                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                |                                                                                                                                                  |                                                                                                                                              | <p>FIG. 4714</p> <p>9</p>  <p>ブレーキパイプ<br/>Brake Pipe</p>               |
|                                                                                                                                                  |                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                |                                                                                                                                                  |                                                                                                                                              | <p>FIG. 4715</p> <p>10</p>  <p>ブレーキ<br/>Brake</p>                     |
|                                                                                                                                                  |                                                                                                                                                |                                                                                                                                                             |                                                                                                                                                |                                                                                                                                                  |                                                                                                                                              |                                                                                                                                                           |

# FIG. INDEX

|                                                                                                                                       |                                                                                                               |                                                                                                                                   |                                                                                                                            |                                                                                                                                             |                                                                                                                                   |                                                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| FIG. 5101<br><br>フレームトウエイト<br>Frame & Weight         | FIG. 5201<br><br>フード<br>Hood | FIG. 5301<br><br>インストルメントパネル<br>Instrument Panel | FIG. 5308<br><br>ドライバースイット<br>Driver Seat | FIG. 5401<br><br>ヘッドガードトアクセサリー<br>Head Guard & Accessory | FIG. 5405<br><br>インジケータプレート<br>Indicator Plate | FIG. 5502<br><br>フロントガラス<br>Front Glass                 |
| <p>ボデー、エレクトリカルグループ<br/>BODY, ELECTRICAL GROUP</p>  |                                                                                                               |                                                                                                                                   |                                                                                                                            |                                                                                                                                             |                                                                                                                                   |                                                                                                                                            |
|                                                                                                                                       |                                                                                                               |                                                                                                                                   |                                                                                                                            |                                                                                                                                             |                                                                                                                                   | FIG. 5601<br><br>ワイヤリング<br>Wiring                       |
|                                                                                                                                       |                                                                                                               |                                                                                                                                   |                                                                                                                            |                                                                                                                                             |                                                                                                                                   | FIG. 5611<br><br>ランプ<br>Lamp                            |
|                                                                                                                                       |                                                                                                               |                                                                                                                                   |                                                                                                                            |                                                                                                                                             |                                                                                                                                   | FIG. 5612<br><br>ランプブラケット<br>Lamp Bracket               |
|                                                                                                                                       |                                                                                                               |                                                                                                                                   |                                                                                                                            |                                                                                                                                             |                                                                                                                                   | FIG. 5701<br><br>メータートスイッチ<br>Meter & Switch          |
|                                                                                                                                       |                                                                                                               |                                                                                                                                   |                                                                                                                            |                                                                                                                                             | FIG. 5802<br><br>ヒーター<br>Heater              | FIG. 5801<br><br>ワイパーモータートブレード<br>Wiper Motor & Blade |


# FIG. INDEX

|                                                                                                                                                   |                                                                                                                                           |                                                                                                                                          |                                                                                                                                  |                                                                                                                                                    |                                                                                                                                                 |                                                                                                                                                    |
|---------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| FIG. 6101<br><br>マスト<br>Mast                                     | FIG. 6301<br><br>リフト ブラケット ト フォーク<br>Lift Bracket & Fork | FIG. 6302<br><br>チェーント チェーン ホイール<br>Chain & Chain Wheel | FIG. 6501 (V)<br><br>リフト シリンダ<br>Lift Cylinder | FIG. 6502 (FV, FSV)<br><br>フロント リフト シリンダ<br>Front Lift Cylinder | FIG. 6503 (FV, FSV)<br><br>リア リフト シリンダ<br>Rear Lift Cylinder | FIG. 6504 (M)<br><br>リフト シリンダ<br>Lift Cylinder                  |
| マスト , ハイドロリック コンポーネント グループ<br>MAST, HYDRAULIC COMPONENT GROUP  |                                                                                                                                           |                                                                                                                                          |                                                                                                                                  |                                                                                                                                                    |                                                                                                                                                 | FIG. 6511<br><br>ティルト シリンダ<br>Tilt Cylinder                     |
|                                                                                                                                                   |                                                                                                                                           |                                                                                                                                          |                                                                                                                                  |                                                                                                                                                    |                                                                                                                                                 | FIG. 6701<br><br>オイル ポンプ<br>Oil Pump                            |
|                                                                                                                                                   |                                                                                                                                           |                                                                                                                                          |                                                                                                                                  |                                                                                                                                                    |                                                                                                                                                 | FIG. 6705<br><br>オイル コントロール バルブ<br>Oil Control Valve            |
|                                                                                                                                                   |                                                                                                                                           |                                                                                                                                          |                                                                                                                                  |                                                                                                                                                    |                                                                                                                                                 | FIG. 6709<br><br>オイル コントロール バルブ リンク<br>Oil Control Valve Link |
|                                                                                                                                                   |                                                                                                                                           |                                                                                                                                          |                                                                                                                                  |                                                                                                                                                    |                                                                                                                                                 | FIG. 6802<br><br>マスト パイピング<br>Mast Piping                     |
|                                                                                                                                                   |                                                                                                                                           |                                                                                                                                          |                                                                                                                                  |                                                                                                                                                    |                                                                                                                                                 | FIG. 6801<br><br>ボディ パイピング<br>Body Piping                     |

Silverhorn.co.uk

FIG. 0901  
STANDARD TOOL

0901



| PART NAME<br>CODE | PART NAME           | QTY |
|-------------------|---------------------|-----|
| 0901-01           | TOOL SET, STANDARD  | 1   |
| 0901-10           | SPANNER SET         | 1   |
| 0901-11           | PUMP ASSY, GREASE   | 1   |
| 0901-40           | BAG, TOOL           | 1   |
| 0901-41           | PRIERS              | 1   |
| 0901-42           | DRIVER, SCREW       | 1   |
| 0901-43           | WRENCH, MONKEY      | 1   |
| 0901-47           | WRENCH, HUB NUT BOX | 1   |

(2) ( 1 ) 6107


FIG. 1101  
ENGINE ASSY

1101

2J


2J

00



1101 001

02




1101 008

FIG. 1101  
ENGINE ASSY

1101

2J



| PART NAME<br>CODE | PART NAME                      | QTY |
|-------------------|--------------------------------|-----|
| 1101-00           | ENGINE ASSY                    | 1   |
| 1101-00K          | GASKET KIT, ENGINE O/H         | 1   |
| 1101-00L          | GASKET KIT, ENGINE VALVE GRIND | 1   |
| 1101-02           | BLOCK ASSY, SHORT              | 1   |




(2J) ( 2)

G107

FIG. 1104  
CYLINDER HEAD

1104

2J



1104 009


| PART NAME<br>CODE | PART NAME                              | QTY |
|-------------------|----------------------------------------|-----|
| 1104-20           | HEAD SUB-ASSY, CYLINDER                | 1   |
| 1104-20A          | BUSH, VALVE GUIDE INTAKE               | 4   |
| 1104-20B          | BUSH, VALVE GUIDE EXHAUST              | 4   |
| 1104-20C          | BOLT (FOR CYLINDER HEAD SET)           | 18  |
| 1104-21           | COVER SUB-ASSY, CYLINDER HEAD          | 1   |
| 1104-21B          | WASHER, SEAL (FOR CYLINDER HEAD COVER) | 1   |
| 1104-30           | CAP SUB-ASSY, OIL FILLER               | 1   |
| 1104-30A          | GASKET (FOR OIL FILLER CAP)            | 1   |
| 1104-40           | GASKET, CYLINDER HEAD                  | 1   |
| 1104-41           | GASKET, CYLINDER HEAD COVER            | 1   |
| 1104-42           | GASKET, CYLINDER HEAD REAR PLATE       | 1   |
| 1104-43A          | PLUG, TIGHT, NO.1                      | 9   |
| 1104-AA           | PLATE, CAUTION                         | 1   |
| 1104-AB           | PLUG, W/HEAD TAPER SCREW               | 1   |
| 1104-AC           | DEFLECTOR, NO.1                        | 1   |
| 1104-AD           | PLUG, STRAIGHT                         | 1   |
| 1104-AE           | TUBE                                   | 4   |
| 1104-AF           | PLATE, HEAD REAR                       | 1   |

(2J) ( 5 ) G107

FIG. 1105  
CYLINDER BLOCK

1105

2J



| PART NAME<br>CODE | PART NAME                       | QTY |
|-------------------|---------------------------------|-----|
| 1105-20           | BLOCK SUB-ASSY, CYLINDER        | 1   |
| 1105-21           | PAN SUB-ASSY, OIL               | 1   |
| 1105-21A          | PLUG (FOR OIL PAN DRAIN)        | 1   |
| 1105-21B          | GASKET (FOR OIL PAN DRAIN PLUG) | 1   |
| 1105-30           | GAGE SUB-ASSY, OIL LEVEL        | 1   |
| 1105-40           | GASKET, OIL PAN                 | 1   |
| 1105-41           | GUIDE, OIL LEVEL GAGE           | 1   |
| 1105-42           | LINER, CYLINDER                 | 4   |
| 1105-42A          | SLIM, CYLINDER LINER            | 99  |
| 1105-43A          | PLUG, TIGHT, NO.1               | 3   |
| 1105-43B          | PLUG, TIGHT, NO.2               | 9   |
| 1105-43C          | PLUG, TIGHT, NO.3               | 3   |
| 1105-44           | COVER, VALVE PUSH ROD           | 1   |
| 1105-44A          | GASKET, VALVE PUSH ROD COVER    | 1   |
| 1105-AA           | SUPPORT, OIL LEVEL GAGE GUIDE   | 1   |
| 1105-AB           | PIN, STRAIGHT                   | 1   |
| 1105-AC           | COCK SUB-ASSY, DRAIN            | 1   |
| 1105-AD           | PLUG, DRAIN COCK                | 1   |
| 1105-AE           | PIN, STRAIGHT                   | 4   |
| 1105-AF           | PIN, STRAIGHT                   | 2   |
| 1105-AG           | PLUG, W/HEAD TAPER SCREW        | 5   |
| 1105-AH           | PIN, RING                       | 10  |
| 1105-AI           | BOLT                            | 10  |
| 1105-AJ           | PLUG, STRAIGHT                  | 2   |
| 1105-AK           | GASKET                          | 2   |
| 1105-AL           | PLUG, TAPER                     | 1   |


(20) ( 4 )

G107

FIG. 1106  
TIMING GEAR COVER & END PLATE

1106

2J




| PART NAME<br>CODE | PART NAME                              | QTY |
|-------------------|----------------------------------------|-----|
| 1106-10           | FLANGE ASSY, HYDRAULIC PUMP            | 1   |
| 1106-10B          | RING, O, HYDRAULIC PUMP FLANGE         | 1   |
| 1106-20           | COVER SUB-ASSY, TIMING GEAR (OR CHAIN) | 1   |
| 1106-20A          | SEAL, OIL (FOR TIMING GEAR COVER)      | 1   |
| 1106-23           | CASE SUB-ASSY, TIMING GEAR             | 1   |
| 1106-41           | GASKET, TIMING GEAR (OR CHAIN) COVER   | 1   |
| 1106-42           | GASKET, FRONT END PLATE                | 1   |
| 1106-45           | GASKET, REAR OIL SEAL RETAINER         | 1   |
| 1106-46           | RETAINER, REAR OIL SEAL                | 1   |
| 1106-46A          | SEAL, ENGINE REAR OIL                  | 1   |
| 1106-48           | GEAR, PUMP DRIVE                       | 1   |
| 1106-48A          | BEARING, PUMP DRIVE GEAR, NO.1         | 1   |
| 1106-48B          | BEARING, PUMP DRIVE GEAR, NO.2         | 1   |
| 1106-52           | BEARING, INJECTION PUMP GEAR THRUST    | 1   |
| 1106-AA           | PIN, STRAIGHT                          | 2   |
| 1106-AB           | RING, SHAFT SNAP                       | 1   |
| 1106-AC           | BOLT, STUD                             | 3   |

(23) (5) G107


FIG. 1107  
MOUNTING

1107

ZJ



RADIATOR



1107-005


| Part Name Code | Part Name                                  | Qty |
|----------------|--------------------------------------------|-----|
| 1107-30        | SUPPORT SUB-ASSY, ENGINE BRACKET, RH ----- | 1   |
| 1107-31        | SUPPORT SUB-ASSY, ENGINE BRACKET, LH ----- | 1   |
| 1107-40        | BRACKET, ENGINE MOUNTING, FR, RH -----     | 1   |
| 1107-41        | BRACKET, ENGINE MOUNTING, FR, LH -----     | 1   |
| 1107-43        | INSULATOR, ENGINE MOUNTING, FR -----       | 2   |
| 1107-AA        | WASHER, PLATE -----                        | 2   |

(2J) ( 6) G107

FIG. 1201  
VENTILATION HOSE

1201

2J



1201 010




| PART NAME<br>CODE | PART NAME               | QTY |
|-------------------|-------------------------|-----|
| 1201-40           | HOSE, VENTILATION, NO.1 | 1   |

(2J ) ( 7) G107

FIG. 1301  
CRANKSHAFT & PISTON

1301

20



1301-001


| PART NAME<br>CODE | PART NAME                             | QTY |
|-------------------|---------------------------------------|-----|
| 1301-20           | ROD SUB-ASSY, CONNECTING              | 4   |
| 1301-20A          | BUSH, CONNECTING ROD                  | 4   |
| 1301-20B          | BOLT, CONNECTING ROD                  | 8   |
| 1301-20C          | NUT, HEXAGON (FOR CONNECTING ROD)     | 2   |
| 1301-21           | PISTON SUB-ASSY, W/PIN                | 1   |
| 1301-21A          | RING, HOLE SNAP (FOR PISTON PIN)      | 8   |
| 1301-30           | BEARING SET, CONNECTING ROD           | 1   |
| 1301-31           | BEARING SET, CRANKSHAFT               | 1   |
| 1301-32           | RING SET, PISTON                      | 1   |
| 1301-34           | WASHER SET, CRANKSHAFT THRUST         | 1   |
| 1301-40           | CRANKSHAFT                            | 1   |
| 1301-41           | PULLEY, CRANKSHAFT                    | 1   |
| 1301-41A          | KEY, CRANKSHAFT (FOR PULLEY SET)      | 1   |
| 1301-42           | GEAR OR SPROCKET, CRANKSHAFT TIMING   | 1   |
| 1301-42A          | KEY, CRANKSHAFT (FOR TIMING GEAR SET) | 1   |
| 1301-AC           | BOLT                                  | 1   |
| 1301-AD           | WASHER, PLATE                         | 1   |

(23) ( 8) G107

FIG. 1302  
CAMSHAFT & VALVE

1302

2J



1302 001

| PART NAME<br>CODE | PART NAME                              | QTY |
|-------------------|----------------------------------------|-----|
| 1302-20           | SHAFT SUB-ASSY, VALVE ROCKER, NO.1     | 1   |
| 1302-22           | ARM SUB-ASSY, VALVE ROCKER, NO.1       | 4   |
| 1302-22A          | SCREW, VALVE ADJUSTING                 | 8   |
| 1302-22B          | SPRING, COMPRESSION (FOR ROCKER ARM)   | 4   |
| 1302-22C          | NUT, ADJUSTING SCREW HEXAGON           | 8   |
| 1302-23           | ARM SUB-ASSY, VALVE ROCKER, NO.2       | 4   |
| 1302-30           | BEARING SET, CAMSHAFT                  | 1   |
| 1302-40           | CAMSHAFT                               | 1   |
| 1302-40B          | PLUG, EXPANSION (FOR CAMSHAFT)         | 1   |
| 1302-41           | GEAR OR SPURCKLT, CAMSHAFT TIMING      | 1   |
| 1302-41A          | BEARING, CAMSHAFT TIMING GEAR          | 1   |
| 1302-42           | ROD, VALVE PUSH                        | 8   |
| 1302-43           | VALVE, INTAKE                          | 4   |
| 1302-43A          | SLAL OR RING, O (FOR VALVE STEM OIL)   | 8   |
| 1302-44           | VALVE, EXHAUST                         | 4   |
| 1302-45           | LIFTER, VALVE                          | 8   |
| 1302-46           | SPRING, VALVE COMPRESSION              | 8   |
| 1302-47           | RETAINER, VALVE SPRING                 | 8   |
| 1302-47A          | LOCK, VALVE SPRING RETAINER            | 16  |
| 1302-49           | PLATE, CAMSHAFT THRUST                 | 1   |
| 1302-54           | GEAR, IDLE (FOR CAMSHAFT)              | 1   |
| 1302-55           | SHAFT, IDLE GEAR (FOR CAMSHAFT)        | 1   |
| 1302-56           | SUPPORT, VALVE ROCKER, NO.1            | 1   |
| 1302-57           | SUPPORT, VALVE ROCKER, NO.2            | 2   |
| 1302-58           | SUPPORT, VALVE ROCKER, NO.3            | 1   |
| 1302-59           | SUPPORT, VALVE ROCKER, NO.4            | 1   |
| 1302-60           | PLATE, IDLE GEAR THRUST (FOR CAMSHAFT) | 1   |
| 1302-60A          | BOLT (FOR IDLE GEAR THRUST PLATE)      | 1   |
| 1302-AA           | SCREW                                  | 2   |
| 1302-AB           | WASHER, SPRING                         | 2   |
| 1302-AC           | KEY                                    | 1   |
| 1302-AD           | BOLT, W/WASHER                         | 1   |
| 1302-AE           | COLLAR                                 | 1   |
| 1302-AF           | WASHER, PLATE                          | 2   |
| 1302-B1           |                                        | 8   |


(2J) ( 9)

G107

FIG. 1501  
OIL PUMP

1501

2J



| PART NAME<br>CODE | PART NAME                              | QTY |
|-------------------|----------------------------------------|-----|
| 1501-01           | PUMP ASSY, OIL                         | 1   |
| 1501-20           | STRAINER SUB-ASSY, OIL                 | 1   |
| 1501-23           | PIPE SUB-ASSY, INJECTION PUMP INLET    | 1   |
| 1501-23B          | GASKET (FOR INJECTION PUMP INLET PIPE) | 2   |
| 1501-41           | VALVE, OIL PUMP RELIEF                 | 1   |
| 1501-42           | GEAR, OIL PUMP DRIVE SHAFT             | 1   |
| 1501-43           | SHAFT, OIL PUMP                        | 1   |
| 1501-44           | GEAR, OIL PUMP DRIVE                   | 1   |
| 1501-45           | GEAR, OIL PUMP DRIVEN                  | 1   |
| 1501-46           | COVER, OIL PUMP                        | 1   |
| 1501-48           | GASKET, OIL STRAINER                   | 1   |
| 1501-49           | SPRING, OIL PUMP RELIEF VALVE          | 1   |
| 1501-AA           | PLUG, OIL PUMP RELIEF VALVE            | 1   |
| 1501-AE           | PIN, STRAIGHT                          | 1   |
| 1501-AF           | KEY, OIL PUMP DRIVEN SHAFT             | 1   |
| 1501-AG           | RING, SHAFT SNAP                       | 1   |
| 1501-AH           | UNION                                  | 1   |


(2J) ( 10)

G107

FIG. 1502  
OIL FILTER

1502

2J



1502-007

| PART NAME<br>CODE | PART NAME                    | QTY |
|-------------------|------------------------------|-----|
| 1502-20           | ELEMENT SUB-ASSY, OIL FILTER | 1   |
| 1502-21           | PIPE SUB-ASSY, OIL           | 1   |
| 1502-40           | BRACKET, OIL FILTER          | 1   |
| 1502-45           | GASKET, OIL FILTER           | 1   |
| 1502-AA           | UNION                        | 2   |


(23) ( 11)

G107

FIG. 1601  
WATER PUMP

1601

2J



| PART NAME<br>CODE | PART NAME                 | QTY |
|-------------------|---------------------------|-----|
| 1601-01           | PUMP ASSY, WATER          | 1   |
| 1601-10           | COVER ASSY, WATER PUMP    | 1   |
| 1601-30           | SEAL SET, WATER PUMP      | 1   |
| 1601-40           | COVER, WATER PUMP         | 1   |
| 1601-41           | ROTOR, WATER PUMP         | 1   |
| 1601-41A          | BEARING, WATER PUMP, NO.1 | 1   |
| 1601-43           | SEAT, WATER PUMP PULLEY   | 1   |
| 1601-44           | GASKET, WATER PUMP        | 1   |
| 1601-45           | GASKET, WATER PUMP COVER  | 1   |
| 1601-46           | PULLEY, FAN               | 1   |
| 1601-AA           | BOLT, STUD                | 6   |
| 1601-AB           | BODY SUB-ASSY, WATER PUMP | 1   |
| 1601-AC           | NUT                       | 6   |
| 1601-AD           | PLUG, W/HEAD TAPER SCREW  | 1   |

1601-012

(23) ( 12)

G107

1601


012

6101-001-0330

FIG. 1603  
RADIATOR & WATER OUTLET

1603

2J



1603 013


| PART NAME<br>CODE | PART NAME                            | QTY |
|-------------------|--------------------------------------|-----|
| 1603-01           | RADIATOR ASSY                        | 1   |
| 1603-01B          | PLUG, DRAIN COCK                     | 1   |
| 1603-01C          | PACKING (FOR RADIATOR DRAIN COCK)    | 1   |
| 1603-10           | TANK ASSY, RADIATOR RESERVE          | 1   |
| 1603-11           | SCREEN SUB-ASSY, RADIATOR            | 1   |
| 1603-30           | CAP SUB-ASSY, RADIATOR               | 1   |
| 1603-40           | HOUSING, WATER OUTLET                | 1   |
| 1603-41A          | BELT, V                              | 1   |
| 1603-42           | GASKET, WATER OUTLET HOUSING         | 1   |
| 1603-43           | OUTLET, WATER                        | 1   |
| 1603-43A          | THERMOSTAT                           | 1   |
| 1603-44           | GASKET, WATER OUTLET                 | 1   |
| 1603-45           | HOSE, WATER BY-PASS                  | 1   |
| 1603-45A          | CLAMP, HOSE (FOR WATER BY-PASS HOSE) | 2   |
| 1603-46           | HOSE, RADIATOR, INLET                | 1   |
| 1603-46A          | CLAMP, HOSE (FOR RADIATOR INLET)     | 2   |
| 1603-47           | HOSE, RADIATOR, OUTLET               | 1   |
| 1603-47A          | CLAMP, HOSE (FOR RADIATOR OUTLET)    | 1   |
| 1603-48           | SHROUD, FAN, NO.1                    | 1   |
| 1603-53           | PLATE, RUBBER (FOR RADIATOR)         | 4   |
| 1603-55           | BAR, FAN BELT ADJUSTING              | 1   |
| 1603-AA           | BRACKET, RESERVE TANK                | 1   |

(23) ( 13) G107

FIG. 1701  
MANIFOLD

1701

2 J



1701 001

| PART NAME<br>CODE | PART NAME                      | QTY |
|-------------------|--------------------------------|-----|
| 1701-40           | MANIFOLD, INTAKE               | 1   |
| 1701-41           | MANIFOLD, EXHAUST              | 1   |
| 1701-44           | GASKET, EXHAUST MANIFOLD, NO.1 | 2   |
| 1701-45           | GASKET, EXHAUST MANIFOLD, NO.2 | 1   |
| 1701-47           | GASKET, INTAKE MANIFOLD, NO.1  | 2   |
| 1701-AA           | BOLT, STUD                     | 4   |
| 1701-AB           | INSULATOR, EXHAUST             | 1   |
| 1701-AC           | BOLT, STAINLESS                | 3   |
| 1701-AD           | BOLT, STUD                     | 6   |
| 1701-AE           | NUT                            | 6   |
| 1701-AF           | BOLT, STUD                     | 2   |

(23) ( 14)

G107

1701

001


G107-001-0222

FIG. 1702  
EXHAUST PIPE & MUFFLER


1702

2J

2J (CATALYTIC)



1702-017A



1702-008A

1702

| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 1702-01           | MUFFLER ASSY -----                 | 1   |
| 1702-02           | MUFFLER ASSY, CATALYTIC -----      | 1   |
| 1702-20           | PIPE SUB-ASSY, EXHAUST, NO.1 ----- | 1   |
| 1702-40           | GASKET, EXHAUST PIPE -----         | 1   |
| 1702-41           | PELLET -----                       | 1   |
| 1702-AA           | NUT, HEXAGON -----                 | 2   |
| 1702-AB           | BRACKET, CLAMP -----               | 1   |
| 1702-AC           | BOLT, U -----                      | 1   |
| 1702-AM           | BOLT -----                         | 2   |
| 1702-AN           | CUSHION, RUBBER -----              | 4   |

(2) ) ( 15) G107

1703



2J (CYCLONE SINGLE)



FIG. 1703  
AIR CLEANER

1703

2J (CYCLONE DOUBLE)



| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 1703-01           | CLEANER ASSY, AIR                            | 1   |
| 1703-02           | CLEANER ASSY, CYCLONE AIR                    | 1   |
| 1703-20A          | ELEMENT SUB-ASSY, AIR CLEANER                | 1   |
| 1703-20B          | ELEMENT SUB-ASSY, CYCLONE AIR CLEANER        | 1   |
| 1703-20C          | ELEMENT SUB-ASSY, CYCLONE AIR CLEANER, INNER | 1   |
| 1703-200          | ELEMENT SUB-ASSY, CYCLONE AIR CLEANER, OUTER | 1   |
| 1703-23           | CASE SUB-ASSY, AIR CLEANER                   | 1   |
| 1703-24           | CAP SUB-ASSY, AIR CLEANER                    | 1   |
| 1703-41           | PIPE, AIR CLEANER                            | 1   |
| 1703-42           | CONNECTOR, AIR CLEANER                       | 1   |
| 1703-42A          | GASKLT, AIR CLEANER CONNECTOR                | 1   |
| 1703-44           | HOSE, AIR CLEANER, OUTLET NO.1               | 1   |
| 1703-44A          | CLAMP (FOR AIR CLEANER OUTLET NO.1 HOSE)     | 2   |
| 1703-47           | HOSE, AIR CLEANER, OUTLET NO.2               | 1   |
| 1703-47A          | CLAMP (FOR AIR CLEANER OUTLET NO.2 HOSE)     | 2   |
| 1703-AB           | PLATE, CAUTION                               | 1   |
| 1703-AC           | BAND SUB-ASSY                                | 1   |
| 1703-AD           | GUIDE, CLEANER BRACKET                       | 1   |
| 1703-AE           | LINK, CLEANER, RH                            | 1   |
| 1703-AF           | LINK, CLEANER, LH                            | 1   |
| 1703-AG           | PIN, W/HOLE                                  | 4   |
| 1703-AI           | BAFFLE, SCARF                                | 1   |
| 1703-AJ           | BOLT & GASKET ASSY                           | 1   |
| 1703-AK           | CLAMP ASSY                                   | 1   |
| 1703-AL           | INDICATOR                                    | 1   |
| 1703-BA           | SUPPORT, CLEANER LINK, LH                    | 1   |
| 1703-BB           | SUPPORT, CLEANER LINK, RH                    | 1   |


(23) ( 16)

G107

FIG. 1901  
IGNITION COIL & SPARK PLUG

1901

23



| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 1901-01           | BATTERY ASSY                       | 2   |
| 1901-10           | MAGNET ASSY, OVER INJECTION        | 1   |
| 1901-11           | PLUG ASSY, GLOW                    | 4   |
| 1901-31           | CABLE SUB-ASSY, BATTERY TO STARTER | 1   |
| 1901-32           | CABLE SUB-ASSY, BATTERY            | 1   |
| 1901-33           | CABLE SUB-ASSY, BATTERY TO BATTERY | 1   |
| 1901-43           | CAP, BATTERY, NO.1                 | 1   |
| 1901-45           | CONNECTOR, GLOW PLUG, NO.1         | 1   |
| 1901-49           | CABLE, BATTERY EARTH               | 1   |
| 1901-50           | STRAP, BOND                        | 1   |
| 1901-AA           | GROMMET, SCREW                     | 4   |
| 1901-AB           | BOLT                               | 2   |

(23) ( 17)


G107

FIG. 1903  
ALTERNATOR

1903

2J

2J (UL-OS)





1903-011

1903-010

FIG. 1903  
ALTERNATOR

1903

2J (H1-CAPACITY)




1903 013

| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 1903-01           | ALTERNATOR ASSY                          | 1   |
| 1903-02           | ROTOR ASSY, ALTERNATOR                   | 1   |
| 1903-02A          | BEARING (FOR ALTERNATOR ROTOR)           | 1   |
| 1903-03           | STATOR ASSY, ALTERNATOR                  | 1   |
| 1903-10           | HOLDER ASSY, ALTERNATOR BRUSH            | 1   |
| 1903-11           | FRAME ASSY, RECTIFIER END                | 1   |
| 1903-12           | FRAME ASSY, DRIVE END                    | 1   |
| 1903-12A          | BEARING (FOR ALTERNATOR DRIVE END FRAME) | 1   |
| 1903-12B          | FELT (FOR ALTERNATOR DRIVE END FRAME)    | 1   |
| 1903-15           | RECTIFIER ASSY, W/BRUSH                  | 1   |
| 1903-40           | PULLEY, ALTERNATOR                       | 1   |
| 1903-41           | FAN, ALTERNATOR                          | 1   |
| 1903-42           | COVER, REAR END                          | 1   |
| 1903-43           | BRUSH, ALTERNATOR                        | 2   |
| 1903-45           | HOLDER, W/RECTIFIER                      | 1   |
| 1903-46           | HOLDER, W/RECTIFIER POSITIVE             | 1   |
| 1903-47           | HOLDER, W/RECTIFIER NEGATIVE             | 1   |
| 1903-AA           | COLLAR, STEEL                            | 1   |
| 1903-AC           | RING, SNAP                               | 1   |
| 1903-AD           | COVER, FELT                              | 1   |
| 1903-AE           | PLATE, BEARING RETAINER                  | 1   |
| 1903-AF           | BUSHING                                  | 1   |

(2J) ( 18) 6107

1904

2J (UL-DS), 2J+4-ATM (OIL CLUTCH)



1904 571

# 1904

| PART NAME<br>CODE | PART NAME                                   | QTY |
|-------------------|---------------------------------------------|-----|
| 1904-01           | STARTER ASSY -----                          | 1   |
| 1904-01A          | GASKET (FOR STARTER HOUSING) -----          | 1   |
| 1904-02           | ARMATURE ASSY, STARTER -----                | 1   |
| 1904-02A          | BEARING, ARMATURE, NO.1 -----               | 1   |
| 1904-02B          | BEARING, ARMATURE, NO.2 -----               | 1   |
| 1904-03           | YDKE ASSY, STARTER -----                    | 1   |
| 1904-04           | HOUSING ASSY, STARTER DRIVE -----           | 1   |
| 1904-05           | FRAME ASSY, COMMUTATOR END -----            | 1   |
| 1904-06           | SWITCH ASSY, MAGNET -----                   | 1   |
| 1904-06B          | PACKING (FOR MAGNET SWITCH END COVER) ----- | 1   |
| 1904-10           | HOLDER ASSY, STARTER BRUSH -----            | 1   |
| 1904-20           | CLUTCH SUB-ASSY, STARTER -----              | 1   |
| 1904-20A          | RING, O (FOR STARTER CLUTCH) -----          | 1   |
| 1904-21           | PINION SUB-ASSY, STARTER -----              | 1   |
| 1904-22           | CHIP SUB-ASSY, CONTACT -----                | 1   |
| 1904-40           | BRUSH, STARTER -----                        | 2   |
| 1904-41           | WASHER, FELT, STARTER -----                 | 1   |
| 1904-42           | ROLLER, STARTER IDLE GEAR CLUTCH -----      | 6   |
| 1904-43           | RETAINER, STARTER IDLE GEAR -----           | 1   |
| 1904-44           | GEAR, STARTER IDLE -----                    | 1   |
| 1904-47           | SPRING, STARTER MAGNET SWITCH RETURN -----  | 1   |
| 1904-AA           | PLATE -----                                 | 1   |
| 1904-AC           | WASHER, IDLE GEAR CLUTCH -----              | 1   |
| 1904-AD           | WIRE, LEAD -----                            | 1   |
| 1904-AE           | BOLT -----                                  | 3   |
| 1904-AF           | RING, O -----                               | 2   |
| 1904-AG           | COVER, END FRAME -----                      | 1   |
| 1904-AH           | PLUNGER SUB-ASSY, CONTACTOR -----           | 1   |
| 1904-AW           | RING, O -----                               | 3   |

(2J ) ( 19)


G107

FIG. 2201  
INJECTION NOZZLE

2201

2J

2J (UL-D, UL-DS)



2201-001

2201-002

2201

| PART NAME<br>CODE | PART NAME                                        | QTY |
|-------------------|--------------------------------------------------|-----|
| 2201-01           | HOLDER & NOZZLE SET -----                        | 4   |
| 2201-10           | NOZZLE ASSY -----                                | 4   |
| 2201-11           | PIPE ASSY, NOZZLE LEAKAGE, NO.1 -----            | 1   |
| 2201-12           | PIPE ASSY, NOZZLE LEAKAGE, NO.2 -----            | 1   |
| 2201-20           | CHAMBER SUB-ASSY, COMBUSTION -----               | 4   |
| 2201-40           | SEAT, INJECTION NOZZLE -----                     | 4   |
| 2201-41           | GASKET, INJECTION NOZZLE SEAT -----              | 4   |
| 2201-42           | PIECE, DISTANCE (FOR NOZZLE) -----               | 4   |
| 2201-43           | HOSE, FUEL -----                                 | 1   |
| 2201-45           | WASHER (FOR NOZZLE HOLDER RING PACKING) -----    | 4   |
| 2201-46           | WASHER (FOR NOZZLE HOLDER PRESSURE SPRING) ----- | 4   |
| 2201-47           | SPRING, NOZZLE HOLDER PRESSURE -----             | 4   |
| 2201-48           | PIN, NOZZLE HOLDER PRESSURE -----                | 4   |
| 2201-AA           | SCREW, HOLLOW -----                              | 4   |
| 2201-AB           | WASHER -----                                     | 8   |
| 2201-AC           | NUT -----                                        | 4   |
| 2201-AD           | RING, PACKING, NO.1 -----                        | 4   |
| 2201-AI           | UNION, EYE -----                                 | 1   |
| 2201-AJ           | NUT, NOZZLE RETAINING -----                      | 1   |


(2J ) ( 20)

G107

FIG. 2202  
INJECTION PUMP ASSY

2202

2J



2202 00n

| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 2202-01           | PUMP ASSY, INJECTION                     | 1   |
| 2202-30           | PIPE SUB-ASSY, INJECTION, NO.1           | 1   |
| 2202-31           | PIPE SUB-ASSY, INJECTION, NO.2           | 1   |
| 2202-32           | PIPE SUB-ASSY, INJECTION, NO.3           | 1   |
| 2202-33           | PIPE SUB-ASSY, INJECTION, NO.4           | 1   |
| 2202-40           | GASKET, INJECTION PUMP                   | 1   |
| 2202-41           | HOSE OR PIPE, FUEL (PUMP TO FUEL FILTER) | 1   |
| 2202-AA           | CLAMP, INJECTION PIPE                    | 1   |
| 2202-AB           | CLAMP, INJECTION PIPE                    | 2   |
| 2202-AC           | CLAMP, FUEL PIPE, NO.1                   | 1   |
| 2202-AD           | CLAMP, FUEL PIPE, NO.2                   | 1   |

(23) ) ( 21)

G107

2202


029

6107-001-0344

FIG-2203  
INJECTION PUMP BODY

2203

2J




| PART NAME<br>CODE | PART NAME                                   | QTY |
|-------------------|---------------------------------------------|-----|
| 2203-20           | COVER SUB-ASSY, INJECTION PUMP              | 1   |
| 2203-21           | HOUSING SUB-ASSY, INJECTION PUMP            | 1   |
| 2203-30           | VALVE SUB-ASSY, DELIVERY                    | 4   |
| 2203-31           | ELEMENT SUB-ASSY, INJECTION PUMP            | 4   |
| 2203-32           | TAPPET SUB-ASSY                             | 4   |
| 2203-41           | HOLDER, DELIVERY VALVE                      | 4   |
| 2203-42           | FLANGE, INJECTION                           | 1   |
| 2203-43           | CAMSHAFT, INJECTION PUMP                    | 1   |
| 2203-43A          | BEARING, NO.1 (FOR INJECTION PUMP CAMSHAFT) | 2   |
| 2203-44           | RACK, CONTROL                               | 1   |
| 2203-45           | GASKET, DELIVERY VALVE                      | 4   |
| 2203-46           | SPRING, DELIVERY VALVE                      | 4   |
| 2203-47           | PLATE, CAMSHAFT SHIM                        | 99  |
| 2203-48           | PINION, PLUNGER CONTROL                     | 4   |
| 2203-49           | SPRING, PUMP PLUNGER                        | 4   |
| 2203-50           | GASKET, BEARING COVER                       | 1   |
| 2203-51           | SHAFT, SPLINE                               | 1   |
| 2203-52           | SCREW, PLUNGER CONTROL PINION CLAMP         | 4   |
| 2203-53           | PACKING, AIR BLEEDER SCREW                  | 1   |
| 2203-AA           | PLATE SET, VALVE HOLDER LOCK                | 1   |
| 2203-AC           | SLEEVE, PLUNGER CONTROL                     | 4   |
| 2203-AD           | SEAT, SPRING UPPER                          | 4   |
| 2203-AE           | SEAT, SPRING LOWER                          | 4   |
| 2203-AF           | PLATE, TAPPET ADJUSTING SHIM                | 99  |
| 2203-AG           | SCREW, AIR BLEEDER                          | 1   |
| 2203-AI           | NIPPLE, AIR BLEEDER                         | 1   |
| 2203-AJ           | WASHER, AIR BLEEDER NIPPLE                  | 1   |
| 2203-AK           | SCREW, RACK GUIDE                           | 1   |
| 2203-AL           | COVER, CONTROL RACK                         | 1   |
| 2203-AM           | RING, CAMSHAFT ADJUST                       | 2   |
| 2203-AN           | PLUG, FELT PLATE                            | 4   |
| 2203-AO           | KEY                                         | 1   |
| 2203-AP           | WASHER, SPRING                              | 1   |
| 2203-AQ           | NUT, TIMER ROUND                            | 1   |
| 2203-AR           | STAY, INJECTION PUMP BODY                   | 1   |

(2J) ( 22) G107

FIG. 2204  
PNEUMATIC GOVERNOR

2204

2J



| PART NAME<br>CODE | PART NAME                            | QTY |
|-------------------|--------------------------------------|-----|
| 2204-01           | GOVERNOR ASSY, INJECTION PUMP        | 1   |
| 2204-11A          | SEAL, OIL (FOR GOVERNOR HOUSING)     | 1   |
| 2204-30           | DIAPHRAGM SUB-ASSY                   | 1   |
| 2204-31           | LEVER SUB-ASSY, INJECTION PUMP, NO.1 | 1   |
| 2204-32           | LEVER SUB-ASSY, INJECTION PUMP, NO.2 | 1   |
| 2204-33           | LEVER SUB-ASSY, INJECTION PUMP, NO.3 | 1   |
| 2204-41           | LEVER, STOP                          | 1   |
| 2204-42           | HOUSING, LEVER                       | 1   |
| 2204-43           | GASKET, GOVERNOR CAP                 | 1   |
| 2204-AA           | CAM                                  | 1   |
| 2204-AB           | SHAFT                                | 1   |
| 2204-AC           | SCREW                                | 1   |
| 2204-AD           | CAPSULE ASSY, IDLE                   | 1   |
| 2204-AE           | RING, SHAFT SNAP                     | 1   |
| 2204-AF           | SPRING, RETURN                       | 1   |
| 2204-AG           | RING, O                              | 2   |
| 2204-AH           | WASHER                               | 99  |
| 2204-AI           | SPRING, GOVERNOR IDLING              | 1   |
| 2204-AJ           | SCREW                                | 2   |
| 2204-AK           | WASHER, ADJUST                       | 99  |
| 2204-AL           | ROD, PUSH                            | 1   |
| 2204-AM           | WASHER, ADJUST                       | 99  |
| 2204-AN           | SHIM, MAIN SPRING                    | 99  |
| 2204-AO           | SPRING, GOVERNOR MAIN                | 1   |
| 2204-AP           | BOLT, CONNECTING                     | 1   |
| 2204-AQ           | SCREW                                | 1   |
| 2204-AR           | WASHER                               | 99  |
| 2204-AS           | BUSHING                              | 1   |
| 2204-AT           | SPRING, BACK                         | 1   |
| 2204-AU           | NUT                                  | 1   |
| 2204-AV           | BRACKET SUB-ASSY, STOP WIRE          | 1   |
| 2204-AW           | PIN, LEVER                           | 1   |
| 2204-AX           | SPRING, RETURN                       | 1   |
| 2204-AY           | CAPSULE, SPRING                      | 1   |
| 2204-AZ           | COVER, CAMSHAFT                      | 1   |
| 2204-BA           | WASHER                               | 1   |



(23) ( 23)

G107

FIG. 2206  
FUEL FEED PUMP

2206

2J



2206 004


| PART NAME<br>CODE | PART NAME                                 | QTY |
|-------------------|-------------------------------------------|-----|
| 2206-01           | PUMP ASSY, FUEL FEED                      | 1   |
| 2206-01A          | RING, O (FOR FUEL FEED PUMP)              | 1   |
| 2206-41           | VALVE, FEED PUMP CHECK                    | 2   |
| 2206-41A          | SPRING, FEED PUMP CHECK VALVE             | 2   |
| 2206-42           | GASKET, CHECK VALVE CHAMBER PLUG          | 2   |
| 2206-43           | FILTER, FUEL PUMP                         | 1   |
| 2206-44           | TAPPET, FEED PUMP                         | 1   |
| 2206-45           | PISTON, FEED PUMP                         | 1   |
| 2206-46           | SPRING, FEED PUMP PISTON                  | 1   |
| 2206-47           | ROLLER, FEED PUMP TAPPET                  | 1   |
| 2206-48           | GASKET, FEED PUMP PISTON PLUG             | 1   |
| 2206-49           | SCREW, FUEL PIPE HOLLOW                   | 1   |
| 2206-49A          | WASHER, SEAL (FOR FUEL PIPE HOLLOW SCREW) | 4   |
| 2206-50           | PLUG, FEED PUMP PISTON CHAMBER            | 1   |
| 2206-AA           | PLUG, FEED PUMP CHECK VALVE               | 2   |
| 2206-AB           | RING, FEED PUMP TAPPET                    | 1   |
| 2206-AC           | PIN, FEED PUMP TAPPET ROLLER              | 1   |
| 2206-AD           | BLOCK, FEED PUMP TAPPET SLIDING           | 2   |

(23) ( 24) 6107

FIG. 2207  
AUTOMATIC TIMER

2207

2J



| PART NAME<br>CODE | PART NAME               | QTY |
|-------------------|-------------------------|-----|
| 2207-01           | TIMER ASSY, AUTOMATIC   | 1   |
| 2207-43           | WEIGHT, TIMER           | 2   |
| 2207-44           | HUB, TIMER              | 1   |
| 2207-44A          | BEARING (FOR TIMER HUB) | 1   |
| 2207-45           | GEAR, DRIVE             | 1   |
| 2207-46           | SPRING, TIMER           | 2   |
| 2207-47           | SPRING, TIMER SUB       | 2   |
| 2207-AA           | RING, CLAMP             | 1   |
| 2207-AB           | SEAT, SPRING            | 4   |

2207 001

(23) ( 25)

G107

2207


001

6107-001-5348

FIG. 2302  
FUEL FILTER

2302

2J



2302 004 A

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 2302-01           | FILTER ASSY, FUEL (ELEMENT SERVICE TYPE) --- | 1   |
| 2302-01C          | GASKET, NIPPLE UNION (FOR FUEL FILTER) ----- | 4   |
| 2302-10           | PUMP ASSY, PRIMING -----                     | 1   |
| 2302-10A          | GASKET (FOR PRIMING PUMP) -----              | 1   |
| 2302-11           | VALVE ASSY -----                             | 1   |
| 2302-20           | ELEMENT SUB-ASSY, FUEL FILTER -----          | 1   |
| 2302-21           | BODY SUB-ASSY, FUEL FILTER, UPPER -----      | 1   |
| 2302-40           | GASKET, FILTER BOWL -----                    | 1   |
| 2302-AD           | UNION -----                                  | 2   |
| 2302-AE           | SUPPORT, FUEL FILTER -----                   | 1   |
| 2302-AF           | PLUG, BLEEDER -----                          | 1   |
| 2302-AM           | SPRING, SET -----                            | 1   |
| 2302-AN           | BOLT, JOINT -----                            | 1   |
| 2302-AO           | WASHER, PLATE -----                          | 1   |
| 2302-AP           | CAP, BLEEDER PLUG -----                      | 1   |

(23) ( 26) G107

2302

004 A



6107-001-0340

FIG. 2303  
FUEL TANK & FUEL PIPE

2303

2J

(UL-D, UL-D5)



2303-004

| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 2303-10           | CAP ASSY, FUEL TANK                | 1   |
| 2303-11           | VALVE ASSY, SHUT-OFF               | 1   |
| 2303-11A          | CONNECTOR (FOR SHUT-OFF VALVE)     | 2   |
| 2303-20A          | PLUG, DRAIN (FOR FUEL TANK)        | 1   |
| 2303-20B          | GASKET, DRAIN PLUG (FOR FUEL TANK) | 1   |
| 2303-21           | COVER SUB-ASSY, FUEL TANK          | 1   |
| 2303-21A          | PACKING, FUEL TANK COVER           | 1   |
| 2303-23           | PIPE SUB-ASSY, FUEL, NO.1          | 1   |
| 2303-24           | PIPE SUB-ASSY, FUEL, NO.2          | 1   |
| 2303-25           | PIPE SUB-ASSY, FUEL, NO.3          | 1   |
| 2303-30           | TANK SUB-ASSY, SUB                 | 1   |
| 2303-42           | VALVE, BREATHER                    | 1   |
| 2303-45           | HOSE, FUEL, NO.1                   | 1   |
| 2303-52           | ELBOW (FOR NOZZLE LEAKAGE PIPE)    | 1   |
| 2303-AA           | BOLT                               | 4   |
| 2303-AB           | PLATE, SEPARATE                    | 1   |
| 2303-AC           | ELBOW                              | 1   |
| 2303-AE           | BOLT, FLANGE                       | 1   |
| 2303-AF           | GASKET                             | 2   |
| 2303-AG           | GASKET                             | 2   |
| 2303-AI           | UNION                              | 1   |


(23) ( 27)

G107

FIG. 2601  
ACCELERATOR LINK

2601

2J




| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 2601-10           | WIRE ASSY, ACCELERATOR FLEXIBLE          | 1   |
| 2601-12           | BUTTON ASSY, ENGINE STOP                 | 1   |
| 2601-20           | PEDAL SUB-ASSY, ACCELERATOR              | 1   |
| 2601-20A          | BUSH (FOR ACCELERATOR PEDAL)             | 2   |
| 2601-30           | ARM SUB-ASSY, ACCELERATOR LINK, NO.1     | 1   |
| 2601-30A          | BUSH (FOR ACCELERATOR LINK ARM)          | 2   |
| 2601-31           | BRACKET SUB-ASSY, ACCELERATOR WIRE, NO.1 | 1   |
| 2601-33           | BRACKET SUB-ASSY, ACCELERATOR ARM, NO.1  | 1   |
| 2601-40           | SPRING, TENSION                          | 1   |
| 2601-41           | SPRING, TORSION, NO.1                    | 1   |
| 2601-42           | ROD, ACCELERATOR PEDAL                   | 1   |
| 2601-43           | PAO, PEDAL                               | 1   |
| 2601-47           | END, CONNECTING ROD, NO.1                | 2   |
| 2601-51           | BRACKET, PEDAL                           | 1   |
| 2601-AB           | PIN, W/HOLE                              | 1   |
| 2601-AC           | PIN                                      | 1   |
| 2601-AD           | CLAMP                                    | 1   |
| 2601-AE           | BRACKET, RETURN SPRING                   | 1   |
| 2601-AF           | CLAMP                                    | 1   |
| 2601-AH           | STOPPER                                  | 1   |

( 2 ) ( 28 ) G107

FIG. 2606  
VENTURI

2606

2J



| PART NAME<br>CODE | PART NAME                         | QTY |
|-------------------|-----------------------------------|-----|
| 2606-01           | VENTURI ASSY                      | 1   |
| 2606-01A          | GASKET, VENTURI                   | 1   |
| 2606-10           | ROD ASSY, GOVERNOR CONNECTING     | 1   |
| 2606-20           | ROD SUB-ASSY, GOVERNOR CONNECTING | 1   |
| 2606-21           | LEVER SUB-ASSY, THROTTLE ADJUST   | 1   |
| 2606-40           | END, GOVERNOR CONNECTING          | 1   |
| 2606-42           | WASHER, VENTURI HOSE UNION        | 4   |
| 2606-43           | HOSE, VACUUM                      | 1   |
| 2606-44           | HOSE, AIR CLEANER VENT            | 1   |
| 2606-45           | SHAFT, THROTTLE VALVE             | 1   |
| 2606-46           | VALVE, VENTURI THROTTLE           | 1   |
| 2606-AA           | SCREW, HOLLOW                     | 2   |
| 2606-AB           | UNION                             | 2   |
| 2606-AC           | CONNECTOR                         | 1   |
| 2606-AD           | SCREW, LEVER STOP                 | 2   |
| 2606-AE           | WIRE                              | 1   |
| 2606-AF           | SEAL, ROD                         | 1   |
| 2606-AG           | WASHER                            | 99  |
| 2606-AH           | RING, SNAP                        | 1   |

(23) ) ( 29)

6107

2606

001

2606 001

6107-001-0252

**MEMO**

Silverhorn.co.uk

**MEMO**

Silverhorn.co.uk

**MEMO**









Silverhorn.co.uk

FIG. 3201  
TORQUE CONVERTER HOUSING

3201

ATM

01K---(INCL. ■)  
03K---(INCL. ⊗)



3201-014A

3201

|    |        |
|----|--------|
| 第1 | 4P     |
| 第2 | 5H     |
| 第3 | 2J, 5P |



**3201**

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 3201-00           | TRANSMISSION ASSY, AUTOMATIC, W/DIFFERENTIAL | 1   |
| 3201-01K          | TRANSMISSION O/H KIT, AUTOMATIC              | 1   |
| 3201-03K          | TRANSMISSION O/H KIT (FOR TORQUECONVERTER)   | 1   |
| 3201-20           | CASE SUB-ASSY, TORQUECONVERTER, NO.1         | 1   |
| 3201-22           | CASE SUB-ASSY, TRANSMISSION                  | 1   |
| 3201-30           | GAGE SUB-ASSY, OIL LEVEL                     | 1   |
| 3201-42           | PLATE, TORQUECONVERTER END                   | 1   |
| 3201-45B          | PLUG, DRAIN                                  | 1   |
| 3201-45C          | GASKET (FOR DRAIN PLUG)                      | 1   |
| 3201-AA           | COVER, COOLING AIR                           | 1   |
| 3201-AB           | RING, O                                      | 1   |
| 3201-AC           | HANGER                                       | 2   |
| 3201-AD           | PLUG                                         | 1   |
| 3201-AE           | PLUG, W/HEAD STRAIGHT SCREW                  | 1   |
| 3201-AF           | GASKET                                       | 1   |
| 3201-AG           | RING, O                                      | 1   |
| 3201-AH           | PLUG, TAPER SCREW                            | 1   |
| 3201-AI           | PIN, STRAIGHT                                | 2   |
| 3201-AJ           | BOLT, STUD                                   | 10  |
| 3201-AM           | BOLT, STUD                                   | 1   |
| 3201-AN           | PLATE, LOCK                                  | 1   |
| 3201-AO           | MAGNET                                       | 1   |
| 3201-AP           | RING, O                                      | 1   |
| 3201-AQ           | RING, O                                      | 1   |
| 3201-AR           | PIN, STRAIGHT                                | 2   |
| 3201-AS           | PLATE, COVER                                 | 1   |


(ATM ) ( 1)

G107

FIG. 3202  
TORQUE CONVERTER

3202

ATH



3202 002A

# 3202


| PART NAME<br>CODE | PART NAME                                           | QTY |
|-------------------|-----------------------------------------------------|-----|
| 3202-01           | TORQUECONVERTER ASSY -----                          | 1   |
| 3202-01K          | TORQUECONVERTER O/H KIT -----                       | 1   |
| 3202-12           | STATOR ASSY -----                                   | 1   |
| 3202-14           | IMPELLER ASSY, PUMP -----                           | 1   |
| 3202-15           | ROLLER SET (FOR STATOR) -----                       | 1   |
| 3202-20           | GEAR SUB-ASSY, DRIVE PLATE & RING -----             | 1   |
| 3202-21           | RUNNER SUB-ASSY, TURBINE -----                      | 1   |
| 3202-22           | SHAFT SUB-ASSY, STATOR -----                        | 1   |
| 3202-22A          | PACKING (FOR STATOR SHAFT) -----                    | 1   |
| 3202-23           | GEAR SUB-ASSY, OIL PUMP DRIVE -----                 | 1   |
| 3202-24           | GEAR SUB-ASSY, OIL PUMP DRIVEN -----                | 1   |
| 3202-25           | IMPELLER SUB-ASSY, PUMP -----                       | 1   |
| 3202-25A          | RING, O (FOR PUMP IMPELLER) -----                   | 1   |
| 3202-28           | COVER SUB-ASSY, DRIVE (DISC SUB-ASSY) -----         | 1   |
| 3202-28A          | BEARING (FOR DRIVE COVER) -----                     | 1   |
| 3202-30           | CASE SUB-ASSY, OIL PUMP -----                       | 1   |
| 3202-30A          | RING, O (FOR OIL PUMP CASE) -----                   | 1   |
| 3202-31           | EXTENSION SUB-ASSY, PUMP IMPELLER (BOSS) -----      | 1   |
| 3202-31A          | BEARING, PUMP IMPELLER EXTENSION -----              | 1   |
| 3202-31B          | RING, O (FOR PUMP IMPELLER EXTENSION) -----         | 1   |
| 3202-31C          | RING, SEAL (FOR PUMP IMPELLER EXTENSION) -----      | 1   |
| 3202-41           | PIECE, CENTER (BOSS, PILOT) -----                   | 1   |
| 3202-43           | SHAFT, TURBINE (SHAFT, INPUT) -----                 | 1   |
| 3202-43A          | BEARING, TURBINE SHAFT -----                        | 1   |
| 3202-43B          | RING, SEAL (FOR TURBINE SHAFT) -----                | 2   |
| 3202-43C          | RING, SHAFT SNAP (FOR TURBINE SHAFT BEARING) -----  | 1   |
| 3202-43E          | RING, HOLE SNAP (FOR TURBINE SHAFT BEARING) -----   | 1   |
| 3202-45           | HUB, TURBINE RUNNER (FACE, INNER) -----             | 1   |
| 3202-45B          | WASHER, THRUST, NO.1 (FOR TURBINE RUNNER HUB) ----- | 2   |
| 3202-45G          | COLLAR (FOR TURBINE RUNNER HUB) -----               | 1   |
| 3202-53           | SPRING (FOR STATOR) -----                           | 8   |
| 3202-54           | CAP, SPRING (FOR STATOR) -----                      | 8   |
| 3202-AA           | RING, O -----                                       | 1   |
| 3202-AB           | RING, SHAFT SNAP -----                              | 1   |
| 3202-AC           | WASHER, TURBINE, FRONT -----                        | 1   |
| 3202-AD           | NUT -----                                           | 20  |
| 3202-AH           | BOLT -----                                          | 20  |
| 3202-A1           | RING, HOLE SNAP -----                               | 1   |
| 3202-A3           | RING, HOLE -----                                    | 2   |
| 3202-AL           | BOLT -----                                          | 6   |
| 3202-AM           | SEAL, TYPE O OIL -----                              | 1   |
| 3202-AQ           | PLATE, THRUST -----                                 | 2   |
| 3202-AR           | BOLT -----                                          | 6   |
| 3202-AS           | SPACER, DRIVE PLATE -----                           | 1   |
| 3202-AT           | SUPPORT, CENTERING -----                            | 1   |

(ATM ) ( 2) G107

FIG. 3203  
TORQUE CONVERTER CLUTCH

3203

ATH



3203-002C

**3203**

| PART NAME<br>CODE | PART NAME                                         | QTY |
|-------------------|---------------------------------------------------|-----|
| 3203-10           | DRUM ASSY, CLUTCH, NO.1 -----                     | 1   |
| 3203-20           | DRUM SUB-ASSY, CLUTCH, NO.1 -----                 | 1   |
| 3203-22           | PISTON SUB-ASSY, CLUTCH, NO.1 -----               | 2   |
| 3203-22A          | RING, PISTON (FOR CLUTCH PISTON) -----            | 2   |
| 3203-24           | SHAFT SUB-ASSY, CLUTCH, NO.1 -----                | 1   |
| 3203-24A          | RING, SEAL (FOR CLUTCH SHAFT) -----               | 3   |
| 3203-24D          | BEARING, NO.1 (FOR NO.1 CLUTCH SHAFT) -----       | 1   |
| 3203-40           | DISC, CLUTCH -----                                | 10  |
| 3203-41           | PLATE, CLUTCH -----                               | 10  |
| 3203-42A          | RING, HOLE SNAP (FOR CLUTCH PRESSURE PLATE) ----- | 2   |
| 3203-43           | SPRING, CLUTCH RETURN -----                       | 2   |
| 3203-44           | COLLAR, SERVO -----                               | 1   |
| 3203-45           | GEAR, CLUTCH (FORWARD) -----                      | 1   |
| 3203-45B          | COLLER (FOR FORWARD CLUTCH GEAR) -----            | 1   |
| 3203-45C          | WASHER, THRUST (FOR FORWARD CLUTCH GEAR) -----    | 1   |
| 3203-46           | GEAR, CLUTCH (REVERSE) -----                      | 1   |
| 3203-46C          | WASHER, THRUST, NO.1 (FOR REVERSE GEAR) -----     | 1   |
| 3203-46D          | WASHER, THRUST, NO.2 (FOR REVERSE GEAR) -----     | 1   |
| 3203-50           | PLATE, CLUTCH CAMBER -----                        | 2   |
| 3203-51           | PLATE, CLUTCH BACKING -----                       | 2   |
| 3203-AC           | RING, SHAFT SNAP -----                            | 2   |
| 3203-AD           | BALL -----                                        | 2   |
| 3203-AE           | PLUG, STRAIGHT -----                              | 2   |
| 3203-AG           | WASHER, WAVE -----                                | 1   |
| 3203-AH           | RING, SHAFT SNAP -----                            | 1   |
| 3203-AJ           | RETAINER, SPRING -----                            | 2   |
| 3203-AM           | CAP, MAIN SHAFT -----                             | 1   |
| 3203-AN           | RING, O -----                                     | 1   |
| 3203-AO           | RING, HOLE SNAP -----                             | 1   |
| 3203-AZ           | GEAR SET, FORWARD -----                           | 1   |

(ATM


) ( 3)

G107

FIG. 3204  
TORQUE CONVERTER GEAR

3204

ATM



3204-002

| PART NAME<br>CODE | PART NAME               | QTY |
|-------------------|-------------------------|-----|
| 3204-43           | SHAFT, IDLE             | 1   |
| 3204-44           | GEAR, IDLE, NO.1        | 1   |
| 3204-44A          | BEARING (FOR IDLE GEAR) | 2   |
| 3204-46           | GEAR, OUTPUT, NO.1      | 1   |
| 3204-AA           | LOCK, SHAFT             | 1   |
| 3204-AB           | WASHER                  | 2   |
| 3204-AC           | SPACER, IDLER SHAFT     | 1   |

(ATM) ( 4 ) G107


FIG. 3206  
CONTROL VALVE

3206



ATM

ATM

01K -- (INCL. ●)



3206 009



3206 010A

# 3206

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 3206-01           | COVER & VALVE ASSY, TRANSMISSION -----       | 1   |
| 3206-01K          | COVER O/H KIT, TRANSMISSION -----            | 1   |
| 3206-10           | COVER ASSY, CONTROL VALVE SMALL UPPER -----  | 1   |
| 3206-11           | VALVE ASSY, CONTROL, W/REGULATOR VALVE ----- | 1   |
| 3206-20           | COVER SUB-ASSY, UPPER -----                  | 1   |
| 3206-20A          | PLUG, BREATHER -----                         | 1   |
| 3206-20B          | GASKET (FOR BREATHER PLUG) -----             | 1   |
| 3206-30           | BODY SUB-ASSY, ORIFICE VALVE -----           | 1   |
| 3206-40           | PACKING, TRANSMISSION COVER -----            | 1   |
| 3206-41           | PACKING, CONTROL VALVE BODY -----            | 2   |
| 3206-44           | VALVE, INCHING -----                         | 1   |
| 3206-45           | VALVE, SELECTOR -----                        | 1   |
| 3206-46           | VALVE, CHANGE -----                          | 1   |
| 3206-47           | VALVE, MODULATOR -----                       | 1   |
| 3206-48           | PISTON, MODULATOR -----                      | 1   |
| 3206-49           | VALVE, ORIFICE -----                         | 1   |
| 3206-50           | VALVE, REGULATOR -----                       | 1   |
| 3206-AA           | LEVER, SHIFT -----                           | 1   |
| 3206-AB           | WASHER, PLATE -----                          | 2   |
| 3206-AC           | PIN, LEVER LOCK -----                        | 2   |
| 3206-AD           | SEAL, OIL -----                              | 2   |
| 3206-AE           | BUSHING -----                                | 2   |
| 3206-AF           | LEVER, INCHING -----                         | 1   |
| 3206-AG           | PLUG -----                                   | 2   |
| 3206-AH           | JOINT -----                                  | 1   |
| 3206-AI           | GASKET -----                                 | 1   |
| 3206-AJ           | PLUG, STRAIGHT -----                         | 2   |
| 3206-AK           | WASHER, PLATE -----                          | 2   |
| 3206-AL           | LEVER SUB-ASSY, INCHING CAM -----            | 1   |
| 3206-AM           | PLATE, ADJUST SHIFT -----                    | 2   |
| 3206-AN           | LEVER SUB-ASSY, SHIFT CAM -----              | 1   |
| 3206-AO           | PLUG, STRAIGHT -----                         | 2   |
| 3206-AP           | STOPPER, CHANGE VALVE -----                  | 1   |
| 3206-AQ           | PIN, SPRING -----                            | 2   |
| 3206-AS           | SPRING, MODULATOR OUTER -----                | 1   |
| 3206-AT           | RING, SNAP -----                             | 1   |
| 3206-AU           | SPRING, ORIFICE VALVE -----                  | 1   |
| 3206-AV           | SPRING, REGULATOR VALVE -----                | 1   |
| 3206-AW           | SPRING, INCHING VALVE -----                  | 1   |
| 3206-AX           | BALL, STEEL -----                            | 1   |
| 3206-AY           | SPRING -----                                 | 1   |
| 3206-AZ           | PLATE, HOLDER SPRING -----                   | 1   |
| 3206-BA           | PLATE, OIL SEPARATOR -----                   | 1   |
| 3206-BB           | BODY, CONTROL VALVE -----                    | 1   |

(ATM


) ( 5)

G107

FIG. 3213  
TORQUE CONVERTER PIPING

3213

ATM



| PART NAME<br>CODE | PART NAME                                 | QTY |
|-------------------|-------------------------------------------|-----|
| 3213-10           | FILTER ASSY, OIL                          | 1   |
| 3213-30           | STRAINER SUB-ASSY, OIL (SCREEN)           | 1   |
| 3213-35           | PIPE SUB-ASSY, CASE TO CASE               | 1   |
| 3213-41           | HOSE, LOW PRESSURE, NO.1 (FOR OIL COOLER) | 1   |
| 3213-41A          | CLAMP, NO.1 (FOR OIL COOLER HOSE)         | 2   |
| 3213-41B          | CLAMP, NO.2 (FOR OIL COOLER HOSE)         | 2   |
| 3213-42           | HOSE, LOW PRESSURE, NO.2 (FOR OIL COOLER) | 1   |
| 3213-AC           | ELBOW                                     | 2   |
| 3213-AO           | UNION                                     | 2   |
| 3213-AJ           | PACKING                                   | 4   |
| 3213-AK           | UNION                                     | 2   |
| 3213-AL           | BOLT, UNION                               | 2   |



(ATM) ( 6) G107

FIG. 3214  
CONTROL SHAFT

3214

ATM (LH LEVER)

ATM (RH LEVER)



3214 004

3214 002

3214

002

004

G107-001-0452

3214

| PART NAME<br>CODE | PART NAME                                 | QTY |
|-------------------|-------------------------------------------|-----|
| 3214-10           | END ASSY, CONNECTING ROD, NO.1 -----      | 1   |
| 3214-11           | END ASSY, CONNECTING ROD, NO.2 -----      | 1   |
| 3214-20           | SHAFT SUB-ASSY, CONTROL -----             | 1   |
| 3214-21           | LINK SUB-ASSY, CONTROL SHAFT -----        | 1   |
| 3214-30           | PIN SUB-ASSY, LINK -----                  | 1   |
| 3214-40           | LEVER, CONTROL -----                      | 1   |
| 3214-41           | ROD, FORWARD & REVERSE CHANGE, NO.1 ----- | 1   |
| 3214-42           | KNOB, SHIFT LEVER -----                   | 1   |
| 3214-44           | ROD, FORWARD & REVERSE CHANGE, NO.2 ----- | 1   |
| 3214-AA           | PIN, SPRING -----                         | 1   |
| 3214-AB           | BUSHING, SOLID -----                      | 2   |
| 3214-AD           | NUT -----                                 | 1   |
| 3214-AE           | PLATE, CHANGE LEVER CENTER -----          | 1   |
| 3214-AF           | BUSHING, SOLID -----                      | 1   |
| 3214-AG           | BRACKET, CHANGE LEVER -----               | 1   |

(ATM


) ( 7)

G107

FIG. 4101  
DIFFERENTIAL

4101

ATM



4101-005A

# 4101



| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 4101-02           | CASE ASSY, DIFFERENTIAL -----                | 1   |
| 4101-10           | RING GEAR & PINION SET, DIFFERENTIAL -----   | 1   |
| 4101-10A          | BEARING, DRIVE PINION -----                  | 2   |
| 4101-10B          | BEARING, DRIVE PINION PILOT -----            | 1   |
| 4101-10C          | NUT, LOCK -----                              | 1   |
| 4101-10D          | SHIM, BEARING PRELOAD ADJUST -----           | 99  |
| 4101-20           | CASE SUB-ASSY, DIFFERENTIAL -----            | 1   |
| 4101-20A          | NUT, ADJUSTING -----                         | 2   |
| 4101-20B          | BEARING, DIFFERENTIAL CASE -----             | 2   |
| 4101-40           | HOUSING, DIFFERENTIAL -----                  | 1   |
| 4101-40B          | RING, O (FOR DIFFERENTIAL HOUSING) -----     | 1   |
| 4101-40C          | PLUG, BREATHER (FOR DIFFERENTIAL HOUSING) -- | 1   |
| 4101-44           | PLUG (FOR INPUT SHAFT) -----                 | 1   |
| 4101-44A          | PACKING (FOR INPUT SHAFT PLUG) -----         | 1   |
| 4101-46           | GEAR, SIDE -----                             | 2   |
| 4101-46A          | WASHER, SIDE GEAR THRUST -----               | 2   |
| 4101-47           | SPIDER -----                                 | 1   |
| 4101-48           | PINION -----                                 | 4   |
| 4101-48A          | WASHER, PINION THRUST -----                  | 4   |
| 4101-49           | PLUG, DRAIN -----                            | 1   |
| 4101-49A          | GASKET, DRAIN PLUG -----                     | 1   |
| 4101-50           | RETAINER, DRIVE PINION BEARING -----         | 1   |
| 4101-50B          | RING, O (FOR BEARING RETAINER) -----         | 1   |
| 4101-50C          | SEAL, OIL (FOR BEARING RETAINER) -----       | 1   |
| 4101-50D          | SHIM, DIFFERENTIAL DRIVE PINION BEARING ---- | 99  |
| 4101-54           | CAP, RING GEAR THRUST SCREW -----            | 1   |
| 4101-55           | BDLT, RING GEAR SET -----                    | 12  |
| 4101-AA           | PLATE, BOLT LOCK -----                       | 2   |
| 4101-AB           | BOLT -----                                   | 12  |
| 4101-AC           | SCREW, RING GEAR THRUST -----                | 1   |
| 4101-AD           | NUT -----                                    | 1   |
| 4101-AF           | LOCK, ADJUSTING -----                        | 2   |
| 4101-AI           | PLUG -----                                   | 1   |
| 4101-AJ           | GASKET -----                                 | 1   |
| 4101-AK           | BOLT -----                                   | 2   |
| 4101-AL           | BOLT -----                                   | 4   |
| 4101-AN           | RING, O -----                                | 1   |
| 4101-AO           | SPACER, BEARING -----                        | 1   |

(ATM ) ( 8) G107

FIG. 4201  
FRONT AXLE SHAFT

4201

ATH



4201-006

| PART NAME<br>CODE | PART NAME                             | QTY |
|-------------------|---------------------------------------|-----|
| 4201-40           | SHAFT, FRONT AXLE                     | 2   |
| 4201-40A          | WASHER, CORN                          | 16  |
| 4201-40B          | WASHER, SPRING (FOR FRONT AXLE SHAFT) | 16  |
| 4201-40C          | SEAL, OIL (FOR FRONT AXLE SHAFT)      | 2   |
| 4201-40D          | GASKET, FRONT AXLE SHAFT              | 2   |
| 4201-41           | HUB, FRONT AXLE                       | 2   |
| 4201-41A          | SEAL, OIL (FOR FRONT AXLE HUB)        | 2   |
| 4201-41B          | BEARING, NO.1 (FOR FRONT AXLE HUB)    | 2   |
| 4201-41D          | NUT, BEARING LOCK                     | 2   |
| 4201-41E          | BOLT, HUB                             | 12  |
| 4201-41F          | BOLT, STUD (FOR FRONT AXLE SHAFT)     | 16  |
| 4201-41G          | NUT, HUB                              | 12  |
| 4201-42           | DRUM, BRAKE                           | 2   |
| 4201-43           | BRACKET, FRONT AXLE, RH               | 1   |
| 4201-43A          | NUT, BRAKE SET SELF                   | 16  |
| 4201-44           | BRACKET, FRONT AXLE, LH               | 1   |
| 4201-49           | PLATE, LOCK NUT                       | 2   |
| 4201-AA           | BOLT                                  | 4   |
| 4201-AB           | BOLT, BRACKET SET                     | 4   |
| 4201-AC           | BOLT, STUD BRAKE SET                  | 16  |
| 4201-AD           | WASHER, CO SPRING                     | 16  |
| 4201-AE           | BOLT                                  | 2   |


(ATH) ( 9 )

G107

FIG. 4301  
REAR AXLE & TIE-ROD

4301

ATM



| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 4301-01           | AXLE ASSY, RR                      | 1   |
| 4301-10           | END ASSY, TIE-ROD, NO.1            | 2   |
| 4301-10A          | NUT, CASTLE (FOR TIE-ROD END)      | 4   |
| 4301-10B          | NUT (RH THREADS)                   | 2   |
| 4301-10C          | PIN, COTTER (FOR TIE-ROD END)      | 4   |
| 4301-11           | END ASSY, TIE-ROD, NO.2            | 2   |
| 4301-11B          | NUT (LH THREADS)                   | 2   |
| 4301-13K          | TIE-ROD KIT                        | 2   |
| 4301-20           | BEAM SUB-ASSY, REAR AXLE           | 1   |
| 4301-20A          | BUSH, REAR AXLE BEAM               | 2   |
| 4301-20B          | SHIM, REAR AXLE BEAM               | 1   |
| 4301-23           | BELLCRANK SUB-ASSY, STEERING       | 1   |
| 4301-23A          | BEARING (FOR STEERING BELLCRANK)   | 2   |
| 4301-23B          | SEAL, OIL (FOR STEERING BELLCRANK) | 2   |
| 4301-23K          | SEAL KIT, BELLCRANK PIN            | 1   |
| 4301-40           | KNUCKLE, STEERING, RH              | 1   |
| 4301-41           | KNUCKLE, STEERING, LH              | 1   |
| 4301-42           | PIN, STEERING KNUCKLE KING         | 2   |
| 4301-42A          | BEARING, STEERING KNUCKLE THRUST   | 2   |
| 4301-42B          | SEAL, OIL, NO.1                    | 4   |
| 4301-42C          | BEARING, NEEDLE                    | 4   |
| 4301-42D          | SHIM, STEERING KNUCKLE             | 1   |
| 4301-42E          | SEAL, OIL, NO.2                    | 2   |
| 4301-42K          | SEAL KIT, KING PIN                 | 2   |
| 4301-43           | PIN, KING PIN LOCK                 | 2   |
| 4301-44A          | BEARING, INNER                     | 2   |
| 4301-44B          | BEARING, OUTER                     | 2   |
| 4301-44E          | PIN, REAR AXLE COTTER              | 2   |
| 4301-44F          | SEAL, OIL (FOR REAR AXLE HUB)      | 2   |
| 4301-44G          | NUT, CASTLE (FOR REAR AXLE HUB)    | 2   |
| 4301-45           | CAP, REAR AXLE HUB                 | 2   |
| 4301-47           | TIE-ROD                            | 2   |
| 4301-48           | PIN, BELLCRANK                     | 1   |
| 4301-AA           | BOLT                               | 2   |
| 4301-AB           | FITTING, GREASE                    | 4   |
| 4301-AC           | FITTING, GREASE                    | 3   |
| 4301-AD           | WASHER, CRAW                       | 2   |
| 4301-AE           | SHIM                               | 1   |
| 4301-AF           | PLATE, STOPPER                     | 1   |


(ATM) ( 10)

G107

FIG. 4406  
FRONT WHEEL & TIRE

4406

ATM



| PART NAME<br>CODE | PART NAME  | QTY |
|-------------------|------------|-----|
| 4406-01           | WHEEL ASSY | 2   |
| 4406-13           | TIRE ASSY  | 2   |


(ATM ) ( 11)

6107

FIG. 4407  
REAR WHEEL & TIRE

4407

ATM



| PART NAME<br>CODE | PART NAME            | QTY |
|-------------------|----------------------|-----|
| 4407-01           | WHEEL ASSY           | 2   |
| 4407-13           | TIRE ASSY            | 2   |
| 4407-20           | WHEEL SUB-ASSY, DISC | 2   |

4407 001


(ATM ) ( 12)

G107

FIG.4501  
STEERING WHEEL

4501

ATM



4501-002

| PART NAME<br>CODE | PART NAME                         | QTY |
|-------------------|-----------------------------------|-----|
| 4501-01           | WHEEL ASSY, STEERING              | 1   |
| 4501-10           | KNOB ASSY, STEERING WHEEL         | 1   |
| 4501-30           | KNOB SUB-ASSY, STEERING WHEEL     | 1   |
| 4501-40           | BUTTON, HORN                      | 1   |
| 4501-42           | PLATE, HORN CONTACT               | 1   |
| 4501-43           | SEAT, HORN CONTACT                | 1   |
| 4501-44           | SPRING, HORN                      | 1   |
| 4501-45           | PLATE, LEAD                       | 1   |
| 4501-AA           | SCREW                             | 1   |
| 4501-AB           | WASHER                            | 3   |
| 4501-AC           | SCREW                             | 2   |
| 4501-AD           | CAP, STEERING WHEEL               | 1   |
| 4501-AE           | BOLT, STEERING WHEEL KNOB SET     | 1   |
| 4501-AF           | BRACKET, STEERING WHEEL KNOB      | 1   |
| 4501-AG           | SEAT, STEERING WHEEL KNOB BRACKET | 1   |
| 4501-AH           | SEAT, STEERING WHEEL KNOB BRACKET | 1   |
| 4501-AI           | SEAT, WHEEL KNOB SET PLATE        | 1   |
| 4501-AJ           | PLATE, STEERING WHEEL KNOB SET    | 1   |
| 4501-AK           | RING, HORN CONTACT NO.1           | 1   |

(ATM) ( 13 )


G107

FIG. 4502  
STEERING PDST


4502

ATM

ATM



4502-005



4502-006A

# 4502

| PART NAME<br>CODE | PART NAME                                  | QTY |
|-------------------|--------------------------------------------|-----|
| 4502-01           | POST ASSY, STEERING -----                  | 1   |
| 4502-10           | GEAR ASSY, STEERING -----                  | 1   |
| 4502-10K          | GEAR O/H KIT, STEERING -----               | 1   |
| 4502-11           | BALL SCREW SET -----                       | 1   |
| 4502-11A          | BEARING, NO.1 (FOR BALL SCREW SET) -----   | 1   |
| 4502-11B          | BEARING, NO.2 (FOR BALL SCREW SET) -----   | 1   |
| 4502-11C          | BEARING, THRUST (FOR BALL SCREW SET) ----- | 2   |
| 4502-12           | BODY ASSY, VALVE -----                     | 1   |
| 4502-20           | JACKET SUB-ASSY, MAST -----                | 1   |
| 4502-21           | BOX SUB-ASSY, STEERING GEAR -----          | 1   |
| 4502-21B          | BEARING, NO.1 (FOR SECTOR SHAFT) -----     | 1   |
| 4502-21C          | SEAL, OIL (FOR SECTOR SHAFT) -----         | 1   |
| 4502-30           | COVER SUB-ASSY, SIDE -----                 | 1   |
| 4502-30A          | BUSH, SECTOR SHAFT, NO.2 -----             | 1   |
| 4502-30C          | RING, O (FOR SIDE COVER) -----             | 1   |
| 4502-32           | INSULATOR SUB-ASSY, W/COLUMN BUSH -----    | 1   |
| 4502-40           | SHAFT, SECTOR -----                        | 1   |
| 4502-45           | COVER, TOP -----                           | 1   |
| 4502-45A          | RING, O (FOR TOP COVER) -----              | 1   |
| 4502-46           | COVER, END -----                           | 1   |
| 4502-46C          | RING, O (FOR END COVER) -----              | 1   |
| 4502-49           | GROMMET, STEERING COLUMN (INSULATOR) ----- | 1   |
| 4502-AD           | GROMMET -----                              | 1   |
| 4502-AE           | STAY SUB-ASSY, STEERING -----              | 1   |
| 4502-AF           | CLAMP -----                                | 1   |
| 4502-AG           | CLAMP, STEERING COLUMN, LOWER -----        | 1   |
| 4502-AI           | NUT -----                                  | 4   |
| 4502-AJ           | WASHER, SPRING -----                       | 4   |
| 4502-AK           | BOLT, STUD -----                           | 4   |
| 4502-AL           | PLUG, OIL -----                            | 1   |
| 4502-AM           | BOLT, ADJUSTING -----                      | 1   |
| 4502-AN           | PLATE, ADJUSTING -----                     | 1   |
| 4502-AP           | NUT -----                                  | 1   |
| 4502-AS           | SEAL, OIL -----                            | 1   |
| 4502-AT           | COLLAR -----                               | 1   |
| 4502-AU           | RING, SNAP -----                           | 1   |
| 4502-AV           | PACKING -----                              | 1   |
| 4502-AX           | NUT -----                                  | 1   |
| 4502-AY           | NUT, LOCK -----                            | 1   |
| 4502-BA           | RING, SNAP -----                           | 1   |
| 4502-BB           | SEAT -----                                 | 8   |
| 4502-BC           | SPRING -----                               | 4   |
| 4502-BD           | STOPPER, BALANCE PISTON -----              | 1   |
| 4502-BE           | RING, O -----                              | 1   |
| 4502-BF           | VALVE SUB-ASSY, RELIEF -----               | 1   |
| 4502-BG           | SPRING, BALANCE PISTON -----               | 1   |
| 4502-BH           | PLATE -----                                | 1   |
| 4502-BI           | RING, SNAP -----                           | 1   |
| 4502-BL           | BOLT, W/WASHER -----                       | 7   |
| 4502-BM           | BOLT, W/WASHER -----                       | 4   |
| 4502-BR           | BOOT, MAST JACKET -----                    | 1   |


(ATM ) ( 14 )

G107

FIG. 4507  
DRAG LINK & STEERING PIPING

4507

ATM



4507 005

# 4507

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 4507-10           | END ASSY, DRAG LINK -----                    | 2   |
| 4507-10A          | NUT, CASTLE (FOR DRAG LINK END) -----        | 2   |
| 4507-11           | END ASSY, POWER CYLINDER -----               | 2   |
| 4507-11A          | NUT, CASTLE (FOR POWER CYLINDER END) -----   | 2   |
| 4507-30           | PIPE SUB-ASSY, NO.1 (STEERING TO CYLINDER) - | 1   |
| 4507-31           | PIPE SUB-ASSY, NO.2 (STEERING TO CYLINDER) - | 1   |
| 4507-40           | ROD, DRAG LINK, NO.1 -----                   | 1   |
| 4507-41           | ARM, PITMAN -----                            | 1   |
| 4507-42           | HOSE, POWER CYLINDER, NO.1 -----             | 1   |
| 4507-43           | HOSE, POWER CYLINDER, NO.2 -----             | 1   |
| 4507-44           | END, POWER CYLINDER -----                    | 1   |
| 4507-AA           | CLAMP, END -----                             | 2   |
| 4507-AB           | CLAMP, PIPE -----                            | 1   |
| 4507-AC           | CLAMP, END -----                             | 2   |
| 4507-AE           | BRACKET SUB-ASSY, POWER CYLINDER -----       | 1   |

(ATM ) ( 15)

G107


4507

G107-002-0464

FIG. 4508  
STEERING POWER CYLINDER

4508

ATM



4508 004

| PART NAME<br>CODE | PART NAME                   | QTY |
|-------------------|-----------------------------|-----|
| 4508-01           | CYLINDER ASSY, POWER        | 1   |
| 4508-01K          | PACKING KIT, POWER CYLINDER | 1   |
| 4508-20           | CYLINDER SUB-ASSY, POWER    | 1   |
| 4508-40           | ROD, PISTON                 | 1   |
| 4508-40A          | NUT, SELF LOCK (FOR PISTON) | 1   |
| 4508-41           | PISTON                      | 1   |
| 4508-42           | RING, PISTON                | 2   |
| 4508-43           | GUIDE, ROD                  | 1   |
| 4508-AA           | BUSHING                     | 1   |
| 4508-AB           | RING, SNAP                  | 1   |
| 4508-AC           | SEAL, DUST                  | 1   |
| 4508-AD           | RING, O                     | 1   |
| 4508-AI           | COLLAR, REAR COVER          | 1   |
| 4508-AJ           | SEAT                        | 2   |
| 4508-AK           | RING, SNAP                  | 1   |
| 4508-AL           | PACKING, U                  | 1   |
| 4508-AM           | RING, BACK UP               | 1   |


(ATM) ( 16)

G107

FIG. 4601  
PARKING BRAKE

4601

ATM



| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 4601-10           | HANDLE ASSY, PARKING BRAKE               | 1   |
| 4601-24           | CABLE SUB-ASSY, PARKING BRAKE, NO.1      | 1   |
| 4601-25           | CABLE SUB-ASSY, PARKING BRAKE, NO.2      | 1   |
| 4601-29           | LEVER SUB-ASSY, INTERMEDIATE             | 1   |
| 4601-29A          | SPRING, TENSION (FOR INTERMEDIATE LEVER) | 1   |
| 4601-AA           | CLIP                                     | 2   |
| 4601-AC           | SPACER                                   | 1   |
| 4601-AD           | BUSHING, NYLON                           | 1   |
| 4601-AE           | BAR SUB-ASSY, EQUALIZER                  | 1   |
| 4601-AF           | PIN, W/HOLE                              | 1   |
| 4601-AG           | PULLEY                                   | 1   |
| 4601-AH           | CLAMP, WIRE SET                          | 1   |
| 4601-AI           | CLAMP                                    | 1   |


(ATM) ( 17 )

G107

FIG. 4701  
BRAKE PEDAL

4701

ATM



4701 004A

| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 4701-10           | END ASSY, INCHING ROD, NO.1        | 1   |
| 4701-11           | END ASSY, INCHING ROD, NO.2        | 1   |
| 4701-20           | PEDAL SUB-ASSY, BRAKE              | 1   |
| 4701-20A          | BUSH (FOR BRAKE PEDAL)             | 4   |
| 4701-21           | LINK SUB-ASSY, BRAKE, NO.1         | 1   |
| 4701-21A          | BUSH (FOR BRAKE LINK)              | 4   |
| 4701-22           | BRACKET SUB-ASSY, BRAKE PEDAL      | 1   |
| 4701-23           | LINK SUB-ASSY, BRAKE, NO.2         | 1   |
| 4701-27           | ROD SUB-ASSY, INCHING              | 1   |
| 4701-28           | LINK SUB-ASSY, INCHING             | 1   |
| 4701-28A          | BUSH (FOR INCHING LINK)            | 2   |
| 4701-40           | PAD, PEDAL                         | 1   |
| 4701-43           | SPRING, TORSION (FOR PEDAL RETURN) | 1   |
| 4701-44           | ROD, INCHING                       | 1   |
| 4701-45           | BRACKET, BRAKE PEDAL               | 2   |
| 4701-46           | LINK, BRAKE                        | 4   |
| 4701-AA           | SPACER                             | 2   |
| 4701-AC           | BRACKET, LINK                      | 1   |
| 4701-AF           | NUT                                | 1   |
| 4701-AI           | PIN, W/HOLE                        | 4   |
| 4701-AJ           | PIN, W/HOLE                        | 2   |
| 4701-AK           | PIN, W/HOLE                        | 2   |

( ATM ) ( 18 )

G107

4701


004A

6107 001-0481

FIG. 4704  
BRAKE VALVE

4704

ATM




| PART NAME<br>CODE | PART NAME              | QTY |
|-------------------|------------------------|-----|
| 4704-01           | VALVE ASSY, BRAKE      | 1   |
| 4704-01K          | VALVE O/H KIT, BRAKE   | 1   |
| 4704-20           | PISTON SUB-ASSY, INPUT | 1   |
| 4704-30           | VALVE SUB-ASSY, CLOSED | 1   |
| 4704-41           | BOOT                   | 1   |
| 4704-43           | ROD, PUSH              | 1   |
| 4704-44           | CUP, CYLINDER          | 1   |
| 4704-45           | PISTON, REACTION       | 1   |
| 4704-46           | GUIDE, REACTION PISTON | 1   |
| 4704-47           | SEAT, UNION            | 2   |
| 4704-48           | SPOOL, BRAKE VALVE     | 1   |
| 4704-49           | CLEVIS                 | 1   |
| 4704-50           | RETAINER, SPRING       | 1   |
| 4704-AA           | SPRING, COMPRESSION    | 1   |
| 4704-AB           | WASHER, PLATE          | 1   |
| 4704-AC           | RING, SNAP             | 1   |
| 4704-AD           | NUT                    | 2   |
| 4704-AE           | PLUG, HOLE             | 1   |
| 4704-AF           | RING, O                | 1   |
| 4704-AG           | RING, O                | 1   |
| 4704-AH           | SPRING, VALVE RETURN   | 1   |
| 4704-AI           | RING, O                | 1   |
| 4704-AJ           | RING, BACK UP          | 1   |
| 4704-AK           | RING, O                | 1   |
| 4704-AL           | RING, O                | 2   |

(ATM ) ( 19) G107

FIG. 4706  
BRAKE ACCUMULATOR

4706

ATM



| PART NAME<br>CODE | PART NAME                      | QTY |
|-------------------|--------------------------------|-----|
| 4706-01           | ACCUMULATOR ASSY               | 1   |
| 4706-10           | VALVE ASSY, CHECK              | 1   |
| 4706-10A          | RING, O (FOR CHECK VALVE)      | 1   |
| 4706-20           | ACCUMULATOR SUB-ASSY           | 1   |
| 4706-21           | PISTON SUB-ASSY                | 1   |
| 4706-21A          | RING, O (FOR PISTON)           | 1   |
| 4706-21B          | RING, BACK UP (FOR PISTON)     | 1   |
| 4706-41           | COVER, BODY                    | 1   |
| 4706-41A          | RING, O (FOR BODY COVER)       | 1   |
| 4706-41B          | RING, BACK UP (FOR BODY COVER) | 1   |
| 4706-42           | ROD, STROKE SWITCH             | 1   |
| 4706-AA           | RING, O                        | 1   |
| 4706-AB           | BRACKET, ACCUMULATOR, RR       | 1   |
| 4706-AD           | BOLT                           | 2   |

(ATM) ( 20)

G107

4706


001A

G107 001 0468

FIG. 4714  
BRAKE PIPE

4714

ATM




| PART NAME<br>CODE | PART NAME                                         | QTY |
|-------------------|---------------------------------------------------|-----|
| 4714-22           | PIPE SUB-ASSY, BRAKE, RH NO.1 -----               | 1   |
| 4714-23           | PIPE SUB-ASSY, BRAKE, LH NO.1 -----               | 1   |
| 4714-29           | PIPE SUB-ASSY, VALVE TO VALVE, NO.1 -----         | 1   |
| 4714-31           | PIPE SUB-ASSY, VALVE TO STEERING -----            | 1   |
| 4714-32           | PIPE SUB-ASSY, RETURN, NO.1 (VALVE TO TANK) ----- | 1   |
| 4714-33           | PIPE SUB-ASSY, RETURN, NO.2 (VALVE TO TANK) ----- | 1   |
| 4714-36           | PIPE SUB-ASSY, ACCUMULATOR TO VALVE, NO.1 --      | 1   |
| 4714-37           | PIPE SUB-ASSY, ACCUMULATOR TO VALVE, NO.2 --      | 1   |
| 4714-38           | PIPE SUB-ASSY, RETURN (ACCUMULATOR TO TANK) ----- | 1   |
| 4714-61           | HOSE, LOW PRESSURE (ACCUMULATOR TO TANK) ---      | 1   |
| 4714-61A          | CLAMP (FOR ACCUMULATOR TO TANK HOSE) -----        | 2   |
| 4714-AC           | PLUG -----                                        | 1   |
| 4714-AE           | 3-WAY SUB-ASSY -----                              | 1   |
| 4714-AG           | CLAMP -----                                       | 2   |

(ATM) ( 21 ) G107

FIG. 4715  
DRUM BRAKE

4715

ATH



| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 4715-01           | BRAKE ASSY, RH                     | 1   |
| 4715-02           | BRAKE ASSY, LH                     | 1   |
| 4715-10           | CYLINDER ASSY, WHEEL               | 2   |
| 4715-10K          | CYLINDER O/H KIT, WHEEL            | 2   |
| 4715-20           | SHOE SUB-ASSY (FOR FRONT OR UPPER) | 2   |
| 4715-21           | SHOE SUB-ASSY (FOR REAR OR LOWER)  | 1   |
| 4715-22           | PLATE SUB-ASSY, BACKING, RH        | 1   |
| 4715-23           | PLATE SUB-ASSY, BACKING, LH        | 1   |
| 4715-30           | SCREW SUB-ASSY, ADJUSTING, RH      | 1   |
| 4715-31           | SCREW SUB-ASSY, ADJUSTING, LH      | 1   |
| 4715-33           | CABLE & FITTING SUB-ASSY           | 2   |
| 4715-34           | CUP SUB-ASSY, PISTON               | 2   |
| 4715-40           | BOOT, WHEEL CYLINDER               | 4   |
| 4715-41           | CUP, WHEEL CYLINDER PISTON         | 4   |
| 4715-42           | LEVER, AUTOMATIC ADJUSTMENT, RH    | 1   |
| 4715-43           | LEVER, AUTOMATIC ADJUSTMENT, LH    | 1   |
| 4715-44           | GUIDE, CABLE                       | 2   |
| 4715-45           | SPRING, SHOE HOLD DOWN             | 4   |
| 4715-46           | CUP, SHOE HOLD DOWN                | 8   |
| 4715-47           | SPRING, ADJUSTER                   | 2   |
| 4715-48           | PIN, SHOE HOLD DOWN                | 4   |
| 4715-49           | RDD, PUSH                          | 4   |
| 4715-51           | SPRING, ANCHOR TO SHOE             | 4   |
| 4715-AB           | ?????                              | 2   |
| 4715-AD           | PLATE, SHOE GUIDE                  | 2   |
| 4715-AE           | WASHER, SPRING                     | 2   |
| 4715-AF           | LEVER SUB-ASSY, PARKING            | 1   |
| 4715-AG           | STRUT, LEVER                       | 1   |
| 4715-AH           | RING, SNAP                         | 2   |
| 4715-AI           | ?????                              | 1   |
| 4715-AJ           | SPRING, STRUT TO SHOE              | 2   |
| 4715-AK           | CAP, BREATHER SCREW                | 2   |
| 4715-AL           | SCREW, BREATHER                    | 2   |
| 4715-AN           | SPRING, WHEEL CYLINDER             | 2   |
| 4715-AX           | SPRING, LEVER RETURN, RH           | 1   |
| 4715-AY           | SPRING, LEVER RETURN, LH           | 1   |


(ATH) ( 22)

G107

FIG. 5101  
FRAME & WEIGHT

5101

ATM



5101 003

| PART NAME<br>CODE | PART NAME                         | QTY |
|-------------------|-----------------------------------|-----|
| 5101-30           | DRAW-BAR SUB-ASSY                 | 1   |
| 5101-31           | COVER SUB-ASSY, RADIATOR          | 1   |
| 5101-34           | GUARD SUB-ASSY, MUD, RH           | 1   |
| 5101-35           | GUARD SUB-ASSY, MUD, LH           | 1   |
| 5101-AA           | GUARD, MUD, FRONT                 | 2   |
| 5101-AB           | BOLT                              | 4   |
| 5101-AC           | WASHER, WAVE                      | 4   |
| 5101-AD           | HOSE, LOW PRESSURE                | 2   |
| 5101-AE           | CLAMP SUB-ASSY                    | 2   |
| 5101-AF           | BOLT, HEXAGON                     | 1   |
| 5101-AG           | PLATE, WASHER                     | 1   |
| 5101-AH           | BRACKET SUB-ASSY, RADIATOR COVER  | 2   |
| 5101-AI           | SPONGE                            | 1   |
| 5101-AJ           | MUD                               | 1   |
| 5101-AK           | HOOK SUB-ASSY, WEIGHT             | 2   |
| 5101-AL           | NUT, CASTLE                       | 2   |
| 5101-AM           | WASHER, PLATE                     | 4   |
| 5101-AN           | WRENCH, WEIGHT BOLT BOX           | 1   |
| 5101-AO           | HANDLE, WEIGHT BOLT BOX WRENCH    | 1   |
| 5101-AQ           | COVER SUB-ASSY, RADIATOR SIDE, RH | 1   |
| 5101-AR           | COVER SUB-ASSY, RADIATOR SIDE, LH | 1   |
| 5101-AS           | INSULATOR, EDGE                   | 1   |
| 5101-BY           | BRACKET SUB-ASSY, LOWER           | 1   |
| 5101-BZ           | GROMMET                           | 1   |



(ATM) ( 23 )

G107

FIG. 5201  
HOOD & HINGE

5201

ATM



5201 025

| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 5201-10           | STAY ASSY, ENGINE (OR BATTERY) HOOD      | 1   |
| 5201-20           | HOOD SUB-ASSY, ENGINE (OR BATTERY)       | 1   |
| 5201-30           | HINGE SUB-ASSY, ENGINE (OR BATTERY) HOOD | 2   |
| 5201-32           | CATCH SUB-ASSY (FOR HOOD)                | 1   |
| 5201-40           | RUBBER, CUSHION (FOR HOOD)               | 4   |
| 5201-AA           | STAY SUB-ASSY, ENGINE HOOD               | 1   |
| 5201-AB           | PIN, W/HOLE                              | 3   |
| 5201-AC           | WASHER, PLATE                            | 1   |
| 5201-AD           | SCREW, W/TOOTHED WASHER                  | 8   |
| 5201-AE           | HOOK, HOOD LOCK                          | 1   |
| 5201-AF           | PLUG, HOLE                               | 4   |
| 5201-AG           | PLUG, HOLE                               | 4   |
| 5201-AH           | PLATE, HEAT INSULATOR                    | 1   |
| 5201-AI           | CLIP                                     | 9   |


(ATM) ( 24 )

G107

FIG. 5301  
INSTRUMENT PANEL & FLOOR

5301

ATM




| PART NAME<br>CODE | PART NAME                  | QTY |
|-------------------|----------------------------|-----|
| 5301-20           | PANEL SUB-ASSY, INSTRUMENT | 1   |
| 5301-30           | TOE-BOARD SUB-ASSY, NO.1   | 1   |
| 5301-31           | TOE-BOARD SUB-ASSY, NO.2   | 1   |
| 5301-34           | CLAMP SUB-ASSY, PAPER      | 1   |
| 5301-AA           | SCREW                      | 4   |
| 5301-AC           | PLUG                       | 1   |
| 5301-AD           | PLUG                       | 1   |
| 5301-AE           | PLUG                       | 1   |
| 5301-AF           | WASHER, PLATE              | 4   |
| 5301-AG           | WALK, SAFETY               | 1   |
| 5301-AK           | EDGE, RH                   | 1   |
| 5301-AL           | EDGE, LH                   | 1   |
| 5301-AM           | SPRING                     | 1   |
| 5301-AN           | RUBBER, REAR TOE-BOARD     | 1   |
| 5301-AO           | SAFETY, WALK               | 1   |
| 5301-AQ           | WALK, SAFETY               | 1   |
| 5301-EG           | PLATE, RUBBER              | 2   |

(ATM) ( 25 ) G107

5308

ATM (W/ABSORBER)



5308 009

5308

| PART NAME<br>CODE | PART NAME                        | QTY |
|-------------------|----------------------------------|-----|
| 5308-D1           | SEAT ASSY -----                  | 1   |
| 5308-10           | CUSHION ASSY -----               | 1   |
| 5308-11           | TRACK ASSY -----                 | 1   |
| 5308-12           | TRACK ASSY, SEAT OUTER, RH ----- | 1   |
| 5308-13           | TRACK ASSY, SEAT OUTER, LH ----- | 1   |
| 5308-20           | SEAT SUB-ASSY, BACK -----        | 1   |
| 5308-40           | FRAME, BACK SEAT -----           | 1   |
| 5308-AA           | RUBBER, VIBRATION ISOLATOR ----- | 2   |
| 5308-AB           | BRACKET, NUMBER PLATE -----      | 1   |
| 5308-AC           | NUT, CAP -----                   | 2   |
| 5308-AD           | WIRE -----                       | 1   |
| 5308-AE           | WASHER -----                     | 2   |
| 5308-AF           | SPRING, TENSION, BACK SEAT ----- | 2   |
| 5308-AG           | LINK -----                       | 2   |
| 5308-AH           | PIN -----                        | 4   |
| 5308-AJ           | COIL, SPRING -----               | 2   |
| 5308-AK           | E-RING -----                     | 4   |
| 5308-AL           | PIN, NO.2 -----                  | 2   |
| 5308-AM           | SHOCK ABSORBER -----             | 1   |
| 5308-AN           | PIN, NO.3 -----                  | 2   |
| 5308-AO           | BUSHING -----                    | 2   |
| 5308-AP           | ADJUSTER, ROD -----              | 1   |
| 5308-AQ           | RUBBER, SEAT CUSHION -----       | 1   |
| 5308-AR           | HOOK, SEAT CUSHION -----         | 10  |
| 5308-AS           | RING, E -----                    | 2   |
| 5308-BC           | NUT, STOPPER -----               | 1   |
| 5308-BD           | BOLT, W/WASHER -----             | 4   |


(ATM ) ( 26)

G107

FIG. 5401  
HEAD GUARD & ACCESSORY

5401

ATM



| PART NAME<br>CODE | PART NAME                             | QTY |
|-------------------|---------------------------------------|-----|
| 5401-10           | CLOCK ASSY -----                      | 1   |
| 5401-30           | SHEET SUB-ASSY, HEAD GUARD -----      | 1   |
| 5401-31           | MIRROR SUB-ASSY, BACK -----           | 1   |
| 5401-32           | BRACKET SUB-ASSY, BACK MIRROR -----   | 1   |
| 5401-40           | REFLECTOR -----                       | 2   |
| 5401-50           | HARNESS SUB-ASSY, CLOCK -----         | 1   |
| 5401-AA           | BRACKET SUB-ASSY, LICENCE PLATE ----- | 1   |
| 5401-AB           | WIRE -----                            | 1   |
| 5401-AC           | BOLT, HEAD W/HOLE HEXAGON -----       | 1   |
| 5401-AD           | SEAL, ROD -----                       | 1   |
| 5401-AE           | PLUG, HOLE -----                      | 2   |
| 5401-AG           | CUSHION, RUBBER -----                 | 2   |
| 5401-AH           | GROMMET -----                         | 1   |

5401 002


(ATM ) ( 27 )

G107

FIG. 5405  
INDICATOR PLATE

5405

ATM




| PART NAME<br>CODE | PART NAME                          | QTY  |
|-------------------|------------------------------------|------|
| 5405-AA           | PLATE, CAUTION                     | 2    |
| 5405-AB           | TOYOTA MARK                        | 1- 2 |
| 5405-AC           | PLATE, CAUTION                     | 2    |
| 5405-AD           | PLATE, CAUTION                     | 1    |
| 5405-AE           | PLATE, INDICATOR                   | 1    |
| 5405-AF           | PLATE, SHIFT LEVER INDICATOR       | 1    |
| 5405-AG           | PLATE, LOAD INDICATOR              | 1    |
| 5405-AH           | PLATE, BRAKE INDICATOR             | 1    |
| 5405-AI           | PLATE, TILT INDICATOR              | 1    |
| 5405-AJ           | PLATE, CAUTION                     | 1    |
| 5405-AK           | PLATE, INDICATOR                   | 1    |
| 5405-AL           | TOYOTA MARK                        | 2    |
| 5405-AM           | PLATE, SERVICE INDICATOR           | 1    |
| 5405-AN           | PLATE, INDICATOR                   | 1    |
| 5405-AO           | PLATE, INDICATOR                   | 1    |
| 5405-AP           | STRIPE                             | 2    |
| 5405-AQ           | PLATE, CAPACITY INDICATOR          | 2    |
| 5405-AR           | PLATE, CAUTION                     | 1    |
| 5405-AT           | PLATE, CAUTION                     | 1    |
| 5405-AU           | RIVET                              | 4    |
| 5405-AV           | PLATE, ACCUMULATOR INDICATOR       | 1    |
| 5405-AW           | PLATE, SERVICE INDICATOR           | 1    |
| 5405-AX           | PLATE, DISCONNECT SWITCH INDICATOR | 1    |
| 5405-BC           | MARK, UL                           | 2    |

FIG. 5502  
CANVAS CABIN & FRONT GLASS

5502

ATM



| PART NAME<br>CODE | PART NAME                   | QTY |
|-------------------|-----------------------------|-----|
| 5502-02           | PANEL ASSY, FRONT GLASS     | 1   |
| 5502-20           | PANEL SUB-ASSY, FRONT GLASS | 1   |
| 5502-40           | GLASS, WINDSHIELD           | 4   |
| 5502-50           | WEATHER STRIP               | 1   |
| 5502-AC           | GROMMET                     | 2   |
| 5502-AD           | RUBBER, WINDSHIELD          | 2   |

(ATM) ( 29)

G107

5502


001A

G107-001-047B

FIG. 5601  
WIRING & CLAMP

5601

**ATM**



| PART NAME<br>CODE | PART NAME                    | QTY  |
|-------------------|------------------------------|------|
| 5601-10           | HARNES ASSY, WIRING          | 1    |
| 5601-20           | HARNES SUB-ASSY, MAIN        | 1    |
| 5601-21           | HARNES SUB-ASSY, PANEL       | 1-1  |
| 5601-22           | HARNES SUB-ASSY, RR          | 1    |
| 5601-27           | HARNES, RR                   | 2    |
| 5601-41           | RESISTOR                     | 3    |
| 5601-44           | CORD, HEAD LAMP              | 2    |
| 5601-AA           | CORD, OIL PRESSURE           | 1    |
| 5601-AB           | CORD, WATER TEMPERATURE      | 1    |
| 5601-AC           | CORD, TORCON HEAT GAGE       | 1    |
| 5601-AC           | HARNES, WIRE                 | 1    |
| 5601-AF           | CLAMP                        | 2    |
| 5601-AG           | CORD, OIL PRESSURE           | 1    |
| 5601-AH           | GROMMET                      | 4    |
| 5601-AI           | TUBE                         | 3    |
| 5601-AJ           | WIRE, LAMP BRACKET EARTH     | 2    |
| 5601-AK           | COLLAR                       | 4    |
| 5601-AL           | WASHER, RUBBER               | 4    |
| 5601-AM           | CLAMP                        | 4    |
| 5601-AN           | CORD, WORKING LAMP           | 1    |
| 5601-AP           | CORD, SPEEDMETER             | 1    |
| 5601-AQ           | CORD, SPEEDMETER             | 1    |
| 5601-AR           | CORD, SPEEDMETER             | 1    |
| 5601-AS           | BOLT, W/WASHER               | 2    |
| 5601-AT           | PLATE SUB-ASSY               | 1    |
| 5601-AU           | SPONGE                       | 2    |
| 5601-BA           | CLAMP                        | 1    |
| 5601-BB           | CLIP                         | 1    |
| 5601-BC           | CLAMP                        | 1    |
| 5601-BD           | CLAMP, ENGINE WIRE HARNES    | 1    |
| 5601-BE           | CLAMP                        | 1    |
| 5601-BK           | GROMMET                      | 1- 2 |
| 5601-BL           | FUSE BLOCK ASSY              | 1    |
| 5601-BM           | BRACKET SUB-ASSY, FUSE BLOCK | 1    |
| 5601-BN           | FUSIBLE, LINK                | 1    |
| 5601-CD           | HOLDER, FUSE                 | 1    |












(ATM) (30)

G107

FIG. 5611  
LAMP

5611

ATM



5611 002

# 5611


| PART NAME<br>CODE | PART NAME                               | QTY |
|-------------------|-----------------------------------------|-----|
| 5611-01           | LAMP ASSY, HEAD -----                   | 2   |
| 5611-01A          | UNIT, SEALBEAM (FOR HEAD LAMP) -----    | 2   |
| 5611-02           | LAMP ASSY, WORKING -----                | 1   |
| 5611-02A          | UNIT, SEALBEAM (FOR WORKING LAMP) ----- | 2   |
| 5611-03           | LAMP ASSY, FLASHER -----                | 2   |
| 5611-03A          | BULB (FOR FLASHER LAMP) -----           | 2   |
| 5611-03B          | LENS (FOR FLASHER LAMP) -----           | 2   |
| 5611-04           | LAMP ASSY, REAR COMBINATION -----       | 1   |
| 5611-04A          | BULB (FOR REAR COMBINATION LAMP) -----  | 1   |
| 5611-04B          | LENS (FOR REAR COMBINATION LAMP) -----  | 1   |
| 5611-05           | LAMP ASSY, LICENCE -----                | 1   |
| 5611-05A          | BULB (FOR LICENCE LAMP) -----           | 1   |
| 5611-05B          | LENS (FOR LICENCE LAMP) -----           | 1   |
| 5611-07           | LAMP ASSY, CLEARANCE -----              | 2   |
| 5611-07A          | BULB (FOR CLEARANCE LAMP) -----         | 2   |
| 5611-07B          | LENS (FOR CLEARANCE LAMP) -----         | 2   |
| 5611-20           | LAMP ASSY, ACCUMULATOR PILOT -----      | 1   |
| 5611-24           | LAMP ASSY, CHARGE WARNING -----         | 1   |
| 5611-25           | LAMP ASSY, WORKING PILOT -----          | 1   |
| 5611-26           | LAMP ASSY, COMBINATION PILOT -----      | 1   |
| 5611-30           | CONTROLLER ASSY, GLOW PLUG -----        | 1   |
| 5611-AA           | RING -----                              | 2   |
| 5611-AB           | SCREW -----                             | 2   |
| 5611-AC           | SPRING, SET -----                       | 6   |
| 5611-AD           | SPACER -----                            | 2   |
| 5611-AF           | CORD, HEAD LAMP -----                   | 2   |
| 5611-AH           | STOPPER, SCREW -----                    | 2   |
| 5611-AI           | SCREW -----                             | 4   |
| 5611-AK           | PACKING -----                           | 4   |
| 5611-AL           | SCREW -----                             | 4   |
| 5611-AM           | SCREW -----                             | 2   |
| 5611-AN           | SCREW, TAP -----                        | 2   |
| 5611-AD           | PACKING -----                           | 1   |
| 5611-AP           | GASKET -----                            | 1   |
| 5611-AQ           | HOUSING -----                           | 1   |
| 5611-AR           | SCREW -----                             | 2   |

(ATM ) ( 31) G107


FIG. 5612  
LAMP BRACKET

5612

ATM



(L.P.G.)



5612 002

| PART NAME<br>CODE | PART NAME                     | QTY |
|-------------------|-------------------------------|-----|
| 5612-AA           | PROTECTOR SUB-ASSY, HEAD LAMP | 1   |
| 5612-AB           | BRACKET SUB-ASSY, HEAD LAMP   | 1   |
| 5612-AC           | BRACKET, BACK LAMP            | 1   |
| 5612-AD           | PLATE                         | 1   |
| 5612-AE           | COVER, CLEARANCE LAMP         | 2   |
| 5612-AF           | GUARD, COMBINATION            | 4   |
| 5612-AH           | BRACKET, REAR LAMP            | 2   |


(ATM) ( 32)

G107

FIG. 5701  
METER & SWITCH

5701

ATM



5701 002A

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 5701-01           | REGULATOR ASSY, GENERATOR                    | 1   |
| 5701-02           | RELAY ASSY, STARTER                          | 1   |
| 5701-03           | RELAY ASSY, GLOW PLUG                        | 1   |
| 5701-05           | RELAY ASSY, FLASHER                          | 1   |
| 5701-07           | UNIT ASSY, FUEL                              | 1   |
| 5701-09           | BUZZER ASSY, ACCUMULATOR INDICATOR           | 1   |
| 5701-10           | HORN ASSY                                    | 1   |
| 5701-11           | BUZZER ASSY, BACK                            | 1   |
| 5701-13           | SWITCH ASSY, TURN SIGNAL                     | 1   |
| 5701-13A          | SWITCH ASSY, MICRO (FOR TURN SIGNAL SWITCH)  | 2   |
| 5701-14           | SWITCH ASSY, LIGHT CONTROL                   | 1   |
| 5701-15           | SWITCH ASSY, IGNITION STARTER                | 1   |
| 5701-16           | SWITCH ASSY, OVER INJECTION                  | 1   |
| 5701-17           | SWITCH ASSY, NEUTRAL SAFETY                  | 1   |
| 5701-17A          | GASKET (FOR NEUTRAL SAFETY SWITCH)           | 1   |
| 5701-18           | SWITCH ASSY, HORN                            | 1   |
| 5701-18A          | CONTACT, HORN                                | 1   |
| 5701-19           | SWITCH ASSY, BACK-UP LAMP                    | 1   |
| 5701-20           | GAGE ASSY, FUEL                              | 1   |
| 5701-21           | GAGE ASSY, WATER TEMPERATURE (ENGINE)        | 1   |
| 5701-22           | GAGE ASSY, TEMPERATURE (TORCON)              | 1   |
| 5701-23           | GAGE ASSY, OIL PRESSURE (ENGINE)             | 1   |
| 5701-24           | METER ASSY, HOUR                             | 1   |
| 5701-29           | GAGE ASSY, OIL PRESSURE SENDER (ENGINE)      | 1   |
| 5701-30           | GAGE ASSY, WATER TEMPERATURE SENDER (ENGINE) | 1   |
| 5701-31           | GAGE ASSY, TEMPERATURE SENDER (TORCON)       | 1   |
| 5701-32           | SWITCH ASSY, OIL PRESSURE (ENGINE)           | 1   |
| 5701-33           | SWITCH ASSY, STOP LAMP                       | 1   |
| 5701-35           | SWITCH ASSY, ACCUMULATOR PILOT               | 1   |
| 5701-36           | SWITCH ASSY, DISCONNECT                      | 1   |
| 5701-AA           | BRACKET SUB-ASSY, HORN                       | 1   |
| 5701-AB           | BUSHING                                      | 1   |
| 5701-AC           | PLATE, BACK UP LAMP SWITCH                   | 1   |
| 5701-AD           | CLAMP, BACK UP LAMP SWITCH                   | 1   |
| 5701-AE           | NUT, HEXAGON                                 | 1   |
| 5701-AF           | HARNES ASSY                                  | 1   |
| 5701-AG           | BODY, SWITCH                                 | 1   |
| 5701-AH           | HOLDER, HORN POINT                           | 1   |
| 5701-AI           | SPRING, HORN CONTACT                         | 1   |
| 5701-AJ           | COVER                                        | 1   |
| 5701-AK           | LOCKING BLOCK                                | 1   |
| 5701-AL           | COVER, RUBBER                                | 1   |
| 5701-AM           | HARNES ASSY                                  | 1   |
| 5701-AN           | ACTUATOR                                     | 2   |
| 5701-AO           | PLATE, SWITCH                                | 1   |
| 5701-AP           | LEVER, SIGNAL                                | 1   |
| 5701-AQ           | BELLOWS                                      | 1   |
| 5701-AR           | HOLDER, ROLLER                               | 1   |
| 5701-AS           | ROLLER                                       | 1   |
| 5701-AT           | SPRING                                       | 1   |
| 5701-AU           | BRACKET SUB-ASSY, DISCONNECT SWITCH          | 1   |
| 5701-AV           | SCREW                                        | 5   |
| 5701-AW           | BRACKET SUB-ASSY, STOP SWITCH                | 1   |

(ATM) ( 33) G107

5701


| PART NAME<br>CODE | PART NAME          | QTY |
|-------------------|--------------------|-----|
| 5701-AZ           | PLATE, COVER ----- | 1   |

(ATM ) ( 34 ) G107

FIG. 5801  
WIPER MOTOR & BLADE

5801

ATM



| PART NAME<br>CODE | PART NAME             | QTY |
|-------------------|-----------------------|-----|
| 5801-10           | MOTOR ASSY, WIPER     | 1   |
| 5801-30           | BLADE SUB-ASSY, WIPER | 1   |
| 5801-31           | ARM SUB-ASSY, WIPER   | 1   |
| 5801-AA           | HARNESS, WIPER        | 1   |


(ATM ) ( 35)

G107

FIG. 5802  
HEATER

5802

ATM



5802-003A

| PART NAME<br>CODE | PART NAME               | QTY |
|-------------------|-------------------------|-----|
| 5802-01           | HEATER & ACCESSORY ASSY | 1   |
| 5802-02           | HEATER ASSY             | 1   |
| 5802-10           | MOTOR ASSY              | 1   |
| 5802-11           | SWITCH ASSY, HEATER     | 1   |
| 5802-20           | UNIT SUB-ASSY, RADIATOR | 1   |
| 5802-30           | BOOT SUB-ASSY, TILT     | 1   |
| 5802-40           | HOSE, NO.1              | 1   |
| 5802-41           | HOSE, NO.2              | 1   |
| 5802-42           | HOSE, NO.3              | 1   |
| 5802-43           | HOSE, NO.4              | 1   |
| 5802-44           | HOSE, NO.5              | 1   |
| 5802-46           | PIPE, NO.1              | 1   |
| 5802-47           | PIPE, NO.2              | 1   |
| 5802-48           | PIPE, NO.3              | 1   |
| 5802-AA           | CLAMP                   | 2   |
| 5802-AB           | CLAMP                   | 2   |
| 5802-AQ           | JOINT                   | 1   |
| 5802-AE           | JOINT                   | 1   |
| 5802-AG           | BUSHING                 | 3   |
| 5802-AH           | BAND                    | 1   |
| 5802-AI           | BUSHING                 | 1   |
| 5802-AJ           | CLAMP                   | 1   |
| 5802-AK           | PROTECTOR               | 2   |
| 5802-AL           | PLATE, CAUTION          | 1   |
| 5802-AM           | 3-WAY                   | 1   |
| 5802-AN           | ELBOW                   | 1   |
| 5802-AO           | BRACKET SUB-ASSY, PIPE  | 1   |
| 5802-AP           | HARNES SUB-ASSY, HEATER | 1   |
| 5802-AQ           | COVER, HEATER           | 1   |
| 5802-AR           | BOLT                    | 2   |
| 5802-AS           | WASHER, WAVE            | 2   |
| 5802-AT           | COVER, PIPE             | 1   |
| 5802-BU           | COVER, EDGE             | 1   |

(ATM) ( 36)

G107


**MEMO**

Silverhorn.co.uk

FIG. 6101  
MAST

6101

FSV



| PART NAME<br>CODE | PART NAME                            | QTY |
|-------------------|--------------------------------------|-----|
| 6101-20           | MAST SUB-ASSY, OUTER                 | 1   |
| 6101-20B          | BUSH, MAST SUPPORT                   | 2   |
| 6101-21           | MAST SUB-ASSY, INNER                 | 1   |
| 6101-22           | MAST SUB-ASSY, MIDDLE                | 1   |
| 6101-30           | STRIP SUB-ASSY, OUTER MAST           | 2   |
| 6101-30A          | SHIM, OUTER MAST STRIP               | 99  |
| 6101-31           | STRIP SUB-ASSY, MIDDLE MAST          | 2   |
| 6101-31A          | SHIM, MIDDLE MAST STRIP              | 99  |
| 6101-40           | ROLLER, LIFT (FOR OUTER MAST)        | 2   |
| 6101-41           | ROLLER, LIFT (FOR INNER MAST)        | 2   |
| 6101-42           | ROLLER, LIFT (FOR MIDDLE MAST UPPER) | 2   |
| 6101-43           | ROLLER, LIFT (FOR MIDDLE MAST LOWER) | 2   |
| 6101-AD           | FITTING, GREASE                      | 2   |
| 6101-AF           | COVER, ROLLER                        | 2   |
| 6101-AH           | BOLT                                 | 8   |


(FSV ) ( 1 )

G107

FIG. 6301  
LIFT BRACKET & FORK

6301

FSV



6301 017


| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6301-20           | BACKREST SUB-ASSY                  | 1   |
| 6301-21           | FORK SUB-ASSY                      | 2   |
| 6301-22           | BRACKET SUB-ASSY, LIFT             | 1   |
| 6301-40           | ROLLER, LIFT (UPPER, LOWER)        | 4   |
| 6301-40A          | RING, SHAFT SNAP (UPPER, LOWER)    | 2   |
| 6301-40B          | SHIM, LIFT ROLLER                  | 99  |
| 6301-42           | ROLLER, SIDE                       | 2   |
| 6301-42B          | SPACER (FOR SIDE ROLLER)           | 4   |
| 6301-43           | SHAFT, SIDE ROLLER                 | 2   |
| 6301-44           | HOLDER, SIDE ROLLER SHAFT          | 4   |
| 6301-44A          | SHIM (FOR SHAFT HOLDER)            | 99  |
| 6301-46           | PIN, FORK STOPPER                  | 2   |
| 6301-47           | KNOB, FORK STOPPER PIN             | 2   |
| 6301-48           | SPRING, FORK STOPPER PIN           | 2   |
| 6301-49           | PIN, SPRING (FOR FORK STOPPER PIN) | 2   |
| 6301-AA           | COVER, LIFT BRACKET ROLLER         | 4   |
| 6301-AB           | PLATE, SIDE                        | 2   |

(FSV ) ( 2 ) G107

FIG. 6302  
CHAIN & CHAIN WHEEL

6302

FSV



| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 6302-21           | CHAIN SUB-ASSY (FRONT)                   | 2   |
| 6302-21A          | NUT, CHAIN ADJUST (FRONT)                | 2   |
| 6302-21K          | BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)     | 2   |
| 6302-21M          | BOLT KIT, CHAIN EYE (FRONT)              | 2   |
| 6302-22           | CHAIN SUB-ASSY (REAR)                    | 2   |
| 6302-22K          | BOLT KIT, CHAIN ANCHOR, NO.1 (REAR)      | 2   |
| 6302-22L          | BOLT KIT, CHAIN ANCHOR, NO.2 (REAR)      | 2   |
| 6302-41           | WHEEL, CHAIN (FRONT)                     | 2   |
| 6302-41A          | RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL) | 2   |
| 6302-42           | WHEEL, CHAIN (REAR)                      | 4   |
| 6302-42A          | RING, SHAFT SNAP (FOR CHAIN WHEEL)       | 4   |
| 6302-45           | SUPPORT, CHAIN WHEEL                     | 1   |
| 6302-AD           | NUT, HEXAGON                             | 2   |
| 6302-AE           | WASHER, CHAIN SPECIAL                    | 2   |
| 6302-AH           | COVER, CHAIN WHEEL                       | 2   |

(FSV ) ( 3 )

G107

6302


001

G107-001-0489

FIG. 6502  
FRONT LIFT CYLINDER

6502

FSV



6502 007

| PART NAME<br>CODE | PART NAME                         | QTY |
|-------------------|-----------------------------------|-----|
| 6502-01           | CYLINDER ASSY, LIFT               | 1   |
| 6502-01K          | CYLINDER O/H KIT, LIFT            | 1   |
| 6502-11           | VALVE ASSY, SAFETY DOWN           | 1   |
| 6502-20           | CYLINDER SUB-ASSY, LIFT           | 1   |
| 6502-21           | ROD SUB-ASSY, LIFT CYLINDER       | 1   |
| 6502-30           | GUIDE SUB-ASSY, LIFT CYLINDER ROD | 1   |
| 6502-42           | SLEEVE, LIFT CYLINDER ROD GUIDE   | 1   |
| 6502-AA           | BUSHING                           | 1   |
| 6502-AB           | RING, O                           | 1   |
| 6502-AC           | RING, BACK UP                     | 1   |
| 6502-AD           | PACKING, U                        | 1   |
| 6502-AE           | RING, BACK UP                     | 1   |
| 6502-AF           | SEAL, DUST                        | 1   |
| 6502-AG           | RING, O                           | 1   |
| 6502-AH           | PLUG                              | 1   |
| 6502-AI           | RING, O                           | 1   |

(FSV) ( 4 )

G107

6503

| PART NAME | CODE |
|-----------|------|
|-----------|------|

QTY




|          |                                       |   |
|----------|---------------------------------------|---|
| 6503-01  | CYLINDER ASSY, LIFT, RH               | 1 |
| 6503-01K | CYLINDER O/H KIT, LIFT, RH            | 1 |
| 6503-02  | CYLINDER ASSY, LIFT, LH               | 1 |
| 6503-02K | CYLINDER O/H KIT, LIFT, LH            | 1 |
| 6503-11  | VALVE ASSY, SAFETY DOWN               | 1 |
| 6503-20  | CYLINDER SUB-ASSY, LIFT, RH           | 1 |
| 6503-21  | CYLINDER SUB-ASSY, LIFT, LH           | 1 |
| 6503-22  | ROD SUB-ASSY, LIFT CYLINDER, RH       | 1 |
| 6503-23  | ROD SUB-ASSY, LIFT CYLINDER, LH       | 1 |
| 6503-30  | GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH | 1 |
| 6503-31  | GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH | 1 |
| 6503-42  | SLEEVE, LIFT CYLINDER ROD GUIDE       | 2 |
| 6503-AA  | RING, WEAR                            | 2 |
| 6503-AB  | PACKING, U                            | 2 |
| 6503-AE  | PACKING, U                            | 2 |
| 6503-AF  | RING, O                               | 2 |
| 6503-AG  | SEAL, DUST                            | 2 |
| 6503-AH  | RING, O                               | 1 |
| 6503-AI  | SHIM                                  | 2 |
| 6503-AK  | BRACKET SUB-ASSY, LIFT CYLINDER       | 2 |
| 6503-AL  | BUSHING                               | 4 |
| 6503-AM  | SPACER                                | 2 |
| 6503-AN  | SHIM                                  | 2 |
| 6503-AQ  | RING, BACK UP                         | 2 |
| 6503-BB  | BOLT                                  | 2 |

G107

F/G-6511  
TILT CYLINDER

6511

FSV



| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6511-01           | CYLINDER ASSY, TILT                | 2   |
| 6511-01K          | CYLINDER O/H KIT, TILT             | 2   |
| 6511-20           | CYLINDER SUB-ASSY, TILT            | 2   |
| 6511-20A          | BUSH, PIN (FOR CYLINDER)           | 2   |
| 6511-21           | ROD SUB-ASSY, TILT CYLINDER PISTON | 2   |
| 6511-21B          | NUT, CASTLE                        | 2   |
| 6511-30           | GUIDE SUB-ASSY, TILT CYLINDER ROD  | 2   |
| 6511-31           | PIN SUB-ASSY, TILT CYLINDER, FR    | 2   |
| 6511-32           | PIN SUB-ASSY, TILT CYLINDER, RR    | 2   |
| 6511-40           | PISTON, TILT CYLINDER              | 2   |
| 6511-41           | COVER, TILT CYLINDER               | 2   |
| 6511-42           | SLEEVE, TILT CYLINDER ROD GUIDE    | 2   |
| 6511-44           | JOINT, PISTON ROD                  | 2   |
| 6511-50           | SEAL, GREASE                       | 4   |
| 6511-AA           | RING, HOLE SNAP                    | 2   |
| 6511-AB           | SEAL, DUST                         | 2   |
| 6511-AC           | RING, BACK UP                      | 2   |
| 6511-AD           | RING, O                            | 2   |
| 6511-AE           | RING, BACK UP                      | 2   |
| 6511-AF           | PACKING, U                         | 2   |
| 6511-AG           | PLATE, STOPPER                     | 2   |
| 6511-AH           | RING, HOLE SNAP                    | 2   |
| 6511-AI           | RING, O                            | 2   |
| 6511-AJ           | PACKING, U                         | 4   |
| 6511-AK           | SHIM, TILT CONTROL                 | 99  |
| 6511-AL           | SPACER, TILT CONTROL               | 2   |
| 6511-AM           | RING, O                            | 2   |
| 6511-AN           | COLLAR                             | 4   |


(FSV ) ( 6 )

G107

FIG. 6701  
OIL PUMP

6701

FSV



| PART NAME<br>CODE | PART NAME         | QTY |
|-------------------|-------------------|-----|
| 6701-01           | PUMP ASSY, OIL    | 1   |
| 6701-01K          | PUMP D/H KIT, OIL | 1   |
| 6701-10           | GEAR SET          | 1   |
| 6701-11           | BUSH SET          | 2   |
| 6701-43           | BODY              | 1   |
| 6701-44           | FLANGE, MOUNTING  | 1   |
| 6701-44A          | PACKING, OIL PUMP | 1   |
| 6701-45           | COVER             | 1   |
| 6701-AA           | SEAL, BUSHING     | 2   |
| 6701-AB           | RING, BACKING, RH | 2   |
| 6701-AC           | RING, BACKING, LH | 2   |
| 6701-AD           | SEAL, OIL         | 1   |
| 6701-AE           | RING, SNAP        | 1   |
| 6701-AF           | BOLT              | 4   |
| 6701-AG           | WASHER, SPRING    | 4   |
| 6701-AH           | SEAL, BODY        | 2   |
| 6701-AI           | BOLT              | 2   |

6701-005A

(FSV) ( 7 ) G107

6701


NOVA

6107-001-0492

# 6705 CONTROL VALVE

6705





FSV



6705-005 A

6705

(W/REMOTE CONTROL VALVE)




6705-006A

FIG. 6705  
OIL CONTROL VALVE

**6705**

FSV (4-WAY)

(W)/REMOTE CONTROL VALVE



6705-007A

# 6705

| PART NAME<br>CODE | PART NAME                              | QTY |
|-------------------|----------------------------------------|-----|
| 6705-01           | VALVE ASSY, OIL CONTROL                | 1   |
| 6705-01K          | VALVE O/H KIT, OIL CONTROL             | 1   |
| 6705-10           | VALVE ASSY, PLUNGER SECTION, NO.1      | 1   |
| 6705-11           | VALVE ASSY, PLUNGER SECTION, NO.2      | 1   |
| 6705-20           | VALVE SET, PILOT RELIEF, NO.1          | 1   |
| 6705-21           | VALVE SET, PILOT RELIEF, NO.2          | 1   |
| 6705-23           | HOUSING & SPOOL SET, NO.1              | 1   |
| 6705-25           | HOUSING & SPOOL SET, ATTACHMENT, NO.1  | 1   |
| 6705-26           | HOUSING & SPOOL SET, ATTACHMENT, NO.2  | 1   |
| 6705-40           | COVER, SPRING                          | 2   |
| 6705-41           | SPRING, COMPRESSION (FOR SPOOL RETURN) | 2   |
| 6705-50A          | RING, O                                | 2   |
| 6705-50B          | RING, O                                | 1   |
| 6705-50C          | RING, O                                | 2   |
| 6705-AA           | BOLT                                   | 4   |
| 6705-AH           | HOUSING, OUTLET                        | 1   |
| 6705-AC           | RING, O                                | 1   |
| 6705-AD           | RING, O                                | 1   |
| 6705-AE           | RING, O                                | 2   |
| 6705-AF           | BALL, STEEL                            | 1   |
| 6705-AG           | SPRING                                 | 1   |
| 6705-AH           | SPRING, COMPRESSION                    | 1   |
| 6705-AI           | RING, O                                | 1   |
| 6705-AJ           | STOPPER                                | 1   |
| 6705-AK           | HOLDER, SPRING                         | 2   |
| 6705-AL           | WASHER, PLATE                          | 2   |
| 6705-AM           | RING, SHAFT SNAP                       | 2   |
| 6705-AN           | SCREW                                  | 4   |
| 6705-AD           | PLUG                                   | 4   |
| 6705-AP           | RING, O                                | 4   |
| 6705-AQ           | RING, BACK UP                          | 4   |
| 6705-AR           | HOLDER, SEAL                           | 4   |
| 6705-AS           | SCREW                                  | 4   |
| 6705-AT           | STOPPER                                | 1   |
| 6705-AU           | STOPPER                                | 1   |
| 6705-AV           | RING, O                                | 2   |
| 6705-AW           | SPRING, COMPRESSION                    | 1   |
| 6705-AX           | RING, O                                | 3   |
| 6705-AY           | RING, O                                | 3   |
| 6705-AZ           | COLLAR                                 | 1   |
| 6705-BA           | SPRING, COMPRESSION                    | 1   |
| 6705-BB           | WIRE, ORIFICE TURNING                  | 1   |
| 6705-BC           | SPRING, COMPRESSION                    | 2   |
| 6705-BD           | PLUNGER, CHECK                         | 2   |
| 6705-BE           | STOPPER                                | 1   |
| 6705-BH           | PLUG                                   | 1   |
| 6705-BI           | PLUG                                   | 1   |
| 6705-BJ           | SEAT, VALVE                            | 1   |
| 6705-BK           | VALVE, CHECK                           | 1   |
| 6705-BL           | SEAT, INSERT                           | 2   |
| 6705-BM           | VALVE SUB-ASSY, RELIEF                 | 1   |
| 6705-BN           | RING, O                                | 1   |
| 6705-BO           | SPRING                                 | 1   |

(FSV ) ( 8 ) G107

| PART NAME<br>CODE | PART NAME | QTY |
|-------------------|-----------|-----|
| 6705-BP           | STOPPER   | 1   |
| 6705-BT           | FITTING   | 1   |
| 6705-BU           | FITTING   | 1   |
| 6705-BV           | FITTING   | 2   |
| 6705-BW           | FITTING   | 1   |
| 6705-BX           | FITTING   | 2   |
| 6705-BY           | FITTING   | 1   |
| 6705-BZ           | PLUG      | 3   |


(FSV ) ( 9 ) G107

FIG. 6709  
OIL CONTROL VALVE LINK

6709

FSV

FSV (3-WAY)




6709 001A

6709-004

FIG. 6709  
OIL CONTROL VALVE LINK

6709

FSV (4-WAY)




6709-003

| PART NAME<br>CODE | PART NAME                               | QTY |
|-------------------|-----------------------------------------|-----|
| 6709-20           | LEVER SUB-ASSY, CONTROL VALVE, NO.1     | 1   |
| 6709-21           | LEVER SUB-ASSY, CONTROL VALVE, NO.2     | 1   |
| 6709-22           | LEVER SUB-ASSY, CONTROL VALVE, NO.3     | 1   |
| 6709-23           | LEVER SUB-ASSY, CONTROL VALVE, NO.4     | 1   |
| 6709-30           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1 | 1   |
| 6709-30A          | PIN (FOR CONTROL VALVE LEVER ROD)       | 4   |
| 6709-31           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2 | 1   |
| 6709-40           | KNOB, OIL CONTROL VALVE LEVER           | 2   |
| 6709-41           | PIN, OIL CONTROL VALVE LEVER            | 1   |
| 6709-41A          | BUSH (FOR LEVER PIN)                    | 4   |
| 6709-48           | BOOT, CONTROL VALVE LINK, NO.1          | 2   |
| 6709-49           | BOOT, CONTROL VALVE LINK, NO.2          | 2   |
| 6709-50           | TURNBUCKLE                              | 1   |
| 6709-AA           | BRACKET SUB-ASSY                        | 1   |
| 6709-AC           | NUT                                     | 1   |

(FSV ) ( 10)

G107

6801



| PART NAME<br>CODE | PART NAME                                 | QTY  |
|-------------------|-------------------------------------------|------|
| 6801-10           | FILTER ASSY, SUCTION                      | 1    |
| 6801-11           | FILTER ASSY, RETURN                       | 1    |
| 6801-12           | VALVE ASSY, FLOW REGULATOR                | 1    |
| 6801-15A          | PLUG (FOR OIL TANK DRAIN)                 | 1    |
| 6801-15B          | GASKET (FOR OIL TANK DRAIN PLUG)          | 1    |
| 6801-20           | PIPE SUB-ASSY (PUMP INLET)                | 1    |
| 6801-20A          | RING, O (FOR OIL PUMP INLET)              | 1    |
| 6801-21A          | RING, O (FOR OIL PUMP OUTLET)             | 1    |
| 6801-23           | PIPE SUB-ASSY (TILT CYLINDER FRONT)       | 1    |
| 6801-24           | PIPE SUB-ASSY (TILT CYLINDER REAR)        | 1    |
| 6801-26           | OUTLET SUB-ASSY, OIL TANK                 | 1    |
| 6801-26A          | PACKING, OIL TANK COVER                   | 1    |
| 6801-27           | CAP SUB-ASSY, OIL TANK                    | 1    |
| 6801-30           | HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) | 1    |
| 6801-32           | HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) | 1    |
| 6801-33           | HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT) | 2    |
| 6801-34           | HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)    | 1    |
| 6801-35           | HOSE, HIGH PRESSURE, NO.1 (TILT REAR)     | 1    |
| 6801-36           | HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)    | 1    |
| 6801-37           | HOSE, HIGH PRESSURE, NO.2 (TILT REAR)     | 1    |
| 6801-45           | FITTING (FOR TILT CYLINDER)               | 4    |
| 6801-46           | FITTING (FOR LIFT CYLINDER)               | 2    |
| 6801-50           | HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)   | 2    |
| 6801-50A          | CLAMP (FOR LIFT TO TANK NO.1 HOSE)        | 6- 7 |
| 6801-51           | HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)  | 1    |
| 6801-51A          | CLAMP (FOR VALVE TO TANK NO.1 HOSE)       | 2    |
| 6801-52           | HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)  | 1    |
| 6801-52A          | CLAMP (FOR VALVE TO TANK NO.2 HOSE)       | 2    |
| 6801-55           | HOSE, LOW PRESSURE (TANK TO PUMP)         | 1    |
| 6801-55A          | CLAMP (FOR TANK TO PUMP HOSE)             | 2    |
| 6801-56           | HOSE, LOW PRESSURE (STEERING TO VALVE)    | 1    |
| 6801-59           | HOSE, LOW PRESSURE, NO.2 (LIFT TO TANK)   | 1    |
| 6801-59A          | CLAMP (FOR LIFT TO TANK NO.2 HOSE)        | 2    |
| 6801-AA           | BAND, LIFT CYLINDER OVERFLOW HOSE         | 4    |
| 6801-AB           | CLAMP                                     | 2    |
| 6801-AC           | RING, O                                   | 4    |
| 6801-AD           | BOLT                                      | 8    |
| 6801-AF           | FLANGE, SPLIT                             | 1    |
| 6801-AG           | CLAMP                                     | 1    |
| 6801-AH           | BRACKET SUB-ASSY, TILT HOSE               | 1    |
| 6801-AJ           | BRACKET, HIGH PRESSURE HOSE               | 1    |
| 6801-AK           | CLAMP                                     | 1    |
| 6801-AL           | COVER                                     | 1    |
| 6801-AP           | PIPE                                      | 1    |
| 6801-AR           | FITTING                                   | 1    |
| 6801-AS           | FITTING                                   | 1    |
| 6801-AT           | FITTING                                   | 1    |
| 6801-AV           | RING, O                                   | 6    |
| 6801-AW           | ELBOW SUB-ASSY, 3-WAY                     | 1    |
| 6801-AX           | CAP, OIL TANK OVERFLOW PIPE               | 1    |
| 6801-AZ           | SPRING, COMPRESSION                       | 1    |
| 6801-BA           | PLUG                                      | 1    |
| 6801-BB           | SPRING, COMPRESSION                       | 1    |

(FSV ) ( 11) G107

6801

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 6801-BC           | BALL, STEEL -----                            | 1   |
| 6801-BD           | RING, O -----                                | 1   |
| 6801-BF           | BRACKET, FLOW REGULATOR -----                | 1   |
| 6801-BJ           | BAND (FOR VALVE TO LIFT CYLINDER HOSE) ----- | 2   |


(FSV ) ( 12) G107

FIG. 6802  
MAST PIPING



FSV "H3850-H4360"

6802

F5V "H4700-H6000"



5802-005



6002-007

6802

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 6802-20           | PULLEY SUB-ASSY, HOSE GUIDE, NO.1 -----      | 1   |
| 6802-30           | PIPE SUB-ASSY, NO.1 (FRONT LIFT) -----       | 1   |
| 6802-41           | HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT) ----- | 1   |
| 6802-48           | FITTING (FOR FRONT LIFT CYLINDER) -----      | 1   |
| 6802-AA           | PIN, HOSE GUIDE PULLEY -----                 | 1   |
| 6802-AC           | RING, O -----                                | 1   |
| 6802-AD           | COLLAR -----                                 | 1   |
| 6802-AI           | BRACKET, PIPE -----                          | 1   |
| 6802-AJ           | CLAMP -----                                  | 2   |
| 6802-AK           | GUIDE SUB-ASSY, HOSE -----                   | 1   |

(FSV ) ( 13 } G107


**MEMO**

silverhorn.co.uk

FIG. 6101  
MAST

6101

FV



6101 020A

| PART NAME<br>CODE | PART NAME                      | QTY |
|-------------------|--------------------------------|-----|
| 6101-20           | MAST SUB-ASSY, OUTER           | 1   |
| 6101-20B          | BUSH, MAST SUPPORT             | 2   |
| 6101-21           | MAST SUB-ASSY, INNER           | 1   |
| 6101-30           | STRIP SUB-ASSY, OUTER MAST     | 2   |
| 6101-30A          | SHIM, OUTER MAST STRIP         | 99  |
| 6101-40           | ROLLER, LIFT (FOR OUTER MAST)  | 2   |
| 6101-41           | ROLLER, LIFT (FOR INNER MAST)  | 2   |
| 6101-53           | CUSHION, MAST (FOR INNER MAST) | 2   |
| 6101-AD           | FITTING, GREASE                | 2   |
| 6101-AF           | COVER, ROLLER                  | 2   |
| 6101-AH           | BOLT                           | 4   |
| 6101-AI           | STOPPER                        | 2   |
| 6101-AJ           | SHIM, STOPPER                  | 6   |


(FV) ( 1 )

G107

FIG-6301  
LIFT BRACKET & FORK

6301

FV



6301 018

| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6301-20           | BACKREST SUB-ASSY                  | 1   |
| 6301-21           | FORK SUB-ASSY                      | 2   |
| 6301-22           | BRACKET SUB-ASSY, LIFT             | 1   |
| 6301-40           | ROLLER, LIFT (UPPER, LOWER)        | 4   |
| 6301-40A          | RING, SHAFT SNAP (UPPER, LOWER)    | 2   |
| 6301-40B          | SHIM, LIFT ROLLER                  | 99  |
| 6301-41           | ROLLER, LIFT (CENTER)              | 2   |
| 6301-41A          | RING, SHAFT SNAP (CENTER)          | 2   |
| 6301-42           | ROLLER, SIDE                       | 2   |
| 6301-42B          | SPACER (FOR SIDE ROLLER)           | 4   |
| 6301-43           | SHAFT, SIDE ROLLER                 | 2   |
| 6301-44           | HOLDER, SIDE ROLLER SHAFT          | 4   |
| 6301-44A          | SHIM (FOR SHAFT HOLDER)            | 99  |
| 6301-46           | PIN, FORK STOPPER                  | 2   |
| 6301-47           | KNOB, FORK STOPPER PIN             | 2   |
| 6301-48           | SPRING, FORK STOPPER PIN           | 2   |
| 6301-49           | PIN, SPRING (FOR FORK STOPPER PIN) | 2   |
| 6301-AA           | COVER, LIFT BRACKET ROLLER         | 4   |
| 6301-AB           | PLATE, SIDE                        | 2   |


(FV ) ( 2 )

G107

FIG. 6302  
CHAIN & CHAIN WHEEL

6302

FV



6302 017A

| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 6302-21           | CHAIN SUB-ASSY (FRONT)                   | 2   |
| 6302-21A          | NUT, CHAIN ADJUST (FRONT)                | 2   |
| 6302-21K          | BOLT KIT, CHAIN ANCHOR, NO.1 (FRONT)     | 2   |
| 6302-21M          | BOLT KIT, CHAIN EYE (FRONT)              | 2   |
| 6302-41           | WHEEL, CHAIN (FRONT)                     | 2   |
| 6302-41A          | RING, SHAFT SNAP (FOR FRONT CHAIN WHEEL) | 2   |
| 6302-45           | SUPPORT, CHAIN WHEEL                     | 1   |
| 6302-AD           | NUT, HEXAGON                             | 2   |
| 6302-AE           | WASHER, CHAIN SPECIAL                    | 2   |
| 6302-AH           | COVER, CHAIN WHEEL                       | 2   |


(FV) ( 3)

G107

FIG. 6502  
FRONT LIFT CYLINDER

6502

FV



6502 006

| PART NAME<br>CODE | PART NAME                         | QTY |
|-------------------|-----------------------------------|-----|
| 6502-01           | CYLINDER ASSY, LIFT               | 1   |
| 6502-01K          | CYLINDER O/H KIT, LIFT            | 1   |
| 6502-11           | VALVE ASSY, SAFETY DOWN           | 1   |
| 6502-20           | CYLINDER SUB-ASSY, LIFT           | 1   |
| 6502-21           | ROD SUB-ASSY, LIFT CYLINDER       | 1   |
| 6502-30           | GUIDE SUB-ASSY, LIFT CYLINDER ROD | 1   |
| 6502-42           | SLEEVE, LIFT CYLINDER ROD GUIDE   | 1   |
| 6502-AA           | BUSHING                           | 1   |
| 6502-AB           | RING, O                           | 1   |
| 6502-AC           | RING, BACK UP                     | 1   |
| 6502-AD           | PACKING, U                        | 1   |
| 6502-AE           | RING, BACK UP                     | 1   |
| 6502-AF           | SEAL, DUST                        | 1   |
| 6502-AG           | RING, O                           | 1   |
| 6502-AH           | PLUG                              | 1   |
| 6502-A1           | RING, O                           | 1   |


(FV) ( 4 )

G107

FIG. 6503  
REAR LIFT CYLINDER

6503

FV



| PART NAME<br>CODE | PART NAME                             | QTY  |
|-------------------|---------------------------------------|------|
| 6503-01           | CYLINDER ASSY, LIFT, RH               | 1    |
| 6503-01K          | CYLINDER O/H KIT, LIFT, RH            | 1    |
| 6503-02           | CYLINDER ASSY, LIFT, LH               | 1    |
| 6503-02K          | CYLINDER O/H KIT, LIFT, LH            | 1    |
| 6503-11           | VALVE ASSY, SAFETY DOWN               | 1    |
| 6503-20           | CYLINDER SUB-ASSY, LIFT, RH           | 1    |
| 6503-21           | CYLINDER SUB-ASSY, LIFT, LH           | 1    |
| 6503-22           | ROD SUB-ASSY, LIFT CYLINDER, RH       | 1    |
| 6503-23           | ROD SUB-ASSY, LIFT CYLINDER, LH       | 1    |
| 6503-30           | GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH | 1    |
| 6503-31           | GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH | 1    |
| 6503-42           | SLEEVE, LIFT CYLINDER ROD GUIDE       | 2    |
| 6503-AA           | RING, WEAR                            | 2    |
| 6503-AC           | RING, BACK UP                         | 2    |
| 6503-AE           | PACKING, U                            | 2    |
| 6503-AF           | RING, O                               | 2    |
| 6503-AG           | SEAL, DUST                            | 2    |
| 6503-AH           | RING, O                               | 1    |
| 6503-AI           | SHIM                                  | 2    |
| 6503-AK           | BRACKET SUB-ASSY, LIFT CYLINDER       | 2    |
| 6503-AL           | BUSHING                               | 4    |
| 6503-AM           | SPACER                                | 2    |
| 6503-AN           | SHIM                                  | 2- 6 |
| 6503-AP           | PLUG                                  | 2    |


(FV) ( 5 )

G107

6511

PART NAME  
CODE

QTY




C107

FIG. 6701  
OIL PUMP

6701

FV



| PART NAME<br>CODE | PART NAME         | QTY |
|-------------------|-------------------|-----|
| 6701-01           | PUMP ASSY, OIL    | 1   |
| 6701-01K          | PUMP O/H KIT, OIL | 1   |
| 6701-10           | GEAR SET          | 1   |
| 6701-11           | BUSH SET          | 2   |
| 6701-43           | BODY              | 1   |
| 6701-44           | FLANGE, MOUNTING  | 1   |
| 6701-44A          | PACKING, OIL PUMP | 1   |
| 6701-45           | COVER             | 1   |
| 6701-AA           | SEAL, BUSHING     | 2   |
| 6701-AB           | RING, BACKING, RH | 2   |
| 6701-AC           | RING, BACKING, LH | 2   |
| 6701-AD           | SEAL, OIL         | 1   |
| 6701-AE           | RING, SNAP        | 1   |
| 6701-AF           | BOLT              | 4   |
| 6701-AG           | WASHER, SPRING    | 4   |
| 6701-AH           | SEAL, BODY        | 2   |
| 6701-AI           | BOLT              | 2   |


(FV) ( 7 )

G107

FIG. 6705  
DIL CONTROL VALVE

6705




FV



6705-005 A

6705

(W/REMOTE CONTROL VALVE)




G(DT 002-051)

FIG. 6705  
OIL CONTROL VALVE

**6705**

FV (4-WAY)



6 JOE-107A

# 6705

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 6705-01           | VALVE ASSY, OIL CONTROL -----                | 1   |
| 6705-01K          | VALVE O/H KIT, OIL CONTROL -----             | 1   |
| 6705-10           | VALVE ASSY, PLUNGER SECTION, NO.1 -----      | 1   |
| 6705-11           | VALVE ASSY, PLUNGER SECTION, NO.2 -----      | 1   |
| 6705-20           | VALVE SET, PILOT RELIEF, NO.1 -----          | 1   |
| 6705-21           | VALVE SET, PILOT RELIEF, NO.2 -----          | 1   |
| 6705-23           | HOUSING & SPOOL SET, NO.1 -----              | 1   |
| 6705-25           | HOUSING & SPOOL SET, ATTACHMENT, NO.1 -----  | 1   |
| 6705-26           | HOUSING & SPOOL SET, ATTACHMENT, NO.2 -----  | 1   |
| 6705-40           | COVER, SPRING -----                          | 2   |
| 6705-41           | SPRING, COMPRESSION (FOR SPOOL RETURN) ----- | 2   |
| 6705-50A          | RING, O -----                                | 2   |
| 6705-50B          | RING, O -----                                | 1   |
| 6705-50C          | RING, O -----                                | 2   |
| 6705-AA           | BOLT -----                                   | 4   |
| 6705-AB           | HOUSING, OUTLET -----                        | 1   |
| 6705-AC           | RING, O -----                                | 1   |
| 6705-AD           | RING, O -----                                | 1   |
| 6705-AE           | RING, O -----                                | 2   |
| 6705-AF           | BALL, STEEL -----                            | 1   |
| 6705-AG           | SPRING -----                                 | 1   |
| 6705-AH           | SPRING, COMPRESSION -----                    | 1   |
| 6705-AI           | RING, O -----                                | 1   |
| 6705-AJ           | STOPPER -----                                | 1   |
| 6705-AK           | HOLDER, SPRING -----                         | 2   |
| 6705-AL           | WASHER, PLATE -----                          | 2   |
| 6705-AM           | RING, SHAFT SNAP -----                       | 2   |
| 6705-AN           | SCREW -----                                  | 4   |
| 6705-AO           | PLUG -----                                   | 4   |
| 6705-AP           | RING, O -----                                | 4   |
| 6705-AQ           | RING, BACK UP -----                          | 4   |
| 6705-AR           | HOLDER, SEAL -----                           | 4   |
| 6705-AS           | SCREW -----                                  | 4   |
| 6705-AT           | STOPPER -----                                | 1   |
| 6705-AU           | STOPPER -----                                | 1   |
| 6705-AV           | RING, U -----                                | 2   |
| 6705-AW           | SPRING, COMPRESSION -----                    | 1   |
| 6705-AX           | RING, O -----                                | 3   |
| 6705-AY           | RING, O -----                                | 3   |
| 6705-AZ           | COLLAR -----                                 | 1   |
| 6705-BA           | SPRING, COMPRESSION -----                    | 1   |
| 6705-BB           | WIRE, ORIFICE TURNING -----                  | 1   |
| 6705-BC           | SPRING, COMPRESSION -----                    | 2   |
| 6705-BD           | PLUNGER, CHECK -----                         | 2   |
| 6705-BE           | STOPPER -----                                | 1   |
| 6705-BH           | PLUG -----                                   | 1   |
| 6705-BI           | PLUG -----                                   | 1   |
| 6705-BJ           | SEAT, VALVE -----                            | 1   |
| 6705-BK           | VALVE, CHECK -----                           | 1   |
| 6705-BL           | SEAT, INSERT -----                           | 2   |
| 6705-BM           | VALVE SUB-ASSY, RELIEF -----                 | 1   |
| 6705-BN           | RING, O -----                                | 1   |
| 6705-BO           | SPRING -----                                 | 1   |

(FV ) ( 8) G107

| PART NAME<br>CODE | PART NAME     | QTY |
|-------------------|---------------|-----|
| 6705-BP           | STOPPER ----- | 1   |
| 6705-BT           | FITTING ----- | 1   |
| 6705-BU           | FITTING ----- | 1   |
| 6705-BV           | FITTING ----- | 2   |
| 6705-BW           | FITTING ----- | 1   |
| 6705-BX           | FITTING ----- | 2   |
| 6705-BY           | FITTING ----- | 1   |
| 6705-BZ           | PLUG -----    | 3   |


(FV ) ( 9) G107

FIG. 6709  
OIL CONTROL VALVE LINK

6709

FV

FV (3-WAY)




6709 001A

6709 004

FIG. 6709  
OIL CONTROL VALVE LINK

6709

FV (4-WAY)



| PART NAME<br>CODE | PART NAME                               | QTY |
|-------------------|-----------------------------------------|-----|
| 6709-20           | LEVER SUB-ASSY, CONTROL VALVE, NO.1     | 1   |
| 6709-21           | LEVER SUB-ASSY, CONTROL VALVE, NO.2     | 1   |
| 6709-22           | LEVER SUB-ASSY, CONTROL VALVE, NO.3     | 1   |
| 6709-23           | LEVER SUB-ASSY, CONTROL VALVE, NO.4     | 1   |
| 6709-30           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1 | 1   |
| 6709-30A          | PIN (FOR CONTROL VALVE LEVER ROD)       | 4   |
| 6709-31           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2 | 1   |
| 6709-40           | KNOB, OIL CONTROL VALVE LEVER           | 2   |
| 6709-41           | PIN, OIL CONTROL VALVE LEVER            | 1   |
| 6709-41A          | BUSH (FOR LEVER PIN)                    | 4   |
| 6709-48           | BOOT, CONTROL VALVE LINK, NO.1          | 2   |
| 6709-49           | BOOT, CONTROL VALVE LINK, NO.2          | 2   |
| 6709-50           | TURNBUCKLE                              | 1   |
| 6709-AA           | BRACKET SUB-ASSY                        | 1   |
| 6709-AC           | NUT                                     | 1   |

(FV ) ( 10)

G107

6801


| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 6801-10           | FILTER ASSY, SUCTION -----                   | 1   |
| 6801-11           | FILTER ASSY, RETURN -----                    | 1   |
| 6801-12           | VALVE ASSY, FLOW REGULATOR -----             | 1   |
| 6801-15A          | PLUG (FOR OIL TANK DRAIN) -----              | 1   |
| 6801-15B          | GASKET (FOR OIL TANK DRAIN PLUG) -----       | 1   |
| 6801-20           | PIPE SUB-ASSY (PUMP INLET) -----             | 1   |
| 6801-20A          | RING, O (FOR OIL PUMP INLET) -----           | 1   |
| 6801-21A          | RING, O (FOR OIL PUMP OUTLET) -----          | 1   |
| 6801-23           | PIPE SUB-ASSY (TILT CYLINDER FRONT) -----    | 1   |
| 6801-24           | PIPE SUB-ASSY (TILT CYLINDER REAR) -----     | 1   |
| 6801-26           | OUTLET SUB-ASSY, OIL TANK -----              | 1   |
| 6801-26A          | PACKING, OIL TANK COVER -----                | 1   |
| 6801-27           | CAP SUB-ASSY, OIL TANK -----                 | 1   |
| 6801-30           | HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) -- | 1   |
| 6801-32           | HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) -- | 1   |
| 6801-33           | HOSE, HIGH PRESSURE, NO.2 (VALVE TO LIFT) -- | 1   |
| 6801-34           | HOSE, HIGH PRESSURE, NO.1 (TILT FRONT) ----- | 1   |
| 6801-35           | HOSE, HIGH PRESSURE, NO.1 (TILT REAR) -----  | 1   |
| 6801-36           | HOSE, HIGH PRESSURE, NO.2 (TILT FRONT) ----- | 1   |
| 6801-37           | HOSE, HIGH PRESSURE, NO.2 (TILT REAR) -----  | 1   |
| 6801-45           | FITTING (FOR TILT CYLINDER) -----            | 4   |
| 6801-46           | FITTING (FOR LIFT CYLINDER) -----            | 1   |
| 6801-51           | HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK) --- | 1   |
| 6801-51A          | CLAMP (FOR VALVE TO TANK NO.1 HOSE) -----    | 2   |
| 6801-52           | HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK) --- | 1   |
| 6801-52A          | CLAMP (FOR VALVE TO TANK NO.2 HOSE) -----    | 2   |
| 6801-55           | HOSE, LOW PRESSURE (TANK TO PUMP) -----      | 1   |
| 6801-55A          | CLAMP (FOR TANK TO PUMP HOSE) -----          | 2   |
| 6801-56           | HOSE, LOW PRESSURE (STEERING TO VALVE) ----- | 1   |
| 6801-AC           | RING, O -----                                | 4   |
| 6801-AD           | BOLT -----                                   | 8   |
| 6801-AF           | FLANGE, SPLIT -----                          | 1   |
| 6801-AG           | CLAMP -----                                  | 1   |
| 6801-AH           | BRACKET SUB-ASSY, TILT HOSE -----            | 1   |
| 6801-AI           | RING, O -----                                | 1   |
| 6801-AJ           | BRACKET, HIGH PRESSURE HOSE -----            | 1   |
| 6801-AK           | CLAMP -----                                  | 1   |
| 6801-AL           | COVER -----                                  | 1   |
| 6801-AR           | FITTING -----                                | 1   |
| 6801-AS           | FITTING -----                                | 1   |
| 6801-AT           | FITTING -----                                | 1   |
| 6801-AV           | RING, O -----                                | 4   |
| 6801-AZ           | SPRING, COMPRESSION -----                    | 1   |
| 6801-BA           | PLUG -----                                   | 1   |
| 6801-BB           | SPRING, COMPRESSION -----                    | 1   |
| 6801-BC           | BALL, STEEL -----                            | 1   |
| 6801-BD           | RING, O -----                                | 1   |
| 6801-BE           | PROTECTOR -----                              | 1   |

(FV ) ( 11 ) G107

FIG. 6802  
MAST PIPING

6802

FV



| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 6802-30           | PIPE SUB-ASSY, NO.1 (FRONT LIFT) -----       | 1   |
| 6802-41           | HOSE, HIGH PRESSURE, NO.1 (FRONT LIFT) ----- | 1   |
| 6802-48           | FITTING (FOR FRONT LIFT CYLINDER) -----      | 2   |
| 6802-AB           | FITTING -----                                | 1   |
| 6802-AC           | RING, O -----                                | 2   |
| 6802-AF           | GUARD SUB-ASSY, HOSE -----                   | 1   |

(FV ) ( 12)

G107


**MEMO**

silverhorn.co.uk

FIG. 6101  
MAST

6101

H




| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6101-20           | MAST SUB-ASSY, OUTER               | 1   |
| 6101-20B          | BUSH, MAST SUPPORT                 | 2   |
| 6101-21           | MAST SUB-ASSY, INNER               | 1   |
| 6101-30           | STRIP SUB-ASSY, OUTER MAST         | 2   |
| 6101-30A          | SHIM, OUTER MAST STRIP             | 99  |
| 6101-40           | ROLLER, LIFT (FOR OUTER MAST)      | 2   |
| 6101-40A          | SHIM, LIFT ROLLER (FOR OUTER MAST) | 99  |
| 6101-41           | ROLLER, LIFT (FOR INNER MAST)      | 2   |
| 6101-41A          | SHIM, LIFT ROLLER (FOR INNER MAST) | 99  |
| 6101-53           | CUSHION, MAST (FOR INNER MAST)     | 2   |
| 6101-AA           | PIN, SPRING                        | 2   |
| 6101-AB           | GUIDE, CHAIN WHEEL SUPPORT         | 2   |
| 6101-AC           | STOPPER, INNER MAST                | 2   |
| 6101-AE           | BOLT, STOPPER                      | 1   |
| 6101-AF           | COVER, ROLLER                      | 2   |

(H) (1) G107

FIG. 6301  
LIFT BRACKET & FORK

6301

M




| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6301-20           | BACKREST SUB-ASSY                  | 1   |
| 6301-21           | FORK SUB-ASSY                      | 2   |
| 6301-22           | BRACKET SUB-ASSY, LIFT             | 1   |
| 6301-40           | ROLLER, LIFT (UPPER, LOWER)        | 4   |
| 6301-40A          | RING, SHAFT SNAP (UPPER, LOWER)    | 2   |
| 6301-40B          | SHIM, LIFT ROLLER                  | 99  |
| 6301-41           | ROLLER, LIFT (CENTER)              | 2   |
| 6301-41A          | RING, SHAFT SNAP (CENTER)          | 2   |
| 6301-42           | ROLLER, SIDE                       | 2   |
| 6301-42A          | SHIM (FOR SIDE ROLLER)             | 99  |
| 6301-46           | PIN, FORK STOPPER                  | 2   |
| 6301-47           | KNOB, FORK STOPPER PIN             | 2   |
| 6301-48           | SPRING, FORK STOPPER PIN           | 2   |
| 6301-49           | PIN, SPRING (FOR FORK STOPPER PIN) | 2   |
| 6301-AA           | COVER, LIFT BRACKET ROLLER         | 4   |

(M) ( 2 ) G107

FIG. 6302  
CHAIN & CHAIN WHEEL

6302

M




| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6302-20           | CHAIN SUB-ASSY                     | 2   |
| 6302-20A          | NUT, CHAIN ADJUST                  | 2   |
| 6302-20K          | BOLT KIT, CHAIN ANCHOR, NO.1       | 2   |
| 6302-20M          | BOLT KIT, CHAIN EYE                | 2   |
| 6302-40           | WHEEL, CHAIN                       | 2   |
| 6302-40A          | RING, SHAFT SNAP (FOR CHAIN WHEEL) | 2   |
| 6302-45           | SUPPORT, CHAIN WHEEL               | 1   |
| 6302-AC           | CLAMP, CHAIN ANCHOR BOLT           | 2   |
| 6302-A0           | NUT, HEXAGON                       | 2   |
| 6302-AE           | WASHER, CHAIN SPECIAL              | 2   |
| 6302-AG           | BUSHING                            | 2   |
| 6302-AH           | COVER, CHAIN WHEEL                 | 2   |

(M) ( 3 ) G107

FIG. 6504  
LIFT CYLINDER

6504



6504 007

PART NAME  
CODE

PART NAME

QTY

|          |                                    |   |
|----------|------------------------------------|---|
| 6504-01  | CYLINDER ASSY, LIFT                | 1 |
| 6504-01K | CYLINDER O/H KIT, LIFT             | 1 |
| 6504-1D  | VALVE ASSY, FLOW REGULATOR         | 1 |
| 6504-20  | CYLINDER SUB-ASSY, LIFT            | 1 |
| 6504-21  | ROD SUB-ASSY, LIFT CYLINDER PISTON | 1 |
| 6504-30  | GUIDE SUB-ASSY, LIFT CYLINDER ROD  | 1 |
| 6504-40  | PISTON, LIFT CYLINDER              | 1 |
| 6504-41  | COVER, LIFT CYLINDER               | 1 |
| 6504-42  | SLEEVE, LIFT CYLINDER ROD GUIDE    | 1 |
| 6504-AA  | SPACER, LIFT CYLINDER              | 1 |
| 6504-AB  | RING, STOPPER                      | 1 |
| 6504-AC  | RING, WEAR                         | 1 |
| 6504-AD  | RING, BACK UP                      | 1 |
| 6504-AE  | PACKING, U                         | 1 |
| 6504-AF  | RING, BACK UP                      | 1 |
| 6504-AG  | RING, O                            | 1 |
| 6504-AH  | RING, SHAFT SNAP                   | 1 |
| 6504-AI  | SEAL, DUST                         | 1 |
| 6504-AJ  | PACKING, U                         | 1 |
| 6504-AK  | RING, O                            | 1 |
| 6504-AL  | RING, O                            | 1 |


(M) ( 4 )

G107

FIG. 6511  
TILT CYLINDER

6511

M



| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6511-01           | CYLINDER ASSY, TILT                | 2   |
| 6511-01K          | CYLINDER O/H KIT, TILT             | 2   |
| 6511-20           | CYLINDER SUB-ASSY, TILT            | 2   |
| 6511-20A          | BUSH, PIN (FOR CYLINDER)           | 2   |
| 6511-21           | ROD SUB-ASSY, TILT CYLINDER PISTON | 2   |
| 6511-21B          | NUT, CASTLE                        | 2   |
| 6511-30           | GUIDE SUB-ASSY, TILT CYLINDER ROD  | 2   |
| 6511-31           | PIN SUB-ASSY, TILT CYLINDER, FR    | 2   |
| 6511-32           | PIN SUB-ASSY, TILT CYLINDER, RR    | 2   |
| 6511-40           | PISTON, TILT CYLINDER              | 2   |
| 6511-41           | COVER, TILT CYLINDER               | 2   |
| 6511-42           | SLEEVE, TILT CYLINDER ROD GUIDE    | 2   |
| 6511-44           | JOINT, PISTON ROD                  | 2   |
| 6511-50           | SEAL, GREASE                       | 4   |
| 6511-AA           | RING, HOLE SNAP                    | 2   |
| 6511-AB           | SEAL, DUST                         | 2   |
| 6511-AC           | RING, BACK UP                      | 2   |
| 6511-AD           | RING, O                            | 2   |
| 6511-AE           | RING, BACK UP                      | 2   |
| 6511-AF           | PACKING, U                         | 2   |
| 6511-AG           | PLATE, STOPPER                     | 2   |
| 6511-AH           | RING, HOLE SNAP                    | 2   |
| 6511-AI           | RING, O                            | 2   |
| 6511-AJ           | PACKING, U                         | 4   |
| 6511-AK           | SHIM, TILT CONTROL                 | 99  |
| 6511-AL           | SPACER, TILT CONTROL               | 2   |
| 6511-AM           | RING, O                            | 2   |
| 6511-AN           | COLLAR                             | 4   |


(M) ( ) ( 5 )

G107

FIG. 6701  
OIL PUMP

6701

M




| PART NAME<br>CODE | PART NAME         | QTY |
|-------------------|-------------------|-----|
| 6701-01           | PUMP ASSY, OIL    | 1   |
| 6701-01K          | PUMP O/H KIT, OIL | 1   |
| 6701-10           | GEAR SET          | 1   |
| 6701-11           | BUSH SET          | 2   |
| 6701-43           | BODY              | 1   |
| 6701-44           | FLANGE, MOUNTING  | 1   |
| 6701-44A          | PACKING, OIL PUMP | 1   |
| 6701-45           | COVER             | 1   |
| 6701-AA           | SEAL, BUSHING     | 2   |
| 6701-AB           | RING, BACKING, RH | 2   |
| 6701-AC           | RING, BACKING, LH | 2   |
| 6701-AD           | SEAL, OIL         | 1   |
| 6701-AE           | RING, SNAP        | 1   |
| 6701-AF           | BOLT              | 4   |
| 6701-AG           | WASHER, SPRING    | 4   |
| 6701-AH           | SEAL, BODY        | 2   |
| 6701-AI           | BOLT              | 2   |

(M) ( 6 ) C107

FIG. 6705  
OIL CONTROL VALVE

6705

M




6705-005 A

FIG. 6705  
OIL CONTROL VALVE

6705

M (3-WAY)




6705-006A

FIG. 6705  
OIL CONTROL VALVE

6705

M (4-WAY)



6705-007A

# 6705

| PART NAME<br>CODE | PART NAME                                    | QTY |
|-------------------|----------------------------------------------|-----|
| 6705-01           | VALVE ASSY, OIL CONTROL -----                | 1   |
| 6705-01K          | VALVE O/H KIT, OIL CONTROL -----             | 1   |
| 6705-10           | VALVE ASSY, PLUNGER SECTION, NO.1 -----      | 1   |
| 6705-11           | VALVE ASSY, PLUNGER SECTION, NO.2 -----      | 1   |
| 6705-20           | VALVE SET, PILOT RELIEF, NO.1 -----          | 1   |
| 6705-21           | VALVE SET, PILOT RELIEF, NO.2 -----          | 1   |
| 6705-23           | HOUSING & SPOOL SET, NO.1 -----              | 1   |
| 6705-25           | HOUSING & SPOOL SET, ATTACHMENT, NO.1 -----  | 1   |
| 6705-26           | HOUSING & SPOOL SET, ATTACHMENT, NO.2 -----  | 1   |
| 6705-40           | COVER, SPRING -----                          | 2   |
| 6705-41           | SPRING, COMPRESSION (FOR SPOOL RETURN) ----- | 2   |
| 6705-50A          | RING, O -----                                | 2   |
| 6705-50B          | RING, O -----                                | 1   |
| 6705-50C          | RING, O -----                                | 2   |
| 6705-AA           | BOLT -----                                   | 4   |
| 6705-AB           | HOUSING, OUTLET -----                        | 1   |
| 6705-AC           | RING, O -----                                | 1   |
| 6705-AD           | RING, O -----                                | 1   |
| 6705-AE           | RING, O -----                                | 2   |
| 6705-AF           | BALL, STEEL -----                            | 1   |
| 6705-AG           | SPRING -----                                 | 1   |
| 6705-AH           | SPRING, COMPRESSION -----                    | 1   |
| 6705-AI           | RING, O -----                                | 1   |
| 6705-AJ           | STOPPER -----                                | 1   |
| 6705-AK           | HOLDER, SPRING -----                         | 2   |
| 6705-AL           | WASHER, PLATE -----                          | 2   |
| 6705-AM           | RING, SHAFT SNAP -----                       | 2   |
| 6705-AN           | SCREW -----                                  | 4   |
| 6705-AO           | PLUG -----                                   | 4   |
| 6705-AP           | RING, O -----                                | 4   |
| 6705-AQ           | RING, BACK UP -----                          | 4   |
| 6705-AR           | HOLDER, SEAL -----                           | 4   |
| 6705-AS           | SCREW -----                                  | 4   |
| 6705-AT           | STOPPER -----                                | 1   |
| 6705-AU           | STOPPER -----                                | 1   |
| 6705-AV           | RING, O -----                                | 2   |
| 6705-AW           | SPRING, COMPRESSION -----                    | 1   |
| 6705-AX           | RING, O -----                                | 3   |
| 6705-AY           | RING, O -----                                | 3   |
| 6705-AZ           | COLLAR -----                                 | 1   |
| 6705-BA           | SPRING, COMPRESSION -----                    | 1   |
| 6705-BB           | WIRE, ORIFICE TURNING -----                  | 1   |
| 6705-BC           | SPRING, COMPRESSION -----                    | 2   |
| 6705-BD           | PLUNGER, CHECK -----                         | 2   |
| 6705-BE           | STOPPER -----                                | 1   |
| 6705-BH           | PLUG -----                                   | 1   |
| 6705-BI           | PLUG -----                                   | 1   |
| 6705-BJ           | SEAT, VALVE -----                            | 1   |
| 6705-BK           | VALVE, CHECK -----                           | 1   |
| 6705-BL           | SEAT, INSERT -----                           | 2   |
| 6705-BM           | VALVE SUB-ASSY, RELIEF -----                 | 1   |
| 6705-BN           | RING, O -----                                | 1   |
| 6705-BO           | SPRING -----                                 | 1   |

(M ) ( 7)

G107

| PART NAME<br>CODE | PART NAME     | QTY |
|-------------------|---------------|-----|
| 6705-BP           | STOPPER ----- | 1   |
| 6705-BT           | FITTING ----- | 1   |
| 6705-BU           | FITTING ----- | 1   |
| 6705-BV           | FITTING ----- | 2   |
| 6705-BW           | FITTING ----- | 1   |
| 6705-BX           | FITTING ----- | 2   |
| 6705-BY           | FITTING ----- | 1   |
| 6705-BZ           | PLUG -----    | 3   |

(M ) ( 8)


G107

FIG. 6709  
DIL CONTROL VALVE LINK

6709

M

M (3-WAY)




5709-004

6709 001A

FIG. 6709  
OIL CONTROL VALVE LINK

6709

M (4-WAY)



6709-003


| PART NAME<br>CODE | PART NAME                               | QTY |
|-------------------|-----------------------------------------|-----|
| 6709-20           | LEVER SUB-ASSY, CONTROL VALVE, NO.1     | 1   |
| 6709-21           | LEVER SUB-ASSY, CONTROL VALVE, NO.2     | 1   |
| 6709-22           | LEVER SUB-ASSY, CONTROL VALVE, NO.3     | 1   |
| 6709-23           | LEVER SUB-ASSY, CONTROL VALVE, NO.4     | 1   |
| 6709-30           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1 | 1   |
| 6709-30A          | PIN (FOR CONTROL VALVE LEVER ROD)       | 4   |
| 6709-31           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2 | 1   |
| 6709-40           | KNOB, OIL CONTROL VALVE LEVER           | 2   |
| 6709-41           | PIN, OIL CONTROL VALVE LEVER            | 1   |
| 6709-41A          | BUSH (FOR LEVER PIN)                    | 4   |
| 6709-48           | BOOT, CONTROL VALVE LINK, NO.1          | 2   |
| 6709-49           | BOOT, CONTROL VALVE LINK, NO.2          | 2   |
| 6709-50           | TURNBUCKLE                              | 1   |
| 6709-AA           | BRACKET SUB-ASSY                        | 1   |
| 6709-AC           | NUT                                     | 1   |

(M) ( 9) 6107

FIG. 6801  
BODY PIPING

6801

M



| PART NAME<br>CODE | PART NAME                                 | QTY |
|-------------------|-------------------------------------------|-----|
| 6801-10           | FILTER ASSY, SUCTION                      | 1   |
| 6801-11           | FILTER ASSY, RETURN                       | 1   |
| 6801-15A          | PLUG (FOR OIL TANK DRAIN)                 | 1   |
| 6801-15B          | GASKET (FOR OIL TANK DRAIN PLUG)          | 1   |
| 6801-20           | PIPE SUB-ASSY (PUMP INLET)                | 1   |
| 6801-20A          | RING, O (FOR OIL PUMP INLET)              | 1   |
| 6801-21A          | RING, O (FOR OIL PUMP OUTLET)             | 1   |
| 6801-23           | PIPE SUB-ASSY (TILT CYLINDER FRONT)       | 1   |
| 6801-24           | PIPE SUB-ASSY (TILT CYLINDER REAR)        | 1   |
| 6801-26           | OUTLET SUB-ASSY, OIL TANK                 | 1   |
| 6801-26A          | PACKING, OIL TANK COVER                   | 1   |
| 6801-27           | CAP SUB-ASSY, OIL TANK                    | 1   |
| 6801-30           | HOSE, HIGH PRESSURE, NO.1 (PUMP TO VALVE) | 1   |
| 6801-32           | HOSE, HIGH PRESSURE, NO.1 (VALVE TO LIFT) | 1   |
| 6801-34           | HOSE, HIGH PRESSURE, NO.1 (TILT FRONT)    | 1   |
| 6801-35           | HOSE, HIGH PRESSURE, NO.1 (TILT REAR)     | 1   |
| 6801-36           | HOSE, HIGH PRESSURE, NO.2 (TILT FRONT)    | 1   |
| 6801-37           | HOSE, HIGH PRESSURE, NO.2 (TILT REAR)     | 1   |
| 6801-45           | FITTING (FOR TILT CYLINDER)               | 4   |
| 6801-46           | FITTING (FOR LIFT CYLINDER)               | 1   |
| 6801-50           | HOSE, LOW PRESSURE, NO.1 (LIFT TO TANK)   | 1   |
| 6801-50A          | CLAMP (FOR LIFT TO TANK NO.1 HOSE)        | 2   |
| 6801-51           | HOSE, LOW PRESSURE, NO.1 (VALVE TO TANK)  | 1   |
| 6801-51A          | CLAMP (FOR VALVE TO TANK NO.1 HOSE)       | 2   |
| 6801-52           | HOSE, LOW PRESSURE, NO.2 (VALVE TO TANK)  | 1   |
| 6801-52A          | CLAMP (FOR VALVE TO TANK NO.2 HOSE)       | 2   |
| 6801-55           | HOSE, LOW PRESSURE (TANK TO PUMP)         | 1   |
| 6801-55A          | CLAMP (FOR TANK TO PUMP HOSE)             | 2   |
| 6801-56           | HOSE, LOW PRESSURE (STEERING TO VALVE)    | 1   |
| 6801-AA           | BAND, LIFT CYLINDER OVERFLOW HOSE         | 2   |
| 6801-AB           | CLAMP                                     | 2   |
| 6801-AC           | RING, O                                   | 4   |
| 6801-AD           | BOLT                                      | 8   |
| 6801-AF           | FLANGE, SPLIT                             | 1   |
| 6801-AG           | CLAMP                                     | 1   |
| 6801-AH           | BRACKET SUB-ASSY, TILT HOSE               | 1   |
| 6801-AI           | RING, O                                   | 1   |
| 6801-AJ           | BRACKET, HIGH PRESSURE HOSE               | 1   |
| 6801-AK           | CLAMP                                     | 1   |
| 6801-AL           | COVER                                     | 1   |
| 6801-AW           | ELBOW SUB-ASSY, 3-WAY                     | 1   |
| 6801-AX           | CAP, OIL TANK OVERFLOW PIPE               | 1   |

(M) ( 10 )

6107

6801

003

6107-001-01

**MEMO**

Silverhorn.co.uk

6101

| PART NAME<br>CODE | PART NAME                                | QTY |
|-------------------|------------------------------------------|-----|
| 6101-20           | MAST SUB-ASSY, OUTER -----               | 1   |
| 6101-20B          | BUSH, MAST SUPPORT -----                 | 2   |
| 6101-21           | MAST SUB-ASSY, INNER -----               | 1   |
| 6101-30           | STRIP SUB-ASSY, OUTER MAST -----         | 2   |
| 6101-30A          | SHIM, OUTER MAST STRIP -----             | 99  |
| 6101-40           | ROLLER, LIFT (FOR OUTER MAST) -----      | 2   |
| 6101-40A          | SHIM, LIFT ROLLER (FOR OUTER MAST) ----- | 99  |
| 6101-41           | ROLLER, LIFT (FOR INNER MAST) -----      | 2   |
| 6101-41A          | SHIM, LIFT ROLLER (FOR INNER MAST) ----- | 99  |
| 6101-AD           | FITTING, GREASE -----                    | 2   |
| 6101-AF           | COVER, ROLLER -----                      | 1   |

(V) (1)

G107

6101


0124

6107-001-0531

FIG. 6301  
LIFT BRACKET & FORK

6301

V



6301-016


| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6301-20           | BACKREST SUB-ASSY                  | 1   |
| 6301-21           | FORK SUB-ASSY                      | 2   |
| 6301-22           | BRACKET SUB-ASSY, LIFT             | 1   |
| 6301-40           | ROLLER, LIFT (UPPER, LOWER)        | 4   |
| 6301-40A          | RING, SHAFT SNAP (UPPER, LOWER)    | 2   |
| 6301-40B          | SHIM, LIFT ROLLER                  | 99  |
| 6301-41           | ROLLER, LIFT (CENTER)              | 2   |
| 6301-41A          | RING, SHAFT SNAP (CENTER)          | 2   |
| 6301-42           | ROLLER, SIDE                       | 2   |
| 6301-42A          | SHIM (FOR SIDE ROLLER)             | 99  |
| 6301-46           | PIN, FORK STOPPER                  | 2   |
| 6301-47           | KNOB, FORK STOPPER PIN             | 2   |
| 6301-48           | SPRING, FORK STOPPER PIN           | 2   |
| 6301-49           | PIN, SPRING (FOR FORK STOPPER PIN) | 2   |
| 6301-AA           | COVER, LIFT BRACKET ROLLER         | 2   |

(V) ( 2 ) G107

FIG. 6302  
CHAIN & CHAIN WHEEL

6302

V



| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6302-20           | CHAIN SUB-ASSY                     | 2   |
| 6302-20K          | BOLT KIT, CHAIN ANCHOR, NO.1       | 2   |
| 6302-20L          | BOLT KIT, CHAIN ANCHOR, NO.2       | 2   |
| 6302-40           | WHEEL, CHAIN                       | 2   |
| 6302-40A          | RING, SHAFT SNAP (FOR CHAIN WHEEL) | 2   |
| 6302-AD           | NUT, HEXAGON                       | 4   |
| 6302-AH           | COVER, CHAIN WHEEL                 | 2   |
| 6302-AN           | NUT, HEXAGON                       | 2   |



(V) ( 3 )

G107

FIG. 6501  
LIFT CYLINDER

6501

V




| PART NAME<br>CODE | PART NAME                             | QTY |
|-------------------|---------------------------------------|-----|
| 6501-01           | CYLINDER ASSY, LIFT, RH               | 1   |
| 6501-01K          | CYLINDER O/H KIT, LIFT, RH            | 1   |
| 6501-02           | CYLINDER ASSY, LIFT, LH               | 1   |
| 6501-02K          | CYLINDER O/H KIT, LIFT, LH            | 1   |
| 6501-11           | VALVE ASSY, SAFETY DOWN               | 1   |
| 6501-20           | CYLINDER SUB-ASSY, LIFT, RH           | 1   |
| 6501-21           | CYLINDER SUB-ASSY, LIFT, LH           | 1   |
| 6501-22           | ROD SUB-ASSY, LIFT CYLINDER, RH       | 1   |
| 6501-23           | ROD SUB-ASSY, LIFT CYLINDER, LH       | 1   |
| 6501-30           | GUIDE SUB-ASSY, LIFT CYLINDER ROD, RH | 1   |
| 6501-31           | GUIDE SUB-ASSY, LIFT CYLINDER ROD, LH | 1   |
| 6501-42           | SLEEVE, LIFT CYLINDER ROD GUIDE       | 2   |
| 6501-AA           | RING, WEAR                            | 2   |
| 6501-AB           | PACKING, U                            | 2   |
| 6501-AC           | RING, BACK UP                         | 2   |
| 6501-AE           | PACKING, U                            | 2   |
| 6501-AF           | RING, O                               | 2   |
| 6501-AG           | SEAL, DUST                            | 2   |
| 6501-AH           | RING, O                               | 1   |
| 6501-AI           | SHIM                                  | 99  |
| 6501-AK           | BRACKET SUB-ASSY, LIFT CYLINDER       | 2   |
| 6501-AL           | BUSHING                               | 4   |
| 6501-AM           | SPACER                                | 2   |
| 6501-AN           | SHIM                                  | 99  |

(V) (4) G107

FIG. 6511  
TILT CYLINDER

6511

V




| PART NAME<br>CODE | PART NAME                          | QTY |
|-------------------|------------------------------------|-----|
| 6511-01           | CYLINDER ASSY, TILT                | 2   |
| 6511-01K          | CYLINDER O/H KIT, TILT             | 2   |
| 6511-20           | CYLINDER SUB-ASSY, TILT            | 2   |
| 6511-20A          | BUSH, PIN (FOR CYLINDER)           | 2   |
| 6511-21           | ROD SUB-ASSY, TILT CYLINDER PISTON | 2   |
| 6511-21B          | NUT, CASTLE                        | 2   |
| 6511-30           | GUIDE SUB-ASSY, TILT CYLINDER ROD  | 2   |
| 6511-31           | PIN SUB-ASSY, TILT CYLINDER, FR    | 2   |
| 6511-32           | PIN SUB-ASSY, TILT CYLINDER, RR    | 2   |
| 6511-40           | PISTON, TILT CYLINDER              | 2   |
| 6511-41           | COVER, TILT CYLINDER               | 2   |
| 6511-42           | SLEEVE, TILT CYLINDER ROD GUIDE    | 2   |
| 6511-44           | JOINT, PISTON ROD                  | 2   |
| 6511-50           | SEAL, GREASE                       | 4   |
| 6511-AA           | RING, HOLE SNAP                    | 2   |
| 6511-AB           | SEAL, DUST                         | 2   |
| 6511-AC           | RING, BACK UP                      | 2   |
| 6511-AD           | RING, O                            | 2   |
| 6511-AE           | RING, BACK UP                      | 2   |
| 6511-AF           | PACKING, U                         | 2   |
| 6511-AG           | PLATE, STOPPER                     | 2   |
| 6511-AH           | RING, HOLE SNAP                    | 2   |
| 6511-AI           | RING, O                            | 2   |
| 6511-AJ           | PACKING, U                         | 4   |
| 6511-AK           | SHIM, TILT CONTROL                 | 99  |
| 6511-AL           | SPACER, TILT CONTROL               | 2   |
| 6511-AM           | RING, O                            | 2   |
| 6511-AN           | COLLAR                             | 4   |

(V) (5) G107

FIG-6701  
OIL PUMP

6701




| PART NAME<br>CODE | PART NAME         | QTY |
|-------------------|-------------------|-----|
| 6701-01           | PUMP ASSY, OIL    | 1   |
| 6701-01K          | PUMP O/H KIT, OIL | 1   |
| 6701-10           | GEAR SET          | 1   |
| 6701-11           | BUSH SET          | 2   |
| 6701-43           | BODY              | 1   |
| 6701-44           | FLANGE, MOUNTING  | 1   |
| 6701-44A          | PACKING, OIL PUMP | 1   |
| 6701-45           | COVER             | 1   |
| 6701-AA           | SEAL, BUSHING     | 2   |
| 6701-AB           | RING, BACKING, RH | 2   |
| 6701-AC           | RING, BACKING, LH | 2   |
| 6701-AD           | SEAL, OIL         | 1   |
| 6701-AE           | RING, SNAP        | 1   |
| 6701-AF           | BOLT              | 4   |
| 6701-AG           | WASHER, SPRING    | 4   |
| 6701-AH           | SEAL, BODY        | 2   |
| 6701-AI           | BOLT              | 2   |

(V) ( 6 ) G107

FIG. 6705  
DIL CONTROL VALVE

6705

V






6705-005 A

FIG. 6705  
OIL CONTROL VALVE

6705

V (3-WAY)




6705-006A

FIG. 6705  
OIL CONTROL VALVE

6705

V (4-WAY)



6705-007A

# 6705

| PART NAME<br>CODE | PART NAME                              | QTY |
|-------------------|----------------------------------------|-----|
| 6705-01           | VALVE ASSY, OIL CONTROL                | 1   |
| 6705-01K          | VALVE O/H KIT, OIL CONTROL             | 1   |
| 6705-10           | VALVE ASSY, PLUNGER SECTION, NO.1      | 1   |
| 6705-11           | VALVE ASSY, PLUNGER SECTION, NO.2      | 1   |
| 6705-20           | VALVE SET, PILOT RELIEF, NO.1          | 1   |
| 6705-21           | VALVE SET, PILOT RELIEF, NO.2          | 1   |
| 6705-23           | HOUSING & SPOOL SET, NO.1              | 1   |
| 6705-25           | HOUSING & SPOOL SET, ATTACHMENT, NO.1  | 1   |
| 6705-26           | HOUSING & SPOOL SET, ATTACHMENT, NO.2  | 1   |
| 6705-40           | COVER, SPRING                          | 2   |
| 6705-41           | SPRING, COMPRESSION (FOR SPOOL RETURN) | 2   |
| 6705-50A          | RING, O                                | 2   |
| 6705-50B          | RING, O                                | 1   |
| 6705-50C          | RING, O                                | 2   |
| 6705-AA           | BOLT                                   | 4   |
| 6705-A0           | HOUSING, OUTLET                        | 1   |
| 6705-AC           | RING, O                                | 1   |
| 6705-AD           | RING, O                                | 1   |
| 6705-AE           | RING, O                                | 2   |
| 6705-AF           | BALL, STEEL                            | 1   |
| 6705-AG           | SPRING                                 | 1   |
| 6705-AH           | SPRING, COMPRESSION                    | 1   |
| 6705-AI           | RING, O                                | 1   |
| 6705-AJ           | STOPPER                                | 1   |
| 6705-AK           | HOLDER, SPRING                         | 2   |
| 6705-AL           | WASHER, PLATE                          | 2   |
| 6705-AM           | RING, SHAFT SNAP                       | 2   |
| 6705-AN           | SCREW                                  | 4   |
| 6705-A0           | PLUG                                   | 4   |
| 6705-AP           | RING, O                                | 4   |
| 6705-AQ           | RING, BACK UP                          | 4   |
| 6705-AR           | HOLDER, SEAL                           | 4   |
| 6705-AS           | SCREW                                  | 4   |
| 6705-AT           | STOPPER                                | 1   |
| 6705-AU           | STOPPER                                | 1   |
| 6705-AV           | RING, O                                | 2   |
| 6705-AW           | SPRING, COMPRESSION                    | 1   |
| 6705-AX           | RING, O                                | 3   |
| 6705-AY           | RING, O                                | 3   |
| 6705-AZ           | COLLAR                                 | 1   |
| 6705-BA           | SPRING, COMPRESSION                    | 1   |
| 6705-BB           | WIRE, ORIFICE TURNING                  | 1   |
| 6705-BC           | SPRING, COMPRESSION                    | 2   |
| 6705-BD           | PLUNGER, CHECK                         | 2   |
| 6705-BE           | STOPPER                                | 1   |
| 6705-BH           | PLUG                                   | 1   |
| 6705-BI           | PLUG                                   | 1   |
| 6705-BJ           | SEAT, VALVE                            | 1   |
| 6705-BK           | VALVE, CHECK                           | 1   |
| 6705-BL           | SEAT, INSERT                           | 2   |
| 6705-BM           | VALVE SUB-ASSY, RELIEF                 | 1   |
| 6705-BN           | RING, O                                | 1   |
| 6705-BO           | SPRING                                 | 1   |

(V) ( 7 ) 6107

| PART NAME<br>CODE | PART NAME | QTY |
|-------------------|-----------|-----|
| 6705-BP           | STOPPER   | 1   |
| 6705-BT           | FITTING   | 1   |
| 6705-BU           | FITTING   | 1   |
| 6705-BV           | FITTING   | 2   |
| 6705-BW           | FITTING   | 1   |
| 6705-BX           | FITTING   | 2   |
| 6705-BY           | FITTING   | 1   |
| 6705-BZ           | PLUG      | 3   |


(V) ( 8 ) 6107

FIG. 6709  
DIL CONTROL VALVE LINK

6709

V (3-WAY)

V




6709 001A

6709 004

FIG. 6709  
OIL CONTROL VALVE LINK

6709

V (4-WAY)



6709-003

| PART NAME<br>CODE | PART NAME                               | QTY |
|-------------------|-----------------------------------------|-----|
| 6709-20           | LEVER SUB-ASSY, CONTROL VALVE, NO.1     | 1   |
| 6709-21           | LEVER SUB-ASSY, CONTROL VALVE, NO.2     | 1   |
| 6709-22           | LEVER SUB-ASSY, CONTROL VALVE, NO.3     | 1   |
| 6709-23           | LEVER SUB-ASSY, CONTROL VALVE, NO.4     | 1   |
| 6709-30           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.1 | 1   |
| 6709-30A          | PIN (FOR CONTROL VALVE LEVER ROD)       | 4   |
| 6709-31           | ROD SUB-ASSY, CONTROL VALVE LEVER, NO.2 | 1   |
| 6709-40           | KNOB, OIL CONTROL VALVE LEVER           | 2   |
| 6709-41           | PIN, OIL CONTROL VALVE LEVER            | 1   |
| 6709-41A          | BUSH (FOR LEVER PIN)                    | 4   |
| 6709-48           | BOOT, CONTROL VALVE LINK, NO.1          | 2   |
| 6709-49           | BOOT, CONTROL VALVE LINK, NO.2          | 2   |
| 6709-50           | TURNBUCKLE                              | 1   |
| 6709-AA           | BRACKET SUB-ASSY                        | 1   |
| 6709-AC           | NUT                                     | 1   |

(V ) ( 9 )

G107

6801



6107

6801

| PART NAME<br>CODE | PART NAME                 | QTY |
|-------------------|---------------------------|-----|
| 6801-BB           | SPRING, COMPRESSION ----- | 1   |
| 6801-BC           | BALL, STEEL -----         | 1   |
| 6801-BD           | RING, O -----             | 1   |
| 6801-BE           | PROTECTOR -----           | 1   |

(v ) ( 11) G107

**MEMO**

Silverhorn.co.uk

**MEMO**

Silverhorn.co.uk