

<b>DTC</b>	<b>P0420</b>	<b>Catalyst System Efficiency Below Threshold (Bank 1)</b>
<b>DTC</b>	<b>P0430</b>	<b>Catalyst System Efficiency Below Threshold (Bank 2)</b>

### MONITOR DESCRIPTION

The ECM uses sensors mounted in front of and behind the Three-Way Catalytic Converter (TWC) to monitor its efficiency.

The first sensor, the Air-Fuel Ratio (A/F) sensor, sends pre-catalyst information to the ECM. The second sensor, the Heated Oxygen (HO2) sensor, sends post-catalyst information to the ECM.

In order to detect any deterioration in the TWC, the ECM calculates the Oxygen Storage Capacity (OSC) of the TWC. This calculation is based on the voltage output of the HO2 sensor while performing active air-fuel ratio control, rather than the conventional detecting method, which uses the locus ratio.

The OSC value is an indication of the oxygen storage capacity of the TWC. When the vehicle is being driven with a warm engine, active air-fuel ratio control is performed for approximately 15 to 20 seconds. When it is performed, the ECM deliberately sets the air-fuel ratio to lean or rich levels. If the rich-lean cycle of the HO2 sensor is long, the OSC becomes greater. There is a direct correlation between the OSCs of the HO2 sensor and the TWC.

The ECM uses the OSC value to determine the state of the TWC. If any deterioration has occurred, it illuminates the MIL and sets the DTC.

DTC No.	DTC Detection Condition	Trouble Area
P0420	OSC value smaller than standard value under active air-fuel ratio control (2 trip detection logic)	<ul style="list-style-type: none"> <li>• Front exhaust pipe (with TWC)</li> <li>• Gas leakage from exhaust system</li> <li>• Air-Fuel Ratio (A/F) sensor (bank 1 sensor 1)</li> <li>• Heated Oxygen (HO2) sensor (bank 1 sensor 2)</li> </ul>
P0430	OSC value smaller than standard value under active air-fuel ratio control (2 trip detection logic)	<ul style="list-style-type: none"> <li>• Gas leakage from exhaust system</li> <li>• Air-Fuel Ratio (A/F) sensor (bank 2 sensor 1)</li> <li>• Heated Oxygen (HO2) sensor (bank 2 sensor 2)</li> <li>• Exhaust manifold (TWC)</li> </ul>

### HINT:

- Bank 1 refers to the bank that includes No. 1 cylinder.
- Bank 2 refers to the bank that does not include No. 1 cylinder.
- Sensor 1 refers to the sensor closest to the engine assembly.
- Sensor 2 refers to the sensor farthest away from the engine assembly.

### MONITOR STRATEGY

Related DTCs	P0420: Catalyst Deterioration (bank 1) P0430: Catalyst Deterioration (bank 2)
Required Sensors/Components (Main)	A/F sensor and HO2 sensor
Required Sensors/Components (Related)	Intake air temperature sensor, mass air flow meter, crankshaft position sensor and engine coolant temperature sensor
Frequency of Operation	Once per driving cycle
Duration	About 30 seconds
MIL Operation	2 driving cycles
Sequence of Operation	None

## TYPICAL ENABLING CONDITIONS

Monitor runs whenever following DTCs not present	P0011 (VVT System 1 - Advance) P0012 (VVT System 1 - Retard) P0021 (VVT System 2 - Advance) P0022 (VVT System 2 - Retard) P0031, P0032, P0051, P0052 (A/F Sensor heater - Sensor 1) P0037, P0038, P0057, P0058 (O2 Sensor heater - Sensor 2) P0100 - P0103 (MAF meter) P0115 - P0118 (ECT sensor) P0120 - P0223, P2135 (TP sensor) P0125 (Insufficient ECT for Closed Loop) P0136, P0156 (O2 Sensor - Sensor 2) P0171, P0172 (Fuel system) P0300 - P0306 (Misfire) P0335 (CKP sensor) P0340 (CMP sensor) P0351 - P0356 (Igniter) P0500 (VSS) P2196, P2198 (A/F Sensor - rationality) P2A00, P2A03 (A/F Sensor - slow response)
Battery voltage	11 V or more
Intake air temperature	-10°C (14°F) or more
Engine coolant temperature	75°C (167°F) or more
Atmospheric pressure	76 kPa (570 mmHg) or more
Idling	OFF
Engine RPM	Less than 3,200 rpm
A/F sensor status	Activated
Fuel system status	Closed loop
Engine load	10 to 70%
All of following conditions (a), (b) and (c) met	-
(a) Mass air flow rate	5 to 60 g/sec.
(b) Estimated front catalyst temperature	600 to 750°C (1,112 to 1,382°F)
(c) Estimated rear catalyst temperature	100 to 900°C (212 to 1,652°F)
EVAP system monitor	The monitor has not run yet or the vacuum introduction has been completed
A/F sensor monitor	Completed
Rear HO2 sensor heater monitor	Completed
Shift position	4th or higher

## TYPICAL MALFUNCTION THRESHOLDS

Oxygen Storage Capacity (OSC) of Three-Way Catalytic Converter (TWC)	Less than 0.046 g
--	-------------------


## MONITOR RESULT

Refer to CHECKING MONITOR STATUS (see page [ES-19](#)).

## CONFIRMATION DRIVING PATTERN

### HINT:

Performing this confirmation pattern will activate the catalyst monitor. This is very useful for verifying the completion of a repair.



READINESS TESTS	
MISFIRE MON .....	AVAIL
FUEL SYS MON .....	AVAIL
COMP MON .....	AVAIL
CAT EVAL .....	INCMPL
HTD CAT EVAL .....	N/A
EVAP EVAL .....	INCMPL
2nd AIR EVAL .....	N/A
A/C EVAL .....	N/A
O2S EVAL .....	INCMPL
O2S HTR EVAL .....	INCMPL
EGR EVAL .....	N/A

A076855E02

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch ON.
- (c) Turn the tester ON.
- (d) Clear DTCs (if set) (see page ES-39).
- (e) Select the following menu items: DIAGNOSIS / ENHANCED OBD II / DATA LIST / USER DATA / CAT CMPL.
- (f) Check that CAT CMPL is INCMPL (incomplete).
- (g) Start the engine and warm it up.
- (h) Drive the vehicle at between 64 km/h and 113 km/h (40 mph and 70 mph) for at least 10 minutes.
- (i) Note the state of the Readiness Tests items. Those items will change to COMPL (complete) as CAT CMPL monitor operates.
- (j) On the tester, select the following menu items: DIAGNOSIS / ENHANCED OBD II / DTC INFO / PENDING CODES and check if any DTCs (any pending DTCs) are set.


HINT:

If CAT CMPL does not change to COMPL, and any pending DTCs fail to set, extend the driving time.

### CONDITIONING FOR SENSOR TESTING

HINT:

Perform the operation with the engine speeds and time durations described below prior to checking the waveforms of the A/F and HO2 sensors. This is in order to activate the sensors sufficiently to obtain the appropriate inspection results.



P

A118003E02

(a) Connect the intelligent tester to the DLC3.


(b) Start the engine and warm it up with all the accessories switched OFF, until the engine coolant temperature stabilizes.

(c) Run the engine at an engine speed of between 2,500 rpm and 3,000 rpm for at least 3 minutes.

(d) While running the engine at 3,000 rpm and 2,000 rpm alternating at 2 second intervals, check the waveforms of the A/F and HO<sub>2</sub> sensors using the tester.

HINT:

- If either voltage output of the Air-Fuel Ratio (A/F) or Heated Oxygen (HO<sub>2</sub>) sensor does not fluctuate, or there is a noise in the waveform of either sensor, the sensor may be malfunctioning.
- If the voltage outputs of both the sensors remain lean or rich, the air-fuel ratio may be extremely lean or rich. In such cases, perform the following A/F CONTROL using the intelligent tester.
- If the Three-Way Catalytic Converter (TWC) has deteriorated, the HO<sub>2</sub> sensor (located behind the TWC) voltage output fluctuates up and down frequently, even under normal driving conditions (active air-fuel ratio control is not performed).



**INSPECTION PROCEDURE**

**HINT:**

Read freeze frame data using the intelligent tester. Freeze frame data records the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

**1 CHECK ANY OTHER DTCS OUTPUT (IN ADDITION TO DTC P0420 OR P0430)**

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch ON and turn the tester ON.
- (c) Select the following menu items: DIAGNOSIS / ENHANCED OBD II / DTC INFO / CURRENT CODES.
- (d) Read DTCs.

**Result**

Display (DTC Output)	Proceed to
P0420 or P0430	A
P0420 or P0430 and other DTCs	B

**HINT:**

If any DTCs other than P0420 or P0430 are output, troubleshoot those DTCs first.

**B** **GO TO DTC CHART**

**A**

**2 PERFORM ACTIVE TEST USING INTELLIGENT TESTER (A/F CONTROL)**

- (a) Connect the intelligent tester to the DLC3.
- (b) Start the engine and turn the tester ON.

- (c) Warm up the engine at an engine speed of 2,500 rpm for approximately 90 seconds.
- (d) On the tester, select the following menu items:  
DIAGNOSIS / ENHANCED OBD II / ACTIVE TEST / A/F CONTROL.
- (e) Perform the A/F CONTROL operation with the engine in an idling condition (press the RIGHT or LEFT button to change the fuel injection volume).
- (f) Monitor the voltage outputs of the A/F and HO2 sensors (AFS B1 S1 and O2S B1 S2 or AFS B2 S1 and O2S B2 S2) displayed on the tester.

**Result:**

**A/F sensor reacts in accordance with increases and decreases in fuel injection volume:**

**+25% = Rich output:**

**Less than 3.0 V**




**-12.5% = Lean output:**

**More than 3.35 V**

**NOTICE:**

**The A/F sensor has an output delay of a few seconds and the HO2 sensor has a maximum output delay of approximately 20 seconds.**

ES

Case	A/F Sensor (Sensor 1) Output Voltage		HO2 Sensor (Sensor 2) Output Voltage		Main Suspected Trouble Area
1	Injection Volume +25% -12.5%		Injection Volume +25% -12.5%		<ul style="list-style-type: none"> <li>• Catalyst</li> <li>• Exhaust gas leakage</li> </ul>
	Output Voltage More than 3.35 V Less than 3.0 V		Output Voltage More than 0.5 V Less than 0.4 V		
2	Injection Volume +25% -12.5%		Injection Volume +25% -12.5%		<ul style="list-style-type: none"> <li>• A/F sensor</li> <li>• A/F sensor heater</li> <li>• A/F sensor circuit</li> </ul>
	Output Voltage Almost no reaction		Output Voltage More than 0.5 V Less than 0.4 V		
3	Injection Volume +25% -12.5%		Injection Volume +25% -12.5%		<ul style="list-style-type: none"> <li>• HO2 sensor</li> <li>• HO2 sensor heater</li> <li>• HO2 sensor circuit</li> </ul>
	Output Voltage More than 3.35 V Less than 3.0 V		Output Voltage Almost no reaction		
4	Injection volume +25% -12.5%		Injection Volume +25% -12.5%		Extremely rich or lean actual air-fuel ratio <ul style="list-style-type: none"> <li>• Injector</li> <li>• Fuel pressure</li> <li>• Gas leakage from exhaust system</li> </ul>
	Output Voltage Almost no reaction		Output Voltage Almost no reaction		

Following the A/F CONTROL procedure enables technicians to check and graph the voltage outputs of both the A/F and HO2 sensors.

To display the graph, select the following menu items on the tester: DIAGNOSIS / ENHANCED OBD II / ACTIVE TEST / A/F CONTROL / USER DATA / AFS B1 S1 and O2S B1 S2 or AFS B2 S1 and O2S B2 S2; then press the YES button and then the ENTER button followed by the F4 button.

**Result**

Result	Proceed to
Case 1	A
Case 2	B
Case 3	C
Case 4	D

B	REPLACE AIR-FUEL RATIO SENSOR
C	Go to step 4
D	CHECK CAUSE OF EXTREMELY RICH OR LEAN ACTUAL AIR-FUEL RATIO, REPLACE FAULTY AREA AND GO TO NEXT STEP

**ES**

A

**3** CHECK FOR EXHAUST GAS LEAKAGE

OK:  
No gas leakage.

NG	REPAIR OR REPLACE EXHAUST GAS LEAKAGE POINT
----	---

OK

REPLACE THREE-WAY CATALYTIC CONVERTER (BOTH FRONT AND REAR CATALYSTS (FRONT EXHAUST PIPE))

**4** CHECK FOR EXHAUST GAS LEAKAGE

OK:  
No gas leakage.

NG	REPAIR OR REPLACE EXHAUST GAS LEAKAGE POINT
----	---

OK

REPLACE HEATED OXYGEN SENSOR